

FURUNO

OPERATOR'S MANUAL

DOPPLER SPEED LOG

MODEL DS-70

TYPE APPROVED BY MINISTRY OF TRANSPORT JAPAN

Model :	DS-70
Approval No.:	2627
Approval Date:	January 24, 1986



FURUNO ELECTRIC CO., LTD.
NISHINOMIYA, JAPAN



© FURUNO ELECTRIC CO., LTD.

9-52, Ashihara-cho,
Nishinomiya, Japan

Telephone: 0798-65-2111
Telefax: 0798-65-4200

•Your Local Agent/Dealer

All rights reserved. Printed in Japan

FIRST EDITION : OCT. 1985
Y1 : AUG. 9, 2001

(TATA)

PUB. No. OME-72220
DS-70



* 00080662500 *



SAFETY INFORMATION

"**WARNING**", "**CAUTION**" and "**NOTICE**" signs appear throughout this manual. It is the responsibility of the installer and operator of the equipment to read, understand and follow these notices. If you have any questions regarding these safety instructions, please contact a FURUNO agent or dealer.

Safety information for both the installer and operator begins on the next page.



WARNING

This notice indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

This notice indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or property damage.

NOTICE

This notice indicates an unsafe practice which, if not avoided, could result in property damage or equipment malfunction.



SAFETY INFORMATION FOR THE INSTALLER



WARNING



Only qualified personnel should work inside the equipment.

This equipment uses high voltage electricity which can shock, burn, or cause death.

Turn off the power at the ship's mains switchboard before beginning the installation. Post a warning sign near the switchboard to ensure that the power will not be applied while the equipment is being installed.

Serious injury or death can result if the power is not turned off, or is applied while the equipment is being installed.



CAUTION



Ground the equipment.

Ungrounded equipment can give off or receive electro-magnetic interference or cause electrical shock.

Confirm that the power supply voltage is compatible with the voltage rating of the equipment.

Connection to the wrong power supply can cause fire or equipment damage. The voltage rating appears on the label at the rear of the equipment.

NOTICE

The mounting location must satisfy the following conditions:

- Away from rain and water splash
- Out of direct sunlight
- Away from air conditioner vents
- Away from magnets and magnetic fields
- Moderate and stable in temperature and humidity



SAFETY INFORMATION FOR THE OPERATOR



WARNING



Do not open the cover of the equipment.

This equipment uses high voltage electricity which can shock, burn, or cause death. Only qualified personnel should work inside the equipment.

Do not disassemble or modify the equipment.

Fire, electrical shock or serious injury can result.

Immediately turn off the power at the ship's mains switchboard if water or foreign object falls into the equipment or the equipment is emitting smoke or fire.

Continued use of the equipment can cause fire, electrical shock or serious injury.



CAUTION

Do not place liquid-filled containers on the top of the equipment.

Fire or electrical shock can result if a liquid spills into the equipment.

Do not place heater near the equipment.

Heat can melt the power cord, which can result in fire or electrical shock.

Do not operate the unit with wet hands.

Electrical shock can result.

Use the correct fuse.

Use of the wrong fuse can cause fire or equipment damage.

(Continued on next page)

NOTICE

Do not use the equipment for other than its intended purpose.

Use of the equipment as a chair or a shelf, for example, can cause equipment damage.

Immediately turn off the power whenever you feel the equipment is abnormal.

Continued use can cause equipment damage.

The useable temperature range is -15°C to 55°C.

Use out of the range can cause equipment damage.

Keep magnets and magnetic fields (speaker, transformer, etc.) away from the equipment.

Magnets and magnetic fields can cause equipment malfunction.

Do not place objects near the equipment.

Objects near the equipment can cause overheating.

Handle the equipment carefully.

Rough handling can cause corrosion.

Do not use chemical cleaners to clean the equipment.

Chemical cleaners can remove paint and markings.

C O N T E N T S

1. PREFACE	1-1 thru 1-3
2. OPERATION	2-1 thru 2-8
2.1 Function of Controls	
Main Display	2-1
Digital Display	2-4
Distance Indicator	2-5
Analog Display	2-6
Dimmer	2-6
2.2 Operating Procedure	
Main Display	2-7
Distance Indicator	2-8
3. INSTALLATION	3-1 thru 3-19
3.1 Mounting	
Main Display	3-1
Digital Display/Distance Indicator	3-2
Analog Display	3-3
Dimmer	3-4
Distribution Box	3-4
Junction Box	3-4
Transducer	3-5
3.2 Wiring	
Main Display	3-10
Junction Box	3-12
Digital Display/Distance Indicator	3-13
Distribution Box	3-15
3.3 After Installation Check and Adjustment	
Alteration of Power Supply	3-17
Adjustment of Response Time/Correction of Speed Indication ..	3-19
4. POST INSTALLATION TEST	4-1 thru 4-7
4.1 Self-test of Main Display	4-1
4.2 Self-test of Distance Indicator	4-2
4.3 Noise Test	4-3
4.4 Sea Test Procedure	4-4

5. OPERATING PRECAUTIONS AND REMARKS ON DOCKING THE SHIP	5-1
5.1 Abnormal Indication in a Specific Area	5-1
5.2 Countermeasure to protect Transducer from being damaged by Dry Dock Block	5-1
SPECIFICATIONS	6-1 thru 6-5
SYSTEM DIAGRAMS	6-6, 6-7
OUTLINE DRAWINGS	6-8 thru 6-28
INTERCONNECTION DIAGRAMS	S-1, S-2
SCHEMATIC DIAGRAMS	S-3 thru S-6
Principle of Doppler Effect	P-1
Declaration of conformity to type	

1. PREFACE

The FURUNO DS-70 Doppler Speed Log measures ship's speed relative to the water. Its operating principle is based on the Doppler Effect; readout of the ship's speed is made by detecting the doppler shift frequency from the signal reflected by the water mass.

The major features of the DS-70 are as follows.

* **Pair-Beam System**

To compensate for errors due to ship's pitch and roll the transducer assemblies symmetrically emit two sonic beams. This pair-beam system indicates an average doppler shift in both directions, thus providing accurate information under rough sea conditions.


* **Durability**

Because the unit has no moving mechanism, and is composed of only electrical parts, very little maintenance is required.

* **Ease of Operation**

In most cases, all that is needed is a simple push of the power switch.






2. OPERATION

2.1 Function of Controls

MAIN DISPLAY

- Front Panel -



POWER SWITCH

This switch provides power to the display unit. (■: ON, ●: OFF)

Ship's Speed Indicator

This indicator displays the ship's speed. The display is updated every second, and the following indicators appear to alert the operator of the present status of the ship's speed reading.


- a) 0:0 (figure with colon) appears shortly after power is turned on and this indicates that the system is now calculating the ship's speed.
- b) A flashing decimal point indicates that the echo level is low; no signal is being received.
- c) When moving astern a "-" (minus sign) is displayed.

Distance Run Indicator

Both forward and astern speeds are measured, and displayed as the distance run. When the power is turned off the present distance run

figure is memorized for about a one week period. When power is reapplied the previous figure is displayed.

- Inner Panel -



DIMMER

This control adjusts the illumination of the display.

TEST SWITCH

NORMAL: Set to this position for normal use.

TEST: When the system appears faulty, place the switch in this position; and the dummy signal can be used in conjunction with this switch to check the system. (Refer to "4. SELF TEST" for detailed application of this switch.)

DUMMY SIGNAL SWITCH

The switch is effective only when the test switch is set to the TEST mode.

0 KNOTS: A 0.00 or 0.01 knot reading indicates the system is operating properly when the switch is placed in this position.

S I G : 24 thru 30 knot reading indicates the system is operating properly when the switch is set to this position.

RESPONSE TIME SWITCH

FAST: With the switch in this position, it takes approx. a half minute to track 90% of the ship's speed.

SLOW: In this position the response time is three times the speed of the FAST position. Use this position when the reading of the ship's speed is unsteady due to rough sea conditions.

NOTE

When the ship's speed is changed in abrupt steps, the true ship's speed reading will be delayed slightly at the SLOW position.

DIGIT SELECTOR SWITCH

This switch is used for presetting the distance run. When set to other than 0, the display will flush, signalling the unit is being preset. Numerals 1 thru 6 are for setting the distance run from tenths of a n.m. to ten thousands of nautical miles, respectively. Numerals 7 thru 9 are not used for setting the distance run. The distance run can be set to a maximum of 99,999.9 n.m.

DISTANCE RUN SETTING SWITCH

The desired value for the distance run is set with this switch.

CLEAR BUTTON

Pressing this button resets the distance run display to 0.0 n.m. The button may be pressed at any time when a reset of the distance run is desired. The button may also be pressed to erase previously memorized data.

SET BUTTON

This button sets the desired value of the selected digit according to the digit selector and distance run setting switch.


Abnormal Lamp

An abnormal lamp lights when the speed data abruptly changes from the ship's present speed due to noise. If the lamp flashes more than about 1 or 2 times within 5 seconds, the speed indication may be unreliable.

Pilot Lamp

A pilot lamp lights when each voltage is correct.

+12V, -12V : All other controls except transmission block
+30V : Transmission block and output transistor
+10V : Remote display




DIGITAL DISPLAY

DIMMER


Adjusts the illumination of the display.

Ship's Speed Indicator

This indicator displays the ship's speed. The arrow marks at the left of the digital display show the ship's moving direction; when moving fore the upper arrow mark (↑) lights up, and when moving astern the lower one (↓) lights up.



DISTANCE INDICATOR



DIMMER

This control adjusts the illumination of the display.

Distance Indicator

This indicator displays the distance run. When the power is turned off, the previous distance run figure is preserved for about a one week period by the incorporated keep-alive battery. If the unit is off for more than one week, all digits indicate zero for about 30 seconds. Then the upper four digits go off, resulting in normal indication.

Note: Indication can be changed to four-digit integral numbers and two-digit decimal numbers with a jumper wire on the pc board. Consult with your dealer or agent if desired.

SELECT


This button is used for presetting the distance run. When this button is pressed successively, a flashing unit for indicating that it is being preset is switched one by one from left to right. When the SELECT button is pressed while the decimal figure is flashing, all digits will flush; signalling the distance run figure is being reset to zero. Further pressing of this button will return to normal indication.

SET

This button sets the desired value of the selected digit according to the SELECT button. Every pressing of the SET button decrements the value at the flashing figure from 9 to 0. Press it until the desired value is obtained. When the SET button is pressed at the moment all digits are flashing, the distance run indication is reset to zero.

ANALOG DISPLAY


The ship's speed is indicated in range scale of -10 to +30 knots (DS-761/762/763) or -10 to +20 knots (DS-771/772/773).



DIMMER

DIMMER

Adjusts the illumination of the display at a remote place.



INTERFACE UNIT

The Interface Unit DS-741 converts serial digital data (current loop) to VDVBN (IEC61102-1) format to enable to connect radar, ARPA, etc.

2.2 Operating Procedure

MAIN DISPLAY

Basic Operating Procedure

1. Apply power to ship's switchboard (if applicable).
2. Set the inner panel controls to the following positions.
 - a) TEST switch is at NORMAL position.
 - b) DIGIT SELECTOR switch to 0.
 - c) Confirm that RESPONSE TIME SELECTOR switch is set to "FAST".
3. Turn DS-70 POWER switch on.
4. Adjust DIMMER control.

After power is applied, the following is displayed for 2-3 minutes while the ship's speed is being measured.

: 0.0 or -:0.0

The colon in the ship's speed display indicates the system is now calculating the ship's speed. After the colon has extinguished, the figures change to the actual speed gradually thereafter. Anytime the reading does not steady, refer to SELF TEST on page 4-1.

Using RESPONSE TIME switch


Normally the switch should be set to the "FAST" position, however, the "SLOW" position should be used under the following conditions.

- a) When sea conditions are rough and a steady readout can not be obtained.
- b) When sailing for an extended period at a constant speed.

Setting Distance Run

To set 12.3 n.m., for example, use the following procedure.

1. Push CLEAR button to reset display to 0.0 n.m.
2. Set left switch (DIGIT SELECTOR switch) to 1 (display begins to flash).
3. Set right switch (DISTANCE RUN SETTING switch) to 3, push SET button, and display should now read 0.3.
4. Set left switch to 2.




5. Set right switch to 2, push SET button, and display should now read 2.3.
6. Set left and right switch to 3 and 1, respectively. Then, press SET button, and 12.3 will be displayed.
7. Turn the left switch to 0 for normal use, and the display stops flickering. Setting is now complete.

DISTANCE INDICATOR

Clearing Distance Run


1. Press the SELECT button until all digits are flashing.
2. Press the SET button, and the distance run figure is reset to "0.0".
3. Press the SELECT button again for normal use, and the display stops flickering.



Amending Distance Run

ex. Amend 1123.5 to 1134.7

1. Press the SELECT button four times, and the tens digit will be flashing.
2. Press the SET button until the flashing figure changes to "3".
3. Ones digit will flash with the next pressing of the SELECT button.
4. Press the SET button until the figure changes to "4".
5. Next, pressing the SELECT button causes the one tenths to flash.
6. Press the SET button until the figure changes to "7".
7. Press the SELECT button two times to return to normal operation.



3. INSTALLATION

3.1 Mounting


MAIN DISPLAY

In deciding an installation site keep in mind the following factors.


- 1) Choose a place not vulnerable to rain, sea spray or other extreme weather conditions.
- 2) Select a site free from high temperatures and high humidity.
- 3) A place where vibration from other machinery is minimal.
- 4) Install the unit in a place where it will not become soiled easily.
- 5) Mount the unit distant from other electrical sources; esp., radio transceivers operating at 2MHz or harmonic frequencies of 2MHz.

Tabletop or Bulkhead Mount

1. Allowing maintenance space (according to the figure shown below), fix hanger with the four M6 bolts or wood screws. If necessary, stick the rubber cushion supplied as the installation materials onto both inner-sides of the hanger to escape the unit from severe vibration.



2. Attach rubber washers and knob washers to both sides of the unit, and loosely tighten the adjusting knobs.
3. Insert Main Display into hanger, and tighten both knobs.



When mounting the Main Display on the bulkhead, rotate the hanger 90 degrees as illustrated.




Fig.3-3

Flush mount

1. Cut out the planking by a dimension of 260mm wide by 172mm high.
2. Loosen four screws at both sides of the Main display and fix the hanger for flush mount type to the Main Display together with the cosmetic cover fixing plate as shown at right.
3. Put the Main display into the hole and fix it with four wood screws.
4. Fit the cosmetic cover onto the cosmetic cover fixing plate.





Fig.3-4

DIGITAL DISPLAY/DISTANCE INDICATOR

Select an installation site in the same manner as that of the Main Display;


- 1) Choose a place not vulnerable to rain, sea spray or other extreme weather conditions.
- 2) Select a site free from high temperatures and high humidity.
- 3) A place where vibration from other machinery is minimal.
- 4) Install the unit in a place where it will not become soiled easily.

These units can be installed on either a table top or flush mounted. Since the mounting method of these units are also the same as that of the Main Display except the dimensions, install them referring to the outline drawings on pages 6-10 thru 6-13 and the description on the installation method of the Main Display. Note that these units can not be mounted on the bulkhead, as the hanger will not rotate 90 degrees.




ANALOG DISPLAY

Since the Analog Display is a kind of current meter, it should be kept away from magnetic generating devices such as a transformer, generator, etc., so as to avoid erroneous ship's speed readings. Also choose a place free from sea spray, high temperature, high humidity and severe vibration. Either bulkhead or flush mount is available.



DIMMER

The Dimmer, which is designed to comply with the Japan Industrial Standards (JIS F8852), is used for externally controlling the illumination of the display of the Digital/Analog Displays. When the Dimmer is supplied locally, refer to the Interconnection Diagrams on pages 6-26 and 6-27 for the values of the resistors since they are different on the connecting Display (Digital or Analog) and power supply (100V or 220VAC).



DISTRIBUTION BOX

Since the Distribution Box is combined with several units such as the Main Display, Digital Indicator, Distance Indicator, etc., determine the installation site with the wirings to these units taken into account. Refer to the outline drawings on page 6-21 for the mounting dimensions.

JUNCTION BOX

Recommended installation site for the Junction Box is;

- 1) Although the unit is splashproof, do not install it in places of high humidity.
- 2) Keep it away from noise emitting electrical machinery.
- 3) Install in a place where maintenance and checking are optimal.
- 4) Avoid installing the box where strong vibrations occur.
- 5) Choose a place where the junction box will not become soiled easily.
- 6) Install in close proximity to the transducer. (Do not connect the transducer directly to the Main Display Unit without the Junction Box.)

The mounting plate should be well grounded to the ship's body. To prevent breakage of the inner core, do not bend the transducer cables at small angles (more than 300 mm).

TRANSDUCER

The performance of this equipment is directly related to the installation of the seachest; i.e., for the ship's speed sensor to operate properly the transmission signal should not be affected by either air bubbles or noise.

- 1) Separate as far as possible from other equipment and especially those operating at 2MHz or harmonic frequencies of 2MHz.
- 2) Locate the unit at least 2.5m from the transducer of an echo sounder. (This distance has been calculated using an echo sounder having a maximum sounding depth of 500m.) Also, to escape cavitation caused by unevenness of the hull plate, the doppler speed log's seachest should be mounted as below. Be especially careful not to install it on the same line as the echo sounder.




Fig.3-8

- 3) Separate as far as possible from air bubble sources; i.e., side thruster and water disposal pipes.
- 4) Install in close proximity to the keel line, because water flows parallel to the keel line; more accurate speed readings can be obtained.
- 5) Generally, best performance is obtained when mounting on the bow side; the stern side is influenced more easily by air bubbles and propeller cavitation.
- 6) Never apply ordinary paint to the transducer face. Whenever the ship is in dry dock, the transducer face should be kept clean by removing barnacle from the surface.

Mounting of Flush Type Seachest DS-784 (ref. Dwg. C7222-T06 on page 6-26)

1. Loosen lock nut **⑤** with a wrench (hex. size: 50mm) and take off cap nut **④** from transducer flange **③** together with gasket **⑥** and flat washer **⑦**. (It is not necessary to draw the cap nut completely out from the cable.)
2. Unscrew hex. socket head bolts **⑨** (M12 x 25, 4 pcs.) by using a socket screw wrench (size: 10mm). Separate hull flange **②** and transducer **①** from transducer flange **③**. Handle O-ring **⑧** carefully.
3. Weld hull flange **②** to the hull plate. Confirm that the "FORE" mark alignment line on the side of the hull flange faces the fore-aft line of the ship within ± 1 degree. The hull flange should also be horizontal within ± 1 degree at ship's normal trim.
4. Finish the outside hull plate with a grinder to ensure smooth water-flow.
5. Apply "Kinoruster (Anti-crevice corrosive sealant)" to face A of hull flange **②**, O-ring groove on the hull flange, O-ring **⑧** and face A of the transducer flange **③**.
6. Fit O-ring **⑧** onto the O-ring groove.
7. Place transducer **①** into hull flange **②** so that the alignment nipple on the transducer face fits into the notch on the hull flange.
8. Clean the hull flange face and settle transducer flange **③** on the hull flange.
9. Tighten hex. socket bolts **⑨** with a socket screw wrench.
10. Put gasket **⑥** and flat washer **⑦** on top of the transducer flange and tighten cap nut **④** securely with a wrench (hex. size: 50mm). Screw lock nut **⑤**.
11. When running the transducer cable inside the conduit pipe, screw the pipe end onto the cap nut (PS3/4) for watertightness.

NOTE A: NEVER REMOVE THE FOUR FLAT HEAD SCREWS WHICH SEAL SCREW HOLES, OTHERWISE WATERTIGHT INTEGRITY CANNOT BE PRESERVED.






Fig.3-9


Flush mount, projection type Seachest DS-783
(ref. Dwg. E7222-T03-A on page 6-24)

1. Loosen lock nut **⑤** with a wrench (hex. size: 50mm) and take off cap nut **④** from hull flange **③** together with gasket **⑥** and flat washer **⑦**. (It is not necessary to draw the cap nut completely out from the cable.)
2. Unscrew hex. socket head bolts **⑩** (M12 x 32, 4 pcs.) by using a socket screw wrench (size: 10mm). Separate flange **②** and transducer **①** from hull flange **③**. Handle O-ring **⑧** carefully.
3. Weld hull flange **③** to the hull plate. Confirm that the "FORE" mark alignment line on the side of the hull flange faces the fore-aft line of the ship within +1 degree. The hull flange should also be horizontal within +1 degree at ship's normal trim.
4. Finish the outside hull flange with a grinder to ensure smooth water-flow.
5. Apply "Kinoruster (Anti-crevice corrosive sealant)" to face A of hull flange **③**, O-ring groove on the hull flange, O-ring **⑧** and face A of the flange.
6. Fit O-ring **⑧** onto the O-ring groove.
7. Place transducer **①** into hull flange **③** so that the alignment nipple on the transducer face fits into the notch on the hull flange.
8. Clean the hull flange face and settle flange **②** on the hull flange.
9. Tighten hex. socket bolts **⑩** with a socket screw wrench.
10. Put gasket **⑥** and flat washer **⑦** on top of the transducer flange and tighten cap nut **④** securely with a wrench (hex. size: 50mm). Screw lock nut **⑤**.
11. When running the transducer cable inside the conduit pipe, screw the pipe end onto the cap nut (PS3/4) for watertightness.

NOTE A: NEVER REMOVE THE FOUR FLAT HEAD SCREWS WHICH SEAL SCREW HOLES, OTHERWISE WATERTIGHT INTEGRITY CANNOT BE PRESERVED.



Mounting of Projection type Seachest DS-781
(ref. Dwg. C7222-T05 on page 6-27)



1. Weld doubling plate (supplied by shipyard) to hull plate.
2. Remove the two M10 bolts, and take out transducer fixing flange ② (including transducer) from transducer housing ①.
3. Determine the projection distance, and cut transducer housing ①. The horizontal error should be within 1°.
4. Before beginning this step, remove the rubber gasket inside the thru-hull pipe ⑤ to prevent it from melting. After cutting a hole through the hull plate for thru-hull pipe (\varnothing 36), weld the thru-hull pipe to the hull plate.
5. Weld transducer housing ① to doubling plate. Direction error from fore-aft line should be within 1°. At stern side of transducer housing, make air exhaust holes (\varnothing 10-20).
6. Through the thru-hull pipe ⑤, pull up the transducer cable into the ship. Be careful not to jam the cable between the flange and housing. Next, using the two M10 x 30 bolts("Kinoruster" applied), fasten the transducer fixing flange to the transducer housing.

NOTE: ALSO IN THE TYPE, NEVER REMOVE THE FOUR FLAT HEAD SCREWS.

Mounting of Gate Valve Type Seachest DS-786
(ref. Dwg. E7222-T04 on page 6-28)





Fig.3-11

1. Separate hull flange ② and flange ④ (with transducer ① and shaft ⑤) from gate valve ⑩ by removing hex. nut ⑩.
2. Weld hull flange ② to the hull plate. Confirm that the "FORE" and align marks on the side of the hull flange face the fore-aft line of the ship within +1 degree. The hull flange should also be horizontal within +1 degree at ship's normal trim. Finish the outside hull plate flat with a grinder.
3. Apply "Kinoruster (Anti-crevice corrosive sealant)" to face A of hull flange ②, both faces of gasket ⑯ and flange of gate valve ⑩.
4. Put gasket ⑯ onto hull flange ②.
5. Mount gate valve ⑩, considering the direction of the handle (aft direction normally) so as to allow enough space for operation.
6. Apply "Kinoruster" to face B of flange ④, both faces of gasket ⑯ and the flange of gate valve ⑩.
7. Put gasket ⑯ onto the flange of gate valve ⑩ .
8. Mount flange ④ (with transducer and shaft) to gate valve ⑩ . Make sure the fore marks on flange ④ and hull flange ② are aligned.
9. Loosen the hex. socket head bolt, then check that shaft ⑤ moves upward and downward smoothly by hand.
10. Lower shaft ⑤ at its extreme and fasten hex. socket bolt ⑬ .

11. Confirm that the hull plate is flush with the transducer face.


Note: Neither weld the hull flange or transducer tank when the transducer is being fitted, nor weld near the transducer or other equipment.

When the transducer ① is replaced, or separated from the shaft ⑤, re-assemble as follows;



1. Remove sealant from face C and/or face D.
 2. Apply adhesive #1104 (Three Bond) to face D and four fixing screw.
 3. Re-assemble them.

Gate valve, projection type Transducer DS-782
(ref. Dwg. E7222-T02-A on page 6-25)



1. Separate hull flange ③ and flange ④ (with transducer ① and shaft ⑤) from gate valve ② by removing hex. nut ⑯.
2. Weld hull flange ③ to the hull plate. Confirm that the "FORE" and align marks on the side of the hull flange face the fore-aft line of the ship within +1 degree. The hull flange should also be horizontal within +1 degree at ship's normal trim. Finish the outside hull plate flat with a grinder.
3. Apply "Kinoruster (Anti-crevice corrosive sealant)" to face A of hull flange ③, both faces of gasket ⑯ and flange of gate valve ②.
4. Put gasket ⑯ onto hull flange ③.
5. Mount gate valve ②, considering the direction of the handle (aft direction normally or selectable every 45 degrees) so as to allow enough space for operation.
6. Apply "Kinoruster" to face B of flange ④, both faces of gasket ⑯ and the flange of gate valve ②.
7. Put gasket ⑯ onto the flange of gate valve ②.
8. Mount flange ④ (with transducer and shaft) to gate valve ②.
9. Loosen the hex. socket head bolts ⑯ & ⑯, then check that shaft ⑤ moves upward and downward smoothly by hand.
10. Lower shaft ⑤ at its extreme and fasten hex. socket bolt ⑯ and ⑯.
11. Lower the transducer by turning the handle until the transducer case ⑥ touches the hull flange ③.
12. Confirm that the hull plate is projected by 24mm.

Note: Neither weld the hull flange or transducer tank when the transducer is being fitted, nor weld near the transducer of other equipment.

3.2 Wiring

Take the following points into account when planning the cable path.

Transducer Cable

- * Run the cable as short as possible to minimize the affect of interference and noise from other equipments. Run the cable inside the conduit pipe to avoid such noise induction.
- * For perfect grounding, do not damage or cut the armor. The armor should be firmly grounded thru the cable gland of the Junction Box.

Other Cables


- * Do not run the cable along other noise generating devices or cables such as Radar, Radio transmitter, Winch cables, etc.

CAUTION


Ground the armor with a cable clamp after scraping off the paint, otherwise, unexpected noise may be induced into the cable, resulting in malfunction of the equipment.

Piping


The transducer cable should be layed in piping (steel, etc.) extending from the transducer to the Junction Box to shield the cable from external noise. The transducer cable has an outer braided shield, however the composite 4-core cable is superior in keeping out external noise. For this reason, make the length of the transducer cable as short as possible, and use the composite 4-core cable to make the connection from the Junction Box to the Main Display. If the path from the transducer to the Junction Box is electrically isolated by a steel bulkhead, piping is unnecessary.




MAIN DISPLAY



Cable No.	Name	To	Terminal No.	Dwg. No.
1	DPYC-1.25	Ship's Mains	TB1 1 - 2	a
2	DPYC-1.25	Log Signal	TB3 1 - 2	b
		Alarm Signal	TB3 8 - 9	c
3	TTYC-2S	Distance Indicator	TB3 3 - 7	d
4	TTYC-3S	Digital Display	TB2 1 - 7	e
4	TTYC-4S	Distribution Box	TB2 1 - 4, TB3 3 - 7	f
5	65S1034-1	Junction Box	TB4 1 - 7, 10	g





JUNCTION BOX




Fig.3-13

Cable No.	Name	To	Terminal No	Dwg. No.
1	65S1034-1	Main Display	TB1 1 - 8	h
2	65S1046	Transducer	TB1 1 - 8	i

h Composite 4-core Cable

This diagram shows the assembly of a composite 4-core cable. It starts with a 150mm long cable segment. A 22mm section is stripped back, followed by a 40mm section with a white stripe. A tinning wire is attached to the 70mm section. The coaxial cables are then stripped back 40mm, 22mm, and 22mm respectively. The entire assembly is insulated with a vinyl tube and then secured with tape.


i Transducer Cable

This diagram shows the assembly of a transducer cable. It consists of two coaxial cables (no mark and white stripe) and a 2C cable. The coaxial cables are stripped back 40mm, 22mm, and 22mm. The 2C cable is stripped back 140mm. Both are insulated with vinyl tubes and secured with tape. A note indicates to "Insulate with vinyl tube."


DIGITAL DISPLAY/DISTANCE INDICATOR

A special terminal board is used in the Digital Display, Distance Indicator and Distribution Box. The following describes how to connect a wire to the terminal.

1. Strip the vinyl sheath of the wire to expose the core by 5mm thru 6mm.



2. Hook the wire inserting tool (supplied as installation materials, type: 236-332) into the terminal board as shown in Fig.3-15(a) and press it in direction A (opposite to the wire inserting side) to lower the spring. With the wire inserted into the slit, release the tool from the terminal. Pull the wire to make sure that the wire does not come off the terminal.



3. If the wire inserting tool is not available, insert a small screwdriver (-) into hole C and press it upward as shown in Fig.3-15(b).





Fig.3-16

Cable No.	Name	To	Terminal No.	Dwg. No.
1	TTYC-3S *1	Main Display	TB1 1 - 6	j
	TTYC-2S *2 (or Distribution Box)		TB1 3 - 6	
2	TTYC-1.25	Dimmer	TB1 7 - 9	k

*1 : Digital Display *2 : Distance Indicator



DISTRIBUTION BOX




Fig.3-17

Cable No.	Name	To	Terminal No.	Dwg. No.
1	DPYC-1.25	Ship's Mains	TB7 1 - 2	1
2	TTYC-4S	Main Display	TB1 1 - 12	m
3	TTYC-3S	Digital Display	TB2/TB3 1 - 9	n
4	DPYC-1.25	Log Signal	TB4 1 - 12	o
5	TTYC-2S	Distance Indicator	TB5 1 - 12	p
6	TTYCS-1	Analog Display	TB6 1 - 3 , 7 - 9	q
7	DPYC-1.25	Fore-Aft Relay Signal	TB6 4 - 5 , 10 - 11	r

1

m

190

1 2 3 4

Fabricate cable end with the pair twisted for noise reduction.


20

Strip the vinyl sheath by 5 thru 6 mm.

Solder earth wire to shield

5~6mm

Taping




3.3 After Installation Check and Adjustment

ALTERATION OF POWER SUPPLY

The equipment can be operated from any one of 100, 110, 115, 200 and 220 VAC (Transistor Inverter TR-2407/3207 is available for DC power supply). If the ship's mains is different from the power supply labeled on the equipment, change the tap connection of the power transformer in the Main Display and Distribution Box (if provided) as shown below.

- Main Display -

1. Separate the rear panel from the Main Display by loosening four screws (M3 x 6). Be careful not to swing the rear panel upward or downward when removing the panel, because it is directly plugged into the pc boards.
2. Unplug the ML connectors (J33 and P33) located at the bottom corner of the Main Display, then change the connection of the red wire coming from the POWER switch to an appropriate pin number as illustrated.



How to extract the contact pin

Insert the pin extractor(LEJ-13) into the pin hole from the side opposite to the wire inserting side. Pull the wire, and the contact pin can be removed.




Fig.3-19

Distribution Box

Change the tap connection of the power transformer inside the Distribution Box to an appropriate power supply.






Fig.3-20



ADJUSTMENT OF RESPONSE TIME/CORRECTION OF SPEED INDICATION

As the equipment is fully tested and adjusted at the factory, no further adjustment is required in the field after installation. If desired, however, the following items can be readjusted locally on user's demand.

Open the inner panel cover and the five preset potentiometers are located at the top of the inner panel as illustrated.

Potentiometer A is for adjusting the response time and B, for correcting speed indication. Other potentiometers are for factory adjustment only and thus should not be touched in the field.




Fig.3-21

Response Time

The response time in the "SLOW" position can be continuously changed with potentiometer A; the response time is three times the speed of "FAST" position at the counter-clockwise point (factory set) and is the same as the "FAST" position at the fully clockwise point.




Fig.3-22

Correction of speed indication

If an erroneous speed is indicated during the speed test (mile post test), it can be corrected by $\pm 10\%$ of the present indication by adjusting potentiometer B.




Fig.3-23

4. POST INSTALLATION TEST

4.1 Self-test of Main Display

To check the performance of the unit, a built-in test circuit is available. Through the procedure below, the following checks can be made.

CHECK ITEM	TEST SWITCH	
	"SIG"	"0 KNOTS"
Ship's Speed Reading	The reading should gradually reach 24 thru 30 knots if the equipment is operating normally.	Ship's speed should read 0.0 or + 0.1 knots.
Distance Run Reading	Use the following equation to confirm the calculating time required for the increment of the distance run reading by 0.3 n.m. $\frac{1080}{\text{ship's speed reading}} \text{ sec.}$ taken from the above check item ex. If the ship's speed reading is 27.0 knots, the time is; $\frac{1080}{27.0} = 40 \text{ sec.}$	Distance run cannot be incremented.
Log Signal Output Check using a Multimeter	On the rear panel, connect a multimeter to TB3 (1 and 2), and measure the pulse count (*).	There should be no signal output.


(*) This relay contact signal is equivalent to 200 pulses/n.m. Therefore, 60 pulse are equal to 0.3 n.m.

NOTE

Just after changing the dummy signal switch from either SIG to 0 or 0 to SIG (with test switch in TEST position), it takes a while for the ship's speed reading to reach the value of the particular test setting.

4.2 Self-test of Distance Indicator

Remove the top cover of the Distance Indicator and the TEST switch is located on the DSP board (65P3010) as shown below.



Distance Indication check

When the TEST switch is set to "TEST" position, the distance run figure increments by 5.0 miles every 10 seconds.

Figure check

After presetting the distance run figure to 99995.0 with the SELECT and SET button, set the TEST switch to "TEST". If the indication changes to 0.0 in 5 seconds, the unit operates normally.

4.3 Noise Test

After completing the installation, make sure the DS-70 is not picking up noise by following in order the test procedure below.

1. Stop the ship where the distance between the hull bottom and seabed is greater than 3m. Turn off the power to radio equipment, fish finding gear (such as echo sounder, sonar, etc.) and all other electronic equipment.
2. Apply the power to the DS-70, and perform the self-check with the test switch and dummy signal switch inside the inner panel. Set the test switch and dummy signal switch to "TEST" and "SIG" positions, respectively. If the display shows 24 to 30 kts within 30 seconds, return the test switch to the normal position. Approximately 0 kts will be displayed within a few minutes if the unit is operating normally.
3. Make sure the abnormal echo lamp is not blinking excessively. (If the lamp blinks within 1 and 2 times every five seconds, the equipment is operating normally.) Also, confirm that no decimal point is blinking.
4. Turn on one by one the equipment turned off in step 1, and observe the abnormal echo lamp. If the lamp blinks excessively when the power is applied to a piece of equipment, then noise is being picked up from that equipment. Check the installation method of the offending equipment. Likewise, check the ground of noise generating equipment.
5. Run the ship at both cruising and maximum speeds and confirm that the abnormal echo lamp does not blink excessively in either case.

NOTE

Propeller shaft noise may be picked up through the cables of the DS-70. This type of noise (from the brushes, etc.) may be reduced by grounding the shaft to the ship's body.

4.4 Sea Test Procedure

1. Purpose

To ensure the accuracy of the DS-70, the following test should be carried out at sea, during anchoring and cruising of the vessel.

2. Testing Method

Static Data

With the vessel stationary in the dock, read the speed indication of the DS-70 every 10 seconds. The average value and the deviation of indication should be examined.

Speed Test

While running on the mile post, or measuring the vessel's speed by a radio log, record the indication of the DS-70 every 10 seconds. The resultant average value should then be compared with the data obtained by running on the mile posts or by the radio log. The accuracy of the doppler speed log is found out by measuring the time elapsed over one mile of the distance meter.

In practice, the vessel's speed is evaluated as follows.



The data taken by speed test should be recorded on page 4-7 of the TEST SHEET.

1. Measurement of vessel's speed by means of the mile post.

Run the vessel at a constant speed along the test course given by mile posts (P₁/P_{1'} and P₂/P_{2'}) and measure the time (TOG: unit in seconds) elapsed between points (A) and (B). The vessel's speed is obtained from the following equation.

$$\text{Vessel's speed (VMP)} = \frac{1}{\text{TOG}} \times \frac{3600}{1852} \times \frac{d \times \cos\theta}{1} [\text{KTS}] \cdots 1$$

Where d is the distance between points (A) and (B), and θ , drifting angle.

2. Measurement of vessel's speed by using the distance run indication of the DS-70.

While performing the test in step 1, measure the exact time (T/mile) elapsed over a one-mile counting of the distance run indication.

3. Obtain the average value of VMP and VDS in going and returning over the test course.


$$VMP' = \frac{VMP(\text{going}) + VMP(\text{returning})}{2} \quad \dots \dots \dots \quad 1$$

Therefore, the measurement error of the DS-70 is given as follows.

$$\Delta V = \frac{V_{DS'} - V_{MP'}}{V_{MP'}} \times 100\%$$

4. The error ΔV can be corrected with potentiometer F Adj., accessible through the clearance above the top of the inner panel as illustrated.

In order to perform the correction precisely, adjust the F Adj. potentiometer by using the built-in test signal as follows.



- a. Set the TEST and DUMMY SIGNAL switches to TEST and SIG, respectively.
 - b. Wait for a while until the speed indication becomes stable (27 \pm 3 knots).
 - c. Adjust the potentiometer so that the ship's speed reading shows the value given by the following equation.

$$\text{Ship's speed reading} = \frac{\text{VSIG}}{1 + \frac{\Delta V}{100}}$$

Where VSIG is the speed reading by the test signal before adjusting the potentiometer.

Ref: The scale around the potentiometer is graduated in about 2% increments and can be calibrated by $\pm 10\%$ of the present indication.


Ex.

If the ΔV and VSIG is 2% and 27.0 knots, respectively:

$$V_{ADJ} = \frac{27.0}{1 + \frac{2}{100}}$$

≈ 26.5 knots.

Therefore, adjust the potentiometer for a ship's speed reading of 26.5 knots.



5. OPERATING PRECAUTIONS AND REMARKS ON DOCKING THE SHIP

5.1 Abnormal Indication in a Specific Area

The DS-70 measures ship's speed by detecting the doppler shift frequency of the return echo which is reflected by plankton or other micro organisms between 2 and 3m deep. There are rare occurrences, however, that no signal is received due to a lack of the plankton. It was reported that this phenomenon was observed in the Ohotsku Sea during the spring season. The probable reason is that the plankton are lying in deep water because the ice-melted cold water mass covers over the sea surface. Similar cases have also been seen in a fresh water lake. Under such circumstances, the DS-70 will not indicate the correct ship's speed even if the equipment works normally.

5.2 Countermeasure to protect Transducer from being damaged by Dry Dock Blocks

The transducer may be damaged if the transducer touches the block at grounding. Take the following countermeasure to prevent this from occurring.

1. Before delivery, draw up a docking plan referring to the dimensions and location of the transducer. The plan should be kept onboard ship.
2. Plan the placing of the blocks referring to the above plan.
3. Prior to pumping out the water, have a diver check the position between the transducer and the blocks. Confirm that the transducer will not touch the blocks.

Consult with the dockyard personnel over items 2 and 3 above before dry docking.

6. SPECIFICATIONS

GENERAL

1. Speed Range: -10.0 to 30.0 knots
2. Tracking Mode: Water tracking
3. Depth Range: Over 3 m
4. Accuracy: $\pm 1\%$ or ± 0.1 kt
(excluding effect of tide current)
5. Transmission Frequency: 2MHz (Pair-beam system)
6. Ambient Conditions:
Temperature: -15 to 55°C
Relative humidity: 80% (at 45°C)
7. Power Supply/Consumption:
100/110/115/200/220/230 VAC, 1 ϕ , 50/60 Hz
Max. 25VA (except optional units)

MAIN DISPLAY UNIT: DS-700

1. Indication
 - Ship's speed-
Fore:

--	--	--

 knot
Aft : -

--	--	--

 knot
 - Distance run-

--	--	--	--	--	--

.

--

 n. mile
2. Output Signal
 - 1) Digital speed signal
(TTL level: one output)
 - 2) Log signal of 200 pulses/n.m., forward data only
(Relay contact: one output, Contact capacity: 30V max./0.5A max.)
 - 3) Log signal of 400 pulses/n.m., forward data only
(TTL Level: one output)
3. Others
 - 1) Illumination of green EL board and dimmer
 - 2) Manual set of each digit and reset of all digits for distance run
 - 3) Function checks by internal reference signal

DIGITAL DISPLAY: DS-720

- | | |
|----------------------|--|
| 1. Indication | Fore: <input type="checkbox"/> <input type="checkbox"/> . <input type="checkbox"/> knot,
Aft : <input type="checkbox"/> <input type="checkbox"/> . <input type="checkbox"/> knot
(LCD display with dimmer) |
| 2. Power Consumption | 2.5VA approx. |

ANALOG DISPLAY: DS-761/762/763/771/772/773

- | | |
|----------------------|--|
| 1. Indication | -10 to 30 knot (for DS-761/762/763)
-10 to 20 knot (for DS-771/772/773) |
| 2. Power Consumption | 2.5VA approx. |
| 3. Others | Illumination of orange EL board
(except DS-763/773)

External Dimmer Box (JIS F8852 or
equivalent) can be connected. |

DISTANCE INDICATOR: DS-730

- | | |
|----------------------|---|
| 1. Indication | <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> . <input type="checkbox"/> n. mile
. LCD display with dimmer
. Manual set of each digit and reset of
all digits |
| 2. Accuracy | ± 1% or ± 0.1 kt |
| 3. Power Consumption | 2.5VA approx. |
| 4. Others | 1) Function Checks
2) Keep - alive battery to preserve the
distance run figure |

DISTRIBUTION BOX: DS-740

- | | |
|------------------|---|
| 1. Output Signal | 1) Ship's speed for Digital Display
(TTL level: two outputs)

2) Analog ship's speed signals |
|------------------|---|

output i

- * for Analog Display
- * analog current signal
(-10 to 30 knots: 4 to 20mA)
- * analog current signal
(-10 to 30 knots: -3.3 to 10V)

output ii

- * for Analog Display
- * analog current signal
(-10 to 30 knots: -3.3 to 10V)

3) Log signal of 400 pulse/n. miles, forward data only
(TTL level: 2 outputs)

4) Log signal of 200 pulse/n. miles, forward data only
(Relay contact: six output, Contact capacity: 30V/0.5A)

2. Power Consumption

Max. 50VA,

INTERFACE UNIT : DS-741

- (1) Input Port
- (2) Output Port
- (3) I/O Sentences

Input

1 port

2 ports

Output (IEC61162-1)

Serial digital data(current loop)

VDVBW.water speed

\$VDVBW, x. x. x. x. A, x. x. x. x. A<CR><LF>

Status: Ground speed, A= Data valid, V= Data invalid

Transverse ground speed, knots

Longitudinal ground speed, knots

Status: Water speed, A= Data valid, V= Data Invalid

Transverse water speed, knots

Longitudinal water speed, knots

Formatter

Talker, "VD"

Note 1: Longitudinal speed: “-” = astern

Note 2: Transverse/longitudinal ground speed and transverse water speed signals are Null.

- (4) Power Supply

8-18/18-42 VDC, unstabilized. 0.2 A max.

Value is selected by changing receptacle on internal board.

EQUIPMENT LIST (STANDARD)

No.	Name	Type	Wgt.(kg)	Q'ty	Remarks
1	Main Display	DS-700	6 6.2	1	Flush mount Table/Bulkhead mount
2	Transducer	DS-785-10	2.5		w/10m cable
		DS-785-20	4.8	1	w/20m cable
		DS-785-30	7		w/30m cable
3	Seachest	DS-781	11		Projection
		DS-782	75	1	Gate Valve type P
		DS-783	5.6		Flush type P
		DS-784	9.5		Flush
		DS-786	44		Gate Valve type F
4	Junction Box	DS-750	2.6	1	
5	Installation Materials			1 set	
6	Accessories			1 set	
7	Spare Parts			1 set	
8	Interface Unit	DS-741	0.8	1	for SOLAS type ship only

EQUIPMENT LIST (OPTION)

No.	Name	Type	Wgt.(kg)	Remarks
1	Digital Display	DS-720	1.6	Flush/Table mount
2	Analog Display *	DS-761/771	6	Flush mount
		DS-762/772	6	Bulkhead mount
		DS-763/773	1.3	Flush(small) mount
3	Distance Indicator	DS-730	1.7	Flush/Table mount
4	Dimmer	MF-22L-1	1.2	Flush mount
		MF-22L-2	1.3	Bulkhead mount
5	Distribution Box	DS-740		
6	Junction Box	DS-750	1.3	
7	Accessories			
8	Installation Materials			
9	Spare Parts			

* Meter scales are different between DS-76X series and DS-77X series as follows.

DS-761/762/763 : -10 to 30 knot

DS-771/772/773 : -10 to 20 knot

ACCESSORIES

No.	Name	Type	Code No.	Q'ty	Remarks
1	Knob Bolt	KG-B2 M8x20	000-861-934	2	
2	Rubber Washer	02-019-0003	201-900-031	2	
3	Knob Washer	02-043-1112	204-311-120	2	
4	Hanger	02-043-1501	204-315-011	1	
5	Cosmetic Cover Fixing Plate	65-003-0141	100-022-940	2	For DS-700 (Table top/Wall mount)
6	Hanger	65-003-0142	100-022-950	2	
7	Cosmetic Cover	65-003-0143	100-022-960	2	For DS-700 (Flush mount)

8	Hanger	65-003-0318-0	100-033-670	2	For DS-720/730 (Flush mount)
9	Cosmetic Cover Fixing Plate	65-003-0319-0	100-033-680	2	
10	Cosmetic Cover	65-003-0321-0	100-033-690	2	
11	Slotted Hex. Bolt	M6 x 25 SUS304	000-862-133	4	
12	Hex. Nut	M6 SUS304	000-863-109	4	
13	Spring Washer	M6 SUS304	000-864-260	4	For DS-720/730 (Table mount)
14	Hanger	01-011-1015	006-261-890	1	
15	Knob Bolt	KG-B2 M8x15	000-861-937	2	
16	Fiber Washer	M8 FIBER	000-864-936	2	

INSTALLATION MATERIALS


No.	Name	Type	Code No.	Q'ty	Remarks
1	Copper Strap	WEA-1004	500-310-040	1	For DS-700
2	Crimp-on Lug	FV1.25-3 Red	000-538-113	35	
3	Rubber Cushion	65-003-0211-0	100-044-380	2	
4	Copper Strap	WEA-1004-0	500-310-040	1	For DS-720/730
5	Crimp-on Lug	FV2-S3.3	000-538-117	6	
6	Hook Spanner	236-332	000-104-345	1	
7	Crimp-on Lug	FV2-S3.3	000-538-117	5	For DS-76X/77X *
8	Copper Strap	WEA-1004-0	500-310-040	1	For DS-740
9	Crimp-on Lug	FV1.25-3 Red	000-538-113	3	
10	Hook Spanner	236-332	000-104-345	1	
11	Crimp-on Lug	FVD2-4 Blue	000-104-950	10	For DS-750
12	Crimp-on Lug	FVD2-MS3 Blue	000-104-951	10	
13	Crimp-on Lug	V1.25-4 Red	000-538-102	10	
14	Compound 4C Cable	65S1034	000-104-949	□ m	For Transducer seachest
15	Kinoruster (Anti-crevice corrosion sealant)	855 50g	000-801-328	1	

* DS-761/762/763 , DS-771/772/773

SPARE PARTS

No.	Name	Type	Code No.	Q'ty	Remarks
1	Glass Tube Fuse	FGBO 1A AC250V	000-549-019	4	For DS-700
2	Glass Tube Fuse	FGBO 2A AC125V	000-549-062	2	
3	Glass Tube Fuse	FGBO 0.5A AC125V	000-549-060	3	For DS-720/730 *1 For DS-740 *2 For DS-740
4	Glass Tube Fuse	FGBO 0.5A AC250V	000-549-018	3	
		FGBO-A 1A AC125V	000-549-061	3	

*1: For 200 to 220VAC, *2: For 100 to 115VAC



NOTE

DS-70 DOPPLER SPEED LOG

* : SHIPYARD SUPPLY

: CONNECTOR (: FACTORY-FITTED)

: CRIMP-ON LUG (: FACTORY-FITTED)

: GROUNDING COPPER STRAP

: GROUNDING WIRE IV-8sq.

: CABLE SUPPLY SIDE


-- : OPTIONAL SUPPLY

<NOTE 1> :

WHEN CABLE LENGTH IS EXTENDED MORE THAN 120m, USE TWO JUNCTION BOXES INSTEAD OF DS-750.

IF SO, MAXIMUM CABLE LENGTH BETWEEN DS-700 AND TRANSDUCER IS 400m.
(NOTE THAT CABLE LENGTH OF 65S1034-1 SHOULD BE 30m AT MAXIMUM.)

DRAWN <i>Dec 15 '98 T.YAMASAKI</i>	TYPE DS-70
CHECKED <i>Dec 16 '98 K.Kusnicki</i>	NAME DOPPLER SPEED LOG
APPROVED <i>Dec 16 '98 K.Kusnicki</i>	SYSTEM DIAGRAM
DWG. No. E7222D02F000	REMARKS CONNECTION W/ DS-720/730




NOTE

DS-70 DOPPLER SPEED LOG

<NOTE 1>:
WHEN CABLE LENGTH IS EXTENDED MORE THAN 120m, USE TWO JUNCTION BOXES INSTEAD OF DS-750.
IF SO, MAXIMUM CABLE LENGTH BETWEEN DS-700 AND TRANSDUCER IS 400m.
(NOTE THAT CABLE LENGTH OF 65S1034-1 SHOULD BE 30m AT MAXIMUM.)

DRAWN <i>Dec 15 '98 T. YAMASAKI</i>	TYPE DS-70
CHECKED <i>Dec 16 '98 K. Kurumochi</i>	NAME DOPPLER SPEED LOG
APPROVED <i>Dec 16 '98 K. Kurumochi</i>	SYSTEM DIAGRAM
DWG. No E7222D01F000	REMARKS



NOTE

DS-70 DOPPLER SPEED LOG

* : SHIPYARD SUPPLY

: CONNECTOR (: FACTORY-FITTED)

: CRIMP-ON LUG (: FACTORY-FITTED)

: GROUNDING COPPER STRAP

: GROUNDING WIRE IV-8sq.

: CABLE SUPPLY SIDE

-- : OPTIONAL SUPPLY

<NOTE 1> :


WHEN CABLE LENGTH IS EXTENDED MORE THAN 120m, USE TWO JUNCTION BOXES INSTEAD OF DS-750.

IF SO, MAXIMUM CABLE LENGTH BETWEEN DS-700 AND TRANSDUCER IS 400m.


(NOTE THAT CABLE LENGTH OF 65S1034-1 SHOULD BE 30m AT MAXIMUM.)

DRAWN Oct 8'98 K.Kusunoki		TYPE DS-70
CHECKED Oct 9'98 T.YAMASAKI		NAME DOPPLER SPEED LOG
APPROVED Oct 8'98 K.Kusunoki		REMARKS
DWG. No. E7222D03A000		SYSTEM DIAGRAM


A



B



C



D

COMPASS SAFE DISTANCE


(DOT: UK)

STANDARD..... 1.5m

STEERING..... 0.9m

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG.NO.	摘要 REMARKS
承認 APPROVED	JUL. 11. 85 <i>[Signature]</i>	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE	DS-700 主指示器(卓上/壁掛型) MAIN DISPLAY(TABLE TOP/WALL MOUNT)	
検査 CHECKED	JUL. 10. 85 <i>[Signature]</i>	尺 度 SCALE	1/4		
製図 DRAWN	JUL. 8. 85 <i>[Signature]</i>	重 量 WEIGHT	6.2 kg	図番 DWG.NO.	C7222-005-C

* 推奨サービス空間
RECOMMENDED SERVICE CLEARANCE.



COMPASS SAFE DISTANCE


(DOT: UK)

STANDARD..... 1.5m

STEERING..... 0.9m

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE	DS-700		
検 図 CHECKED	尺 度 SCALE	1 / 4	主指示器 (埋込型) MAIN DISPLAY (FLUSH MOUNT)		
製 図 DRAWN	重 量 WEIGHT	6 kg	DWG. NO.	C7222-012-B	

※ 推奨サービス空間
RECOMMENDED SERVICE
CLEARANCE.



D

COMPASS SAFE DISTANCE

(DOT: UK)

STANDARD..... 1.0m


STEERING..... 0.6m

注：指定なき公差は15%


TOLERANCE IS 15% UNLESS OTHERWISE SPECIFIED.

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	AUG. 7 '85 <i>[Signature]</i>	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE	DS-730 航 程 計 (卓 上 型)	
検査 CHECKED	AUG. 7 '85 <i>[Signature]</i>	尺 度 SCALE	1 3	DISTANCE INDICATOR (TABLE TOP MOUNT)	
製図 DRAWN	AUG. 7 '85 <i>[Signature]</i>	質量 MASS	1.7 kg	DWG. NO. C7222-016-C	


※ 推奨サービス空間
RECOMMENDED SERVICE CLEARANCE.



取付寸法図
MOUNTING DIMENSIONS



B



C


COMPASS SAFE DISTANCE
(DOT: UK)
STANDARD..... 1.0m
STEERING..... 0.6m

注：指定なき公差は15%
TOLERANCE IS 1.5% UNLESS OTHERWISE SPECIFIED.


品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q.TY	図番 DWG.NO.	摘要 REMARKS
承認 APPROVED	第三角法 THIRD ANGLE PROJECTION	名称 TITLE	DS-730		
検査 CHECKED	尺度 SCALE	1/3			航程計(埋込型) DISTANCE INDICATOR (FLUSH MOUNT)
製図 DRAWN	質量 MASS	1.7 kg	図番 DWG.NO.	C 7222 - 015 - C	

※ 推奨サービス空間
RECOMMENDED SERVICE CLEARANCE.

A



B



C

D

COMPASS SAFE DISTANCE


(DOT: UK)

STANDARD..... 1.0m


STEERING..... 0.6m

ITEM	品番	品名	材質	数量	図番	摘要
APPROVED	AUG. 7 '85	三 角 法 THIRD ANGLE PROJECTION	名称	DS-720	DWG. NO.	REMARKS
CHECKED	AUG. 7 '85	尺 度 SCALE	1 / 3			デジタル指示器(卓上型) DIGITAL DISPLAY (TABLE TOP MOUNT)
DRAWN	AUG. 7 '85	重 量 WEIGHT	1.6 kg	図番 DWG. NO.	C 7222-013-B	


※ 推奨サービス空間
RECOMMENDED SERVICE CLEARANCE.





取付寸法図
MOUNTING DIMENSIONS



B



C



D

COMPASS SAFE DISTANCE


(DOT: UK)

STANDARD..... 1.0m


STEERING..... 0.6m

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE	DS-720		
検査 CHECKED	尺 度 SCALE		1 / 3		デジタル指示器 (埋込型) DIGITAL DISPLAY (FLUSH MOUNT)
製図 DRAWN	重 量 WEIGHT		1.6 kg	図番 DWG. NO.	C 7222-014-B

A




B




D

取付寸法図
MOUNTING DIMENSION


ケーブル導入口(コーミング)
Φ19 CABLE ENTRY(COAMING)




	品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	SEP. 17. 85 <i>[Signature]</i>	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE			DS-761 アナログ指示器(埋込型) ANALOG DISPLAY (FLUSH MOUNT)
検査 CHECKED	Sep. 17. 85 <i>[Signature]</i>	尺 度 SCALE	1/3			
製図 DRAWN	SEP. 17. 85 <i>[Signature]</i>	重 量 WEIGHT	6.0 kg	図番 DWG. NO.	C 7222 - 024 - A	



A




B



C

指示範囲	DS-763	-10 ~ 30 ノット KNOT
RANGE	DS-773	-10 ~ 20 ノット KNOT




取付寸法図
MOUNTING DIMENSION ($S = \frac{1}{4}$)

D


DS-70

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
------------	------------	----------------	------------	----------------	---------------



承認 APPROVED	SEP. 17. 85 <i>[Signature]</i>	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE	DS-763/773 アナログ指示器 ANALOG DISPLAY	
検査 CHECKED	Sep. 17. 85 <i>[Signature]</i>	尺 度 SCALE	1/2		
製図 DRAWN	SEP. 17. 85 <i>[Signature]</i>	重 量 WEIGHT	1.3 kg	図番 DWG. NO.	C7222-021-B




A



B




C





D


取付寸法図
FIXING DIMENSION

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	SEP. 17. '85 <i>[Signature]</i>	三 角 法 THIRD ANGLE PROJECTION	名称 TITLE	DS-772 アナログ指示器(壁掛型) ANALOG DISPLAY (BULKHEAD MOUNT)	
検査 CHECKED	SEP. 17. '85 <i>[Signature]</i>	尺 度 SCALE	1 / 3		
製図 DRAWN	SEP. 17. '85 <i>[Signature]</i>	重 量 WEIGHT	6.0 kg	図番 DWG. NO.	C 7 2 2 2 - 0 2 2 - A











(DS-70)	品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q/TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	Mar. 3 '87 T. YAKAI	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE			接 続 箱
検 図 CHECKED	Mar. 3 '87 M. IKEDA	尺 度 SCALE	1 2		DS-750 JUNCTION BOX	
製 図 DRAWN	Feb. 26 '87 H. MORI	重 量 WEIGHT	2.6 kg	図番 DWG. NO.	C 7 2 2 2 - 0 5 7 - A	






品番 ITEM	品 名 NAME		材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	APR.26.'91 T. TANAKA	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE			送受波器 TRANSDUCER
検 図 CHECKED	APR.26.'91 M. IKEDA	尺 度 SCALE	1 / 2		DS-785	
製 図 DRAWN	APR.26.'91 C. TANAKA	重 量 WEIGHT	2.5 kg w/10m CABLE	図番 DWG. NO.	C7222-G02-A	

Mounting Procedure


- 1 Loosen lock nut ⑤ with a wrench (hex. size: 50mm) and take off cap nut ④ from hull flange ③ together with gasket ⑥ and flat washer ⑦. (It is not necessary to draw the cap nut completely out from the cable.)
- 2 Unscrew hex. socket head bolts ⑩ (M12 x 32, 4 pcs.) by using a socket screw wrench (size: 10mm). Separate flange ② and transducer ① from hull flange ③. Handle O-ring ⑧ carefully so as not to damage it.
- 3 Weld hull flange ③ to the hull plate. Confirm that the "FORE" mark is orientated to fore and alignment lines on the side of hull flange are in parallel with the fore-aft line of the ship within 1 degree. The hull flange ③ should also be horizontal within 1 degree at ship's normal trim.
- 4 Finish the outside of hull flange with a grinder to ensure smooth water-flow.
- 5 Apply kinoruster (Anti-crevice corrosion sealant) to face A of hull flange ③, O-ring groove on the hull flange, O-ring ⑧ and face A of the flange.
- 6 Fit O-ring ⑧ onto the O-ring groove.
- 7 Place transducer ① into hull flange ③ so that the alignment nipple on the transducer face fits into the notch on the hull flange.
- 8 Settle flange ② on the hull flange.
- 9 Tighten hex. socket bolts ⑩ with a socket screw wrench.
- 10 Put gasket ⑥ and flat washer ⑦ on the top of the flange and tighten cap nut ④ securely with a wrench (hex. size: 50mm). Screw lock nut ⑤.
- 11 When running the transducer cable inside the conduit pipe, screw the pipe end onto the cap nut (PS3/4) for watertightness.



FORE-AFT MARK




FORE-AFT MARK



ITEM	NAME	MATERIAL	Q'TY	REMARKS
10	SOCKET-HEAD SCREW	SUS304	4	M12 x 32
9	SPRING WASHER	SUS304	4	12
8	O-RING	NBR	1	JISB2401-1A-P75
7	FLAT WASHER	SPC	1	9106
6	GASKET	CR	1	9105
5	NUT	SS41	1	9104
4	CAP NUT	SS41	1	9103
3	HULL FLANGE	KAS/SS41	1	9502
2	FLANGE	SS41	1	65-003-9501
1	TRANSDUCER			DS-785

承認 APPROVED	APR. 26. '91 T. NAKAJI	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE
検 査 図 CHECKED	APR. 26. '91 M. IKEDA	尺 度 SCALE	D S-783 TRANSDUCER SEACHEST (FLUSH MOUNT, PROJECTION TYPE)
製 図 DRAWN	APR. 26. '91 C. TANAKA	重 量 WEIGHT	図 番 DWG. NO. E 7222-T03-A




取付要領

- 1 ⑤止めナットを緩め(仮締めなので手で回る。堅い時は対辺50mmスパナを使用のこと)、④キャップナットを③振動子フランジから外す(ケーブルから抜き取る必要はない)。⑥ガスケット、⑦座金も④キャップナットの方へ移しておくこと。
- 2 ⑨M12 六角穴付きボルト4本を外し(対辺10mm六角棒スパナを使用)、③振動子フランジと①振動子を②船底フランジから分離する。(⑨ボルト、⑩ばね座金、⑧Oリングは保管しておく。)
- 3 ②船底フランジを船底に溶接する。この時以下の点に注意のこと。
 - ・側面に刻印されている“FORE”の文字と船首、船尾の2本の基準線を船の船首-船尾方向に合せて溶接する。(取付誤差は±1°以内)
 - ・水平方向も吃水線と平行になるように溶接する。(取付誤差は±1°以内)
- 4 船底溶接部はグラインダー等で面一に仕上げる。
- 5 付属のキノラスター(金属スキマ腐食防止剤)を②船底フランジのフランジ面(A面)、リング溝内及び振動子フランジ面(A面)に塗布する。
- 6 ⑧Oリングを②船底フランジに装着する。
- 7 ①振動子を②船底フランジにはめ込む。(船首マークである②船底フランジの切欠と①振動子の突起を合わせること。)
- 8 ③振動子フランジを②船底フランジに乗せる。
- 9 ⑨六角穴付きボルトを締め付ける。(③振動子フランジは船首方向に関係なく任意方向でよい)
- 10 ⑥ガスケット、⑦座金を③振動子フランジ上に移し④キャップナットを締める(対辺50mmスパナ使用)。それから⑤止めナットを緩み止めとして④キャップナットにかける。
- 11 振動子ケーブルに配管する時は、④キャップナット上部のPS 3/4ねじを利用すること。


Mounting of Flush Type Transducer


1. Loosen lock nut ⑤ with a wrench (hex. size: 50mm) and take off cap nut ④ from transducer flange ③ together with gasket ⑥ and flat washer ⑦. (It is not necessary to draw the cap nut completely out from the cable.)
2. Unscrew hex. socket head bolts ⑨ (M12 x 25, 4 pcs.) by using a socket screw wrench (size: 10mm). Separate hull flange ② and transducer ① from transducer flange ③. Handle O-ring ⑧ carefully so as not to damage it.
3. Weld hull flange ② to the hull plate. Confirm that the "FORE" mark alignment line on the side of the hull flange faces the fore-aft line of the ship within ±1 degree. The hull flange ② should also be horizontal within ±1 degree at ship's normal trim.
4. Finish the outside hull plate with a grinder to ensure smooth water-flow.
5. Apply kinoruster (Anti-Crevice corrosion sealant) to face A of hull flange ②, O-ring groove on the hull flange, O-ring ⑧ and face A of the transducer flange.
6. Fit O-ring ⑧ onto the O-ring groove.
7. Place transducer ① into hull flange ② so that the alignment nipple on the transducer face fits into the notch on the hull flange.
8. Settle transducer flange ③ on the hull flange.
9. Tighten hex. socket bolts ⑨ with a socket screw wrench.
10. Put gasket ⑥ and flat washer ⑦ on top of the transducer flange and tighten cap nut ④ securely with a wrench (hex. size: 50 mm). Screw lock nut ⑤.
11. When running the transducer cable inside the conduit pipe, screw the pipe end onto the cap nut (PS3/4) for watertightness.



品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q.TY	図番 DWG. NO.	摘要 REMARKS
10	バネ座金 SPRING WASHER	SUS304	4		M12
9	六角穴付きボルト HEX. SOCKET HEAD BOLT	SUS304	4		M12 x 25
8	Oリング O RING	NBR	1		JIS B2401 P75
7	平座金 FLAT WASHER	SPC	1		5/8
6	(電線貫通金物用)ガスケット GASKET	CR	1		
5	(電線貫通金物用)止メナット NUT	SS41	1		
4	(電線貫通金物用)キャップナット CAP NUT	SS41	1		
3	振動子フランジ TRANSDUCER FLANGE	SS41	1		
2	船底フランジ FLANGE	KA	1		
1	振動子 TRANSDUCER			DS-785-10/20/30	

DRAWN Mar.25 '98 T.YAMASAKI	CHECKED Mar.25 '98 K.Kusunoki	APPROVED Mar.25 '98 K.Kusunoki	SCALE 1 / 2	MASS 9.5 kg	TYPE DS-784
					名称 船底タンク(埋込型)
					送受波器装備図
					TRANS DUCER SEACHEST(FLUSH TYPE)
DWG NO. C7222-T06-C					TRANS DUCER INSTALLATION






NOTE/INSTALLATION PROCEDURE

1. SEPARATE ② HULL FLANGE AND ④ FLANGE (WITH ① TRANSDUCER/ ⑤ SHAFT) FROM ⑩ GATE VALVE BY REMOVING ⑯ HEX. NUT.
2. WELD ② HULL FLANGE TO HULL PLATE. CONFIRM "FORE" AND REFERENTIAL MARKS SO THAT FORE-AFT INSTALLATION ERROR IS WITHIN +1 DEGREE. ALSO THE FACE OF ② HULL FLANGE SHOULD BE ALIGNED IN PARALLEL WITH THE DRAFT LINE (WITHIN +1 DEGREE). USING A GRINDER OR SIMILAR TOOL, FINISH THE OUTSIDE HULL PLATE SO THAT IT IS SMOOTH AND FLAT.
3. APPLY KINORUSTER (ANTI-CREVICE CORROSION SEALANT) TO FACE A OF ② HULL FLANGE AND TO BOTH FACES OF ⑯ GASKET AND FLANGE OF ⑩ GATE VALVE.
4. PUT ⑯ GASKET ONTO ② HULL FLANGE.
5. FASTEN ⑩ GATE VALVE TO ② HULL FLANGE. THE DIRECTION OF ⑩ GATE VALVE CAN BE SELECTED EVERY 90 DEGREES. (STANDARD DIRECTION OF HANDLE: AFT)
6. APPLY KINORUSTER TO FACE B OF ④ FLANGE AND TO BOTH FACES OF ⑯ GASKET AND FLANGE OF ⑩ GATE VALVE.
7. PUT ⑯ GASKET ONTO FLANGE OF ⑩ GATE VALVE.
8. FASTEN ④ FLANGE (WITH ① TRANSDUCER/ ⑤ SHAFT) TO ⑩ GATE VALVE. ALIGN THE "FORE" MARK OF ④ FLANGE WITH THE "FORE" MARK OF ② HULL FLANGE AT THIS TIME.
9. FOR TESTING THE MOVE OF ⑤ SHAFT, RAISE AND LOWER IT AFTER LOOSENING ⑯ HEX. SOCKET HEAD BOLT OF ⑥ LOCK RING.
10. FASTEN THE ⑯ HEX. SOCKET HEAD BOLT OF ⑥ LOCK RING AT THE LOWEST POSITION ON THE ⑤ SHAFT. ALIGN THE BOW DIRECTION MARK AT THE UPPER SIDE OF ⑤ SHAFT WITH "FORE" MARK OF ④ FLANGE.
11. CONFIRM THAT FACES OF HULL PLATE AND TRANSDUCER ARE EVEN.


21	CONNECTION CABLE			ø11.8
20	GATE VALVE	SC	1	10kg/cm²x65
19	FIXING GLAND	BRASS	1	
18	GASKET		2	10kg/cm²x65
17	O RING	NBR	2	JIS B2401 P30
16	SEAL WASHER	SUS NBR	4	M4
15	HEX. SOCKET HEAD BOLT	SUS304	4	M4x16
14	SPRING WASHER	SUS304	3	M8
13	HEX. SOCKET HEAD BOLT	SUS304	3	M8x30
12	HEX. BOLT	SUS304	4	M16x60
11	SPRING WASHER	SUS304	8	M16
10	HEX. NUT	SUS304	8	M16
9	TAP-END STUD BOLT	SUS304	4	M16x40
8	WASHER	SPC	2	
7	GASKET	CR	1	
6	LOCK RING	SS41	1	
5	SHAFT	SUS304	1	
4	FLANGE	SUS304	1	
3	BUSHING	SUS304	1	
2	HULL FLANGE	KA	1	
1	TRANSDUCER			DS-785-10/20/30
ITEM	NAME	MATERIAL	Q'TY	REMARKS

承認 APPROVED	AUG. 20. '84 <i>[Signature]</i>	三 角 法 THIRD ANGLE PROJECTION	名 称 TITLE
検査 CHECKED	AUG. 20. '84 <i>[Signature]</i>	尺 度 SCALE	1/3
製図 DRAWN	AUG. 20. '84 <i>[Signature]</i>	重 量 WEIGHT	44 kg
		DWG. NO.	E7222-T04-B


A

4-φ5 取付穴
FIXING HOLES

B



C




D

アース端子
GND TERMINAL

DRAWN Sep 24 '98 T.YAMASAKI			TYPE IF-1001/1002, DS741
CHECKED Sep 24 '98 K.Kisimiki			名称 インターフェイスユニット
APPROVED Sep 24 '98 KK Iwahashi			外寸図
SCALE 1 / 2	MASS 0.8 kg	APPLICABLE TO; (MODEL)	NAME INTERFACE UNIT
DEG NO. C4341-G01-B			OUTLINE DRAWING

DS-740 信号分配器
DISTRIBUTION BOX



※1.

TB3

W=50

TB4

W=50

TB5

W=50

TB6

W=50

TB7

W=50

TB8

W=50

TB9

W=50

TB10

W=50

TB11

W=50

TB12

W=50

TB13

W=50

TB14

W=50

TB15

W=50

TB16

W=50

TB17

W=50

TB18

W=50

TB19

W=50

TB20

W=50

TB21

W=50

TB22

W=50

TB23

W=50

TB24

W=50

TB25

W=50

TB26

W=50

TB27

W=50

TB28

W=50

TB29

W=50

TB30

W=50

TB31

W=50

TB32

W=50

TB33

W=50

TB34

W=50

TB35

W=50

TB36

W=50

TB37

W=50

TB38

W=50

TB39

W=50

TB40

W=50

TB41

W=50

TB42

W=50

TB43

W=50

TB44

W=50

TB45

W=50

TB46

W=50

TB47

W=50

TB48

W=50

TB49

W=50

TB50

W=50

TB51

W=50

TB52

W=50

TB53

W=50

TB54

W=50

TB55

W=50

TB56

W=50

TB57

W=50

TB58

W=50

TB59

W=50

TB60

W=50

TB61

W=50

TB62

W=50

TB63

W=50

TB64

W=50

TB65

W=50

TB66

W=50

TB67

W=50

TB68

W=50

TB69

W=50

TB70

W=50

TB71

W=50

TB72

W=50

TB73

W=50

TB74

W=50

TB75

W=50

TB76

W=50

TB77

W=50

TB78

W=50

TB79

W=50

TB80

W=50

TB81

W=50

TB82

W=50

TB83

W=50

TB84

W=50

TB85

W=50

TB86

W=50

TB87

W=50

TB88

W=50

TB89

W=50

TB90

W=50

TB91

W=50

TB92

W=50

TB93

W=50

TB94

W=50

TB95

W=50

TB96

W=50

TB97

W=50

TB98

W=50

TB99

W=50

TB100

W=50

TB101

W=50

TB102

W=50

TB103

W=50

TB104

W=50

TB105

W=50

TB106

W=50

TB107

W=50

TB108

W=50

TB109

W=50

TB110

W=50

TB111

W=50

TB112

W=50

TB113

W=50

TB114

W=50

TB115

W=50

TB116

W=50

TB117

W=50

TB118

W=50

TB119

W=50

TB120

W=50

TB121

W=50

TB122

W=50

TB123

W=50

TB124

W=50

TB125

W=50

TB126

W=50

TB127

W=50

TB128

W=50

TB129

W=50

TB130

W=50

TB131

W=50

TB132

W=50

TB133

W=50

TB134

W=50

TB135

W=50

TB136

W=50

TB137

W=50

TB138

W=50

TB139

W=50

TB140

W=50

TB141

W=50

TB142

W=50

TB143

W=50

TB144

W=50

TB145

W=50

TB146

W=50

TB147

W=50

TB148

W=50

TB149

W=50

TB150

W=50

TB151

W=50

TB152

W=50

TB153

W=50

TB154

W=50


TB155

W=50

TB156

W=50

1 1 2 3







D

NOTE

- *1: GROUND THRU CONNECTOR CLAMP.
- *2: PINS W/O NAME ARE NOT CONNECTED WITH CABLE.
- *3: SHIPYARD SUPPLY.


DRAWN	Jan 20'99 T.MASAKA		TITLE	DS-741
CHECKED	Jan 20'99 K.Kusunoki		名称	インターフェイスユニット
APPROVED	Jan 20'99 K.Kusunoki	DS-70	相互結線図	
SCALE	MASS	kg	NAME	INTERFACE UNIT
DWG. No.	C7222-C02- C		INTERCONNECTION DIAGRAM	






ITEM	NAME	SIZE	UNIT	QTY	REMARKS
1	JAN. 16 '86 APPROVED	1/4	ANGLE PROJECTION	8	TITLE
2	JAN. 18 '86 CHECKED	1/4	SCALE	1	DS-720 デジタル表示器総合回路図
3	JAN. 7 '86 DRAWN	1/4	WEIGHT	kg	DS-720 DIGITAL DISPLAY DWG NO. C 7222-045-A

注 特記なし抵抗の単位はΩ、1/4W、コンデンサーの容量はμF。
ALL RESISTANCE IN OHMS, 1/4W, AND ALL CAPACITANCE
IN MICROFARADS UNLESS NOTED OTHERWISE.



FURUNO



Principle of Doppler Effect

Operation of the Doppler Speed Log is based on the Doppler Effect principle. The Doppler Effect is a phenomenon in which ultrasonic sound emitted from an object in motion is received with slight frequency shifts by an observer at a stationary place.


In the figure at right, ultrasonic sound is emitted below the horizontal plane with an inclination of θ degrees. Assume that the ship's speed is V , the emitting source is approaching the seabed at a speed of $V \cos \theta$.

The frequency of the return signal from the water mass becomes higher in proportion to the ship's speed; the amount of shifting (f_d) caused by the Doppler Effect is given in the following equation.

$$f_d = f_0 \frac{2V \cos \theta}{C}$$

f_0 : Transmission frequency

C : Propagation speed of ultrasonic wave under the water




Since the transmission frequency f_0 , and propagation speed C and inclination θ are known parameters, the ship's speed can be obtained by measuring the doppler shift frequency f_d .

Note : Although the propagation speed C changes slightly, largely depending on water temperature, a temperature sensor in the transducer automatically cancels the measuring error caused by this factor.

In practice, the erroneous frequency shift Δf , caused by rolling and pitching, is involved in the f_d . The advanced pair-beam system provides features to cancel this Δf by subtracting the frequency obtained by the beam in the aft direction from the one in the fore direction.

$$(f_0 + f_d + \Delta f) - (f_0 - f_d + \Delta f) = 2f_d$$



FURUNO


FURUNO ELECTRIC CO., LTD.

9-52 Ashihara-Cho, Nishinomiya City, 662-8580, Hyogo, Japan

Tel: +81 798-65-2111 Fax: +81 798-65-4200

Pub NO. DOC-272

Declaration of conformity to type



We **FURUNO ELECTRIC CO., LTD.**

(Manufacturer)

9-52 Ashihara-Cho, Nishinomiya City, 662-8580, Hyogo, Japan

(Address)

hereby declare under our sole responsibility that the product

Doppler speed log model DS-70 consisting of Main display unit DS-700, Transducer assembly DS-785*, Junction box DS-750 and Interface unit DS-741, and optional Distribution box DS-740, Digital display unit DS-720, Distance indicator DS-730 and Analog display unit DS-762

(Model names, type numbers)

to which this declaration relates conforms to the following standard(s) or normative document(s)

IMO Resolution A.824 (19): 1995, EN 61023, EN-61162-1, EN 60945: 1997 (IEC 60945 Third edition: 1996-11)

(title and/or number and date of issue of the standard(s) or other normative document(s))

For assessment, see EC – type approval certificate Nr. 6299/059/00 of 17 February 2000 issued by Federal Maritime and Hydrographic Agency, the Federal Republic of Germany
(Item marked with asterisk is designated as DS-710 in the certificate, but it has been renamed as DS-785.)

This declaration is issued according to the provisions of European Council Directive 96/98/EC on marine equipment modified by Commission Directive 98/85/EC.

On behalf of Furuno Electric Co., Ltd.

Hiroaki Komatsu
Manager,
International Rules and Regulations

Nishinomiya City, Japan
April 14, 2000

(Place and date of issue)

(name and signature or equivalent marking of authorized person)