


# FURUNO

## INSTALLATION MANUAL




DOPPLER SONAR  
CURRENT INDICATOR

MODEL CI-35/35H



**FURUNO ELECTRIC CO., LTD.**  
NISHINOMIYA, JAPAN



© **FURUNO ELECTRIC CO., LTD.**

9-52, Ashihara-cho,  
Nishinomiya, Japan

Telephone: 0798-65-2111  
Telefax: 0798-65-4200

•Your Local Agent/Dealer

All rights reserved. Printed in Japan

FIRST EDITION : FEB. 1997  
F1 : OCT. 7, 2002

(DAMI) PUB. No. IME-72440-F1  
CI-35/35H



\* 00080797801 \*



\* IME72440F10 \*



# SAFETY INSTRUCTIONS

"DANGER", "WARNING" and "CAUTION" notices appear throughout this manual. It is the responsibility of the installer of the equipment to read, understand and follow these notices. If you have any questions regarding these safety instructions, please contact a FURUNO agent or dealer.



**DANGER**

This notice indicates a potentially hazardous situation which, if not avoided, will result in death or serious injury.



**WARNING**

This notice indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



**CAUTION**

This notice indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury, or property damage.

**⚠ WARNING**

 **ELECTRICAL SHOCK HAZARD**  
Do not open the equipment unless totally familiar with electrical circuits and service manual.

Only qualified personnel should work inside the equipment.

**Turn off the power at the switchboard before beginning the installation. Post a warning sign near the switchboard to ensure that the power will not be applied while the equipment is being installed.**

Serious injury or death can result if the power is not turned off, or is applied while the equipment is being installed.

**⚠ CAUTION**

 **Ground the equipment.**

Ungrounded equipment can give off or receive electromagnetic interference or cause electrical shock.

**Confirm that the power supply voltage is compatible with the voltage rating of the equipment.**

Connection to the wrong power supply can cause fire or equipment damage. The voltage rating appears on the label at the rear of the equipment.

**Observe the following compass safe distances to prevent interference to a magnetic compass:**

	Standard compass	Steering compass
Display unit	1.3 m	1.0 m
Terminal unit	1.7 m	1.3 m

# CONTENTS

<b>Complete Set .....</b>	<b>3</b>
<b>System Diagram.....</b>	<b>5</b>
<b>Installation Materials .....</b>	<b>6 – 12</b>
<b>Accessories .....</b>	<b>13</b>
<b>Spare Parts .....</b>	<b>14 – 18</b>
<b>CHAPTER 1 GENERAL DESCRIPTION .....</b>	<b>1-1 – 1-6</b>
1.1 Selection of Installation Site .....	1-1
1.2 Grounding .....	1-4
1.3 Alteration of Power Supply Voltage .....	1-6
<b>CHAPTER 2 MOUNTING .....</b>	<b>2-1 – 2-10</b>
2.1 Display Unit .....	2-1
2.2 Transceiver Unit.....	2-2
2.3 Matching Box/Junction Box .....	2-3
2.4 Hull (Transducer) Unit for CI-35H .....	2-4
2.5 DC-AC Inverter .....	2-8
2.6 Hull (Transducer) Unit for CI-35 .....	2-9
<b>CHAPTER 3 CONNECTIONS .....</b>	<b>3-1 – 3-16</b>
3.1 Cabling .....	3-1
3.2 Display Unit .....	3-2
3.3 Transceiver Unit.....	3-3
3.4 Junction Box .....	3-5
3.5 External Equipment .....	3-7
3.5.1 Connection of external equipment to the display unit .....	3-7
3.5.2 Connection of external to the transceiver unit.....	3-8
3.6 DC-AC Inverter (TR-2450 or CSH-5050).....	3-12
3.7 Matching Box .....	3-15
<b>CHAPTER 4 POST-INSTALLATION CHECK AND ADJUSTMENT .....</b>	<b>4-1 – 4-25</b>
4.1 Line Voltage .....	4-1
4.2 LED Status Check .....	4-4
4.3 DIP Switch Setting .....	4-9
4.4 TX Output Check .....	4-14
4.5 External Noise and Interference Check .....	4-15
4.5.1 External Noise Check.....	4-15
4.5.2 Interference Check .....	4-16
4.5.3 Interference Rejection .....	4-17

4.6 Sea Trial Check ..... 4-20  
    4.6.1 Ship's Speed Test..... 4-20  
    4.6.2 Current Information Check ..... 4-20  
    4.6.3 Course Calibration ..... 4-22

**Outline Drawings..... D-1**

**Interconnection Diagrams ..... S-1**



## Complete Set


### Standard Supply

No.	Name	Type	Mass (kg)	Q'ty	Remarks
1	Display unit	CI-3500	20	1	for CI-35
		CI-3500-HK			for CI-35H
2	Transceiver unit	CI-3510	32	1	for CI-35
		CI-3510-HK			for CI-35H
3	Matching Box	CI-3540	2	1	for CI-35
	Junction Box	CI-630-HK			for CI-35H
4	Transducer	CI-240		1	for CI-35
		CI-3520-1	22	1	for CI-35H, w/10 m cable
		CI-3520-2	27		for CI-35H, w/20 m cable
5	Installation Materials			1 SET	
6	Accessories	FP66-00400		1 SET	
7	Spare Parts	SP66-00400		1 SET	
		SP66-00410			

### Optional Equipment

NO.	Name	Type	Mass (kg)	Remarks
1	DC-AC Inverter	TR-2450	35	
2	DC-AC Inverter	CSH-5050	21	
3	Distribution Unit	DS-370	19	
4	Digital Indicator	DS-350	7.0	
		DS-351	4.0	Flush mount
5	Remote Box	DS-359	0.7	for DS-351
6	Analog Indicator	DS-381-S	6.4	for CI-35
		DS-381-HK		for CI-35H
		DS-382	6.0	for CI-35
		DS-382-HK		for CI-35H
		MF-22A-1	6.4	-10 to 30 kt, Φ200, Flush mount
		MF-22A-2	6.0	-10 to 30 kt, Φ200, Bulkhead mount
		MF-22A-3	1.3	-10 to 30 kt, Φ200, Flush mount
		MF-22A-4	4.4	-10 to 30 kt, Φ200, Flush mount (less brim)
	MF-22A-5	2.8		

No.	Name	Type	Mass (kg)	Remarks
6	Analog Indicator	MF-22A-6	6.0	-10 to 30 kt, $\phi$ 200, Flush mount
		MF-22A-7	6.0	-10 to 30 kt, $\phi$ 200, Bulkhead mount (counterclockwise dial)
		MF-22A-8	6.0	-10 to 30 kt, $\phi$ 200, Bulkhead mount (counterclockwise dial)
		MF-22A-9	2.3	-10 to 30 kt, $\phi$ 150
		FE-90	1.2	-10 to 30 kt, Flush mount
		FL-90	1.4	-10 to 30 kt, Flush mount
		DS-761	6.0	-10 to 30 kt, Flush mount
		DS-762	6.0	-10 to 30 kt, Bulkhead mount
		DS-763	1.3	-10 to 30 kt, Flush mount (small size)
		DS-771	6.0	-10 to 20 kt, Flush mount
		DS-772	6.0	-10 to 20 kt, Bulkhead mount
		DS-773	1.3	-10 to 20 kt, Flush mount (small size)
7	Range Switch Box	DS-389	0.75	Flush mount
8	Dimmer	MF-22L-1-100V	1.2	Flush mount
		MF-22L-1-200V		
		MF-22L-2-100V	1.3	Bulkhead mount
		MF-22L-2-200V		
9	Distance Indicator	DS-730	1.7	Flush mount/ Tabletop mount



CI-35 DOPPLER SONAR CURRENT INDICATOR




TRANSUCER: CI-3520  
CI-3520

- NOTE
- \* : SHIPYARD SUPPLY
  - ⊠ : CONNECTOR (⊠:FACTORY-FITTED)
  - ⌋ : CRIMP-ON LUG (⌋:FACTORY-FITTED)
  - ⌋ : GROUNDING COPPER STRAP
  - ⌋ : GROUNDING WIRE IV-8sq.
  - ⌋ : CABLE SUPPLY SIDE
  - ⌋ : OPTIONAL SUPPLY
  - CO-0.2x2P: CO-SPEVY-SB-C 0.2x2P, #10.5
  - CO-0.2x5P: CO-SPEVY-SB-C 0.2x5P, #13.5

DRAWN 5th 27/97	TYPE CI-35/35H
CHECKED 5th 27/97	
APPROVED 5th 29/97	NAME DOPPLER SONAR CURRENT INDICATOR
SCALE 1/1000	SYSTEM DIAGRAM
DWG. NO. E724402A000	

**FURUNO**

CODE NO.	006-924-570
TYPE	CP66-00701








工事材料表 INSTALLATION MATERIALS		CI-35/35H カラー潮流観測装置 音波ログ DOPPLER SONAR CURRENT INDICATOR (指示器用) FOR DISPLAY			
番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	アース板 COPPER STRAP		WEA-1004-0 CODE NO. 500-310-040	1	
2	コネクタ CONNECTOR		PRC03-12A10-5M10.5 CODE NO. 000-110-679	1	P33 (外部警報用) FOR P33 EXTERNAL ALARM
3	コネクタ CONNECTOR		NCS-252-P CODE NO. 000-506-501	1	P31 (電源用) FOR P31 POWER CONNECTOR
4	コネクタ CONNECTOR		SRCN6A21-16P CODE NO. 000-508-664	1	P32 (信号用) FOR P32 SIGNAL CONNECTOR
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		

(略図の寸法は、参考値です。)  
DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (1/1)  
DWG. NO. C7242-M01-B

**FURUNO**

CODE NO	006-924-580
TYPE	CP66-00702




工事材料表 INSTALLATION MATERIALS		CI-35/35H カラー潮流観測装置 DOPPLER SONAR CURRENT INDICATOR (送受信演算部用) FOR TRANSCEIVER UNIT			
番号 No	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	アース板 COPPER STRAP		WEA-1004-0	1	
			CODE NO 500-310-040		
2	コネクタ CONNECTOR		NCS-303-P	1	船内電源用 FOR SIP'S MAINS
			CODE NO 000-110-561		
3	圧着端子 CRIMP-ON LUG		FV0.5-3.7 ｷ YEL	10	TB1用 FOR TB1
			CODE NO 000-118-307		
4	圧着端子 CRIMP-ON LUG		FV2-P4 アオ BLU	5	4対ケーブル用 FOR SHIELD A PAIR CABLE
			CODE NO 000-120-199		
5	圧着端子 CRIMP-ON LUG		FV2-P3.5 BUL	6	TB1 シールド線用 FOR SHIELD TO TB1
			CODE NO 000-120-200		
6	コネクタ CONNECTOR		17JE-23250-02(D1)	2	P103(NMEA用) FOR P103 (NMEA)
			CODE NO 000-120-201		
7	コネクタケース HOUSING CASE		17JE-25H-1A	2	P103(NMEA用) FOR P103 (NMEA)
			CODE NO 000-120-202		
8	コネクタ CONNECTOR		SRCN6A16-10P	1	P102(CIF用) FOR P102 (CIF)
			CODE NO 000-508-663		
9	コネクタ CONNECTOR		SRCN6A13-5S	1	P105用 FOR P105
			CODE NO 000-508-666		
10	圧着端子 CRIMP-ON LUG		FV1.25-M3 ｱｶ RED	16	TB1用 FOR TB1
			CODE NO 000-538-110		

(略図の寸法は、参考値です。)  
DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (1/2)  
DWG. NO. C7242-M02-B

**FURUNO**

CODE NO.	006-924-580
TYPE	CP66-00702

工事材料表 INSTALLATION MATERIALS		CI-35/35H カラー潮流観測装置 音波ログ DOPPLER SONAR CURRENT INDICATOR (送受信演算部用) FOR TRANSCEIVER UNIT			
番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
11	圧着端子 CRIMP-ON LUG		FV1.25-4 アカ RED CODE NO. 000-538-114	9	4対ケーブル 芯線用 FOR CORSE OF 4 PAIR CABLE
12	圧着端子 CRIMP-ON LUG		FV5.5-S4 キ YEL CODE NO. 000-538-121	2	4対ケーブル 活シールド線用 FOR OUTER SHIELD OF 4 PAIR CABLE
13	圧着端子 CRIMP-ON LUG		FV2-5 アオ BLU CODE NO. 000-107-331	14	あじろ 鎧装 アース用 FOR GND OF SHIELD OF ARMOR
14	ビニール線 VINYL WIRE		VSF-2.0SQ クロ *5M* BLK CODE NO. 000-121-401	1	あじろ 鎧装 アース用 FOR GND OF SHIELD OF ARMOR
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		



(略図の寸法は、参考値です。)  
DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (2/2)  
DWG. NO. C7242-M03-B

**FURUNO**

CODE NO	
TYPE	

<b>工事材料表</b> INSTALLATION MATERIALS		CI-35/35H カラー潮流観測装置 音波ログ DOPPLER SONAR CURRENT INDICATOR (信号ケーブル用) FOR SIGNAL CABLE	
--	--	--	--

番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	信号ケーブル組品 SIGNAL CABLE ASSEMBLY	 L=10m	S66-4-10(20P) *10M*(CO-SPEVV-SB -C 0.2X10P) CODE NO 006-924-510	1	
1	信号ケーブル組品 SIGNAL CABLE ASSEMBLY	 L=20m	S66-4-20(20P) *20M*(CO-SPEVV-SB -C 0.2X10P) CODE NO 006-924-520	1	
1	信号ケーブル組品 SIGNAL CABLE ASSEMBLY	 L=30m	S66-4-30(20P) *30M*(CO-SPEVV-SB -C 0.2X10P) CODE NO 006-924-530	1	
2	電源ケーブル組品 POWER CABLE ASSEMBLY	 L=10m	P66-1-10 *10M* (DPYCY-1.25,10M) CODE NO 006-924-540	1	
2	電源ケーブル組品 POWER CABLE ASSEMBLY	 L=20m	P66-1-20 *20M* (DPYCY-1.25,20M) CODE NO 006-924-550	1	
2	電源ケーブル組品 POWER CABLE ASSEMBLY	 L=30m	P66-1-30 *30M* (DPYCY-1.25,30M) CODE NO 006-924-560	1	
			CODE NO		
			CODE NO		
			CODE NO		
			CODE NO		

\*1と2は同じ長さのものを選択すること。  
 SELECT SAME LENGTH CABLES.


(略図の寸法は、参考値です。)  
 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (1/1)  
 DWG. NO. C7242-M04-B

**FURUNO**

CODE NO	
TYPE	

<b>工事材料表</b> INSTALLATION MATERIALS	CI-35/35H カラー潮流観測装置 音波ログ DOPPLER SONAR CURRENT INDICATOR (ケーブル用) FOR CABLE	
--	---	--

番号 No	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	4対ケーブル 4P TWISTED PAIR CABLE	 L=5m	66S1067 *5M*	1	
			CODE NO 000-120-210		
1	4対ケーブル 4P TWISTED PAIR CABLE	 L=10m	66S1067 *10M*	1	
			CODE NO 000-120-226		
1	4対ケーブル 4P TWISTED PAIR CABLE	 L=15m	66S1067 *15M*	1	
			CODE NO 000-120-227		
1	4対ケーブル 4P TWISTED PAIR CABLE	 L=20m	66S1067 *20M*	1	
			CODE NO 000-120-228		
1	4対ケーブル 4P TWISTED PAIR CABLE	 L=30m	66S1067 *30M*	1	
			CODE NO 000-120-229		
			CODE NO		
			CODE NO		
			CODE NO		
			CODE NO		
			CODE NO		





(略図の寸法は、参考値です。)  
DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (1/1)  
DWG. NO. C7242-M05-B

**FURUNO**

CODE NO.	006-927-330
TYPE	CP66-00703

工事材料表 INSTALLATION MATERIALS	CI-35/35H カラー潮流観測装置 音波ログ DOPPLER SONAR CURRENT INDICATOR (接続箱用) FOR JUNCTION BOX
---------------------------------	---

番号 No	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	アース板 COPPER STRAP		WEA-1004-0	1	
			CODE NO. 500-310-040		
2	+トラスタップソングネジ TAPPING SCREW		5X25 SUS304 151	4	
			CODE NO. 000-802-082		
3	圧着端子 CRIMP-ON LUG		FV2-P4 アオ BLU	10	シールド線用 FOR SHIELD
			CODE NO. 000-120-199		
4	圧着端子 CRIMP-ON LUG		FV1.25-4 アカ RED	18	芯線用 FOR CORES
			CODE NO. 000-538-114		
5	圧着端子 CRIMP-ON LUG		FV5.5-5 黄 YEL	3	一活シールド 装アース用 FOR GROUND OF SHIELD AND ARMOR
			CODE NO. 000-114-733		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		




(略図の寸法は、参考値です。)  
 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (1/1)  
 DWG. NO. C7242-M06-B

**FURUNO**

CODE NO.	002-876-550
TYPE	CP66-00811

<b>工事材料表</b> INSTALLATION MATERIALS	CI-35/35H カラー潮流観測装置 DOPPLER SONAR CURRENT INDICATOR (分配器用)FOR DISTRIBUTOR
--	---

番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	圧着端子 CRIMP-ON LUG		FV1.25-M4 アカ RED	15	
			CODE NO.		
2	圧着端子 CRIMP-ON LUG		FV1.25-M3 アカ RED	80	
			CODE NO.		
3	アース銅板 *鉄付* COPPER STRAP W/STEEL PLATE		0.4X50X600MM	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		




(略図の寸法は、参考値です。)  
 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (1/1)  
 DWG. NO. C7242-M07-B

**FURUNO**

CODE NO.	000-069-757
TYPE	FP66-00400

<b>付属品表</b> ACCESSORIES		CI-35/35H カラー潮流観測装置 CI-35/35H 音波ログ DOPPLER SONAR CURRENT INDICATOR (指示器用) FOR DISPLAY		
----------------------------	--	--	--	--









番号 No.	名称 NAME	略図 OUTLINE	型名 / 規格 DESCRIPTIONS	数量 Q'TY	用途 / 備考 REMARKS
1	フィルタ袋詰品 FILTER		FP02-02510 CODE NO. 001-410-620	1	
2	フード組品 HOOD ASSEMBLY		FP03-02910 03-034-1601-1 CODE NO. 008-223-520	1	
3	ビニールカバー(12インチ) PLASTIC COVER		66-017-2111 CODE NO. 000-802-058	1	
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		
			CODE NO.		

(略図の寸法は、参考値です。)  
 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.

図番 (1/1)  
 DWG. NO. C7242-F01-B







**FURUNO**

CODE NO.	000-069-755	
TYPE	SP66-00400	BOX NO. P

SHIP NO.	SPARE PARTS LIST FOR		U S E			SETS PER VESSEL
	カラー潮流観測装置 CI-35/35H 音波ログ DOPPLER SONAR CURRENT INDICATOR		(AC100V用) FOR 100VAC			
ITEM NO.	NAME OF PART	O U T L I N E	DWG. NO. OR TYPE NO.	Q U A N T I T Y		REMARKS/CODE NO.
				WORKING	SPARE	
				PER SET	PER VES.	
1	ミゼットヒューズ FUSE		FGMB 0.5A AC125V	1	3	指示器用 FOR DISPLAY UNIT 000-114-994
2	管入りヒューズ GLASS TUBE FUSE		FGBO-A 5A AC125V	2	6	指示器用 FOR DISPLAY UNIT 000-549-064
3	管入りヒューズ GLASS TUBE FUSE		FGBO 7A AC125V	3	5	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-013
4	管入りヒューズ GLASS TUBE FUSE		FGBO-A 1A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-061
5	管入りヒューズ GLASS TUBE FUSE		FGBO-A 3A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-063
6	管入りヒューズ GLASS TUBE FUSE		FGBO-A 5A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-064
7	管入りヒューズ GLASS TUBE FUSE		FGBO 10A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-065
8	管入りヒューズ GLASS TUBE FUSE		FGBO 15A AC125V	2	4	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-014
MFR'S NAME	FURUNO ELECTRIC CO., LTD			DWG. NO.	C7242-P01-B	1/1

**FURUNO**

CODE NO	000-069-756	
TYPE	SP66-00410	BOX NO. P

SHIP NO	SPARE PARTS LIST FOR		U S E			SETS PER VESSEL
	カラー潮流観測装置 CI-35/35H 音波ログ DOPPLER SONAR CURRENT INDICATOR		(AC200V用) FOR 200VAC			
ITEM NO.	NAME OF PART	O U T L I N E	DWG NO. OR TYPE NO.	Q U A N T I T Y		REMARKS/CODE NO
				WORKING	SPARE	
				PER SET	PER VES.	
1	ミゼットヒューズ FUSE		FGMB 0.5A AC125V	1	3	指示器用 FOR DISPLAY UNIT 000-114-994
2	管入りヒューズ GLASS TUBE FUSE		FGBO-A 5A AC125V	2	6	指示器用 FOR DISPLAY UNIT 000-549-064
3	管入りヒューズ GLASS TUBE FUSE		FGBO 7A AC125V	3	5	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-013
4	管入りヒューズ GLASS TUBE FUSE		FGBO-A 1A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-061
5	管入りヒューズ GLASS TUBE FUSE		FGBO-A 3A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-063
6	管入りヒューズ GLASS TUBE FUSE		FGBO-A 5A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-064
7	管入りヒューズ GLASS TUBE FUSE		FGBO 10A AC125V	1	3	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-065
8	管入りヒューズ GLASS TUBE FUSE		FGBO 10A AC250V	2	4	送受信演算部用 FOR TRANSCEI VER UNIT 000-549-067
MFR'S NAME	FURUNO ELECTRIC CO., LTD			DWG NO	C7242-P10-A 1/1	







# CHAPTER 1 GENERAL DESCRIPTION

The Doppler Sonar Current Indicator CI-35/35H consists of a Display Unit, a Transceiver Unit, a Junction Box and a Hull (Transducer) Unit. To obtain absolute tide even in deep waters, the CI-35/35H must be supplied with the speed/course data (or position data) from a navigation equipment (GPS), and the heading data from a gyrocompass (via an A-D converter). The equipment can output ship's speed and true bearing data to a radar or scanning sonar for true-motion display. Further, current data can be output to an echo sounder or scanning sonar in CIF format.

To obtain full performance from the equipment, the installation of the units, especially the hull unit, is very important. Poor siting of units or poor cable layout may cause pick-up of noise, or give interference to other units. This chapter presents an overview of how to install the equipment.

## 1.1 Selection of Installation Site

### Hull (Transducer) Unit

The performance of the equipment largely depends on the installation of the transducer unit, and a very important consideration is the installation site. They should meet the following requirements.

- a) No projections (such as sonar's retraction tank) should exist in the hatched area shown in Fig. 1-1. However, when the transducer unit projects below the lowest part of the keel, the effects when the sonar transducer is lowered must be taken into account.




Fig. 1-1

- b) Mount the transducer between one-third and one-half of the ship's full length (measuring from the bow). Select the place where the transducer is free from the effects of air bubbles. The transducer face should not be above the sea surface when the ship is pitching or rolling.
- c) In general, the air bubbles produced at the bow flow backward alongside the keel. Therefore, separate the transducer by more than 1000 mm from the keel, or flush mount the transducer inside the keel. (See notes below.)
- d) The surface of the transducer should project by 250 mm or more from the hull bottom. For better performance, its surface should be even with the keel's lowest point or below it.
- e) The following is important for preventing interference between the CI-35/35H and other equipment(s).  
If the transducer of an echo sounder or scanning sonar whose harmonic is within the frequency range of 122kHz to 138kHz ( $130 \pm 8\text{kHz}$ ) is mounted, interference may occur. Even if the harmonic is out of the range, the risk of interference still exists if the transducer of the CI-35/35H and other equipment(s) are mounted near one another. For this reason, separate the transducer of the CI-35/35H as far as practical from other equipments which have high output power. If interference is unavoidable due to limited mounting space, connect the interfering equipment to the built-in interference rejector circuit (two inputs) in the transceiver unit. For connection to this circuit, you will need to run a two-core cable between it and the interfering equipment(s).
- f) Make the transducer cable as short as possible. The cable is generally installed in grounded steel conduit run between the transducer and the junction box, to prevent pick-up of noise. The transducer with 20 m transducer cable can be used only when it is passed inside conduit.


*Note 1: For flush mounting, provision must be made to allow water to flow inside the transducer to keep it cool.*

*Note 2: Before installing the hull (transducer) unit, discussion should take place and agreement be reached with the shipyard for sufficient reinforcement and watertightness of the hull and keel to comply with the regulations concerned.*

### **Other Units**

When selecting a mounting location for the other units (except transducer) of the CI-35/35H system, keep the following in mind:

- a) Keep the units out of direct sunlight.
- b) Keep the units away from air conditioners and heaters.
- c) Avoid areas subjected to rain or water splash.
- d) Select a well-ventilated area.
- e) Avoid wet and dusty areas.
- f) Select a place where vibration is minimum.



## 1.2 Grounding

This equipment uses pulse signals which may cause interference to other electronic equipments such as direction finder and radio receiver, if it is not grounded properly. It is strongly recommended to ground all cables referring to the guidelines below.

- a) Separate all units as far as possible from radio equipment.
- b) Do not run interconnection cables close to or near radio equipment or its cables.
- c) Run the cables in the shortest path practical.
- d) Lay the cables on grounded copper plate and fix them every 30 cm with metal cable clamps.
- e) Ground all units with a copper strap as shown in Figs. 1-2 and 1-3.
- f) To join copper straps, use solder cream for perfect contact.





Fig. 1-2 Example of Grounding [1]

Location of earth terminal on each unit and grounding method


- Display Unit (Rear)



Fix copper strap (W=50 mm) to earth studs by the two wing nuts.


	<b>CAUTION</b>
	<b>Ground the equipment.</b>
	Ungrounded equipment can give off or receive electromagnetic interference or cause electrical shock.

- Transceiver Unit (Bottom)



Fix copper strap (w=50 mm) to earth studs by the two wing nuts.

- Junction Box (CI-35H)/Matching Box (CI-35), Bottom



Fix copper strap to earth studs by the two wing nuts.

Fig. 1-3 Examples of Grounding [2]


## 1.3 Alteration of Power Supply Voltage

1ø, 50/60 Hz AC power is supplied to the transceiver unit. The transformer tap is set at the factory according to customer's order. If necessary, change jumper wires at TB5 of the Transceiver Unit according to the input voltage.

**⚠ CAUTION**

**Confirm that the power supply voltage is compatible with the voltage rating of the equipment.**

Connection to the wrong power supply can cause fire or equipment damage. The voltage rating appears on the label at the rear of the equipment.



**Note:** Confirm that the jumper settings in the transceiver unit are set according to ship's mains before turning power on.

*Fig. 1-4 Jumper Connections for Mains Voltages*

# CHAPTER 2 MOUNTING

## 2.1 Display Unit

### Mounting Considerations

The display unit is designed for tabletop mounting. It can be installed almost anywhere, provided the following conditions are met.

- 1) Select a place where controls can be easily operated while observing fishing ground or the area around the vessel.
- 2) Locate the unit at least 1 m from magnetic devices (radar magnetron, loudspeaker, high power transformer, etc.) and magnetic compass.
- 3) Keep the unit out of direct sunlight, water splashes and hot air.
- 4) Secure enough space around the unit for maintenance, checking and ventilation, referring to the outline drawings.
- 5) Select a place where the CRT face is within  $\pm 45^\circ$  from vertical.




Fig. 2-1

### Procedure

1. Remove the mounting base from the display unit by loosening the two bolts at the front of the display unit.
2. Fix the mounting base to the chosen location with four woodscrews ( $\phi 10 \times 25$ ) or four bolts (M10).




Fig. 2-2 Display Unit Mounting Dimensions

3. Fix the display unit to the mounting base with the two bolts removed in step 1.

## 2.2 Transceiver Unit

### Mounting Considerations

- 1) Since the transceiver unit generates heat, install it in a dry, well-ventilated place. The cooling fans at the top of the unit must not be obstructed, to allow heat to escape.
- 2) This unit is designed for bulkhead mounting to permit dissipation of heat. If bulkhead mounting is absolutely impossible, mount the unit on the floor leaving at least 50 mm clearance between it and the floor to permit dissipation of heat.
- 3) The unit weighs 32 kg. Reinforce the mounting area, if necessary.
- 4) Leave space around the unit for maintenance and checking. Refer to the drawing on page D-2.

### Procedure

1. Fix 4 bolts (M10) to the bulkhead so their ends are exposed by about 20 mm. Attach a nut to each bolt to provide clearance between the rear panel of the unit and the bulkhead to prevent warpage of the rear panel. If it warps, it may be impossible to remove the power block in the transceiver unit.




Fig. 2-3 Transceiver Unit Mounting Dimensions (Vertical Mounting)

2. Place the transceiver unit on the bulkhead and fix it with nuts.

## 2.3 Matching Box/Junction Box

### Mounting Considerations

The matching box/junction box forms a joint between the hull unit and the transceiver unit.

Use the matching box for CI-35, junction box for CI-35H.

Install it referring to the guidelines below.

- 1) Keep the box away from noise emitting electrical machinery, i.e., electric generator, radio transmitter, TV, etc.
- 2) Do not install it in places of high humidity.
- 3) Avoid installing the box where temperature varies greatly, since moisture may penetrate the box.
- 4) The box is generally installed above the draft line of the ship and the transducer cable is run inside steel conduit. This permits replacement of the transducer without dry docking. Even if the junction box is installed below the draft line, the conduit is necessary to minimize picking up of noise. If use of conduit is not possible, install the box as near to the transducer as possible.




Fig.2-4 Matching Box/Junction Box Mounting Dimensions

### Procedure

Fix the box to a bulkhead, referring to Fig.2-4.

## 2.4 Hull (Transducer) Unit for CI-35H

### Steel Hull Vessels (See page D-4)

1. Select a mounting place on the hull bottom, referring to chapter 1. (Since the transducer cable is comparatively thick, select a mounting place for the thru-hull pipe where the cable can be easily led into the cable gland.).
2. If necessary, weld a doubling plate (shipyard supply) to the hull bottom.
3. Unpack the transducer casing and determine the projecting length, making it 350 mm or cut it considering the rising angle of the ship's hull. Weld the casing in parallel with ship's fore-aft line with an accuracy of better than  $\pm 1^\circ$ .  
The transducer face should be horizontal at cruising speed.
4. Make a hole for the thru-hull pipe in the hull bottom. Before welding the thru-hull pipe, remove the rubber packing from the thru-hull pipe. Weld the thru-hull pipe. Replace the rubber packing.
5. Make a hole of 10 to 20 mm diameter on the stern side of the casing to allow water to penetrate the transducer casing.
6. Weld the casing to the hull bottom. Do not remove the transducer fixing flange to prevent the casing from being deformed.




Fig.2-5 Fixing Transducer Casing

7. Dismount the fixing flange from the casing. Fix the transducer to the fixing flange.




Fig. 2-6

8. Pass the transducer cable through the thru-hull pipe. Tighten the cable gland, leaving a cable slack of 0.5 to 1 m below the cable gland.




Fig. 2-7 Thru-hull Pipe for Steel Hull

9. Mount the fixing flange with the transducer onto the casing. Take care not to pinch the transducer cable. Never hold the transducer by the cable. Shock will most assuredly damage the transducer.

**FRP Hull Vessels** (See page D-5)

1. Select a mounting place on the hull bottom, referring to chapter 1. (Since the transducer cable is comparatively thick, select a mounting place for the thru-hull pipe where the cable can be easily led into the cable gland.)
2. Determine the projecting length of the casing, making it at least 250 mm. Cut the casing, considering the rising angle of the ship's hull, so that the transducer face is horizontal. The casing should be parallel with ship's fore-aft line within  $\pm 1^\circ$ , and the transducer face should be horizontal at cruising speed.
3. Make a hole of 10 to 20 mm in diameter on the stern side of the casing to allow water to penetrate the transducer casing.
4. Make a hole for the thru-hull pipe on the hull bottom. Allow enough clearance around the pipe for easy tightening of lock nuts.
5. Fix the thru-hull pipe on the hull plate with double nuts and then apply FRP glue around the pipe.
6. Before fixing the casing to the hull bottom, clean the hull plate surface with an electric sander until fiberglass appears, then remove dusts, oils, etc. from surface. Reinforce both sides of the casing with FRP molding.
7. Fix the transducer to the fixing flange.




Fig. 2-8

8. Pass the transducer cable through the thru-hull pipe. Tighten the cable gland, leaving a cable slack of 0.5 to 1 m below the cable gland.

To tighten the cable gland;

- a) Tighten the gland securely.
- b) Tighten the double nut securely.




Fig. 2-9

9. Fix the fixing flange with the transducer to the casing. Take care not to pinch the transducer cable.

## 2.5 DC-AC Inverter

If the ships mains is 24 VDC or 32 VDC a DC-AC inverter is required. Two models are available; TR-2450, 24/32 VDC, and CSH-5050, 32 VDC. For the CSH-5050, change the tap connection for 32 VDC. For further information, see the instruction sheet attached to the CSH-5050. Never share the output of the DC-AC Inverter with other equipment(s).




Fig. 2-10 TR-2450 Mounting Dimensions




Fig. 2-11 CSH-5050 Mounting Dimensions

## 2.6 Hull (Transducer) Unit for CI-35

### Mounting Considerations

Select a mounting place on the bottom, referring to chapter 1.

1. If necessary, weld a doubling plate (shipyard supply).
2. Unpack the transducer casing and determine the projecting length, making it 350 mm or more. Before cutting the casing, confirm that the transducer casing has "direction". Then, cut it considering the rising angle of the ship's hull.
3. Make a hole for the thru-hull pipe in the hull bottom. Before welding the thru-hull pipe, remove the rubber gasket from the thru-hull pipe. Weld the thru-hull pipe. Replace the rubber gasket.
4. Spot-weld the joint of the casing, and then weld the casing to the hull bottom. To prevent the casing from being deformed, note the following points.
  - a) Do not remove the transducer fixing flange and fixing plate.
  - b) Weld the casing to the hull bottom symmetry and equidistantly.




Fig.2-12 Fixing Transducer Casing

**Note:** Weld the casing in parallel with ship's fore-aft line with an accuracy of better than  $\pm 1^\circ$ .

5. Unpack the transducer in the ship's bottom.
6. Dismount the fixing flanges from the casings, and then fix the transducers to flanges appropriately.

Referring to the stickers on the vinyl packing of transducer or beam No. on transducer cable, mount the transducers as below.




Fig.2-13 Mounting transducers on flanges




Fig. 2-14 Transducer casing, bottom view and beam direction

7. Pass the transducer cable through the thru-hull pipe. Tighten the cable gland, leaving a cable slack of 0.5 to 1 m below the cable gland.
8. Mount fixing flange with the transducer onto the casing. Take care not to pinch the transducer cable. Never hold the transducer by the cable. Shock will most assuredly damage the transducer.

# CHAPTER 3 CONNECTIONS

## 3.1 Cabling

Connect cables referring to the figure below.





Fig. 3-1 Cabling for basic system


## 3.2 Display Unit

Two cables run from the transceiver unit: a power cable and a signal cable. Fit a connector to each as shown below.

1) Power cable P66-1-10/20/30 (DPYCY-1.25)



2) Signal cable S66-4-10/20/30 (CO-SPEVV-SB-C 0.2 sq x 10P)



### 3.3 Transceiver Unit

A power cable and a 4 pair cable (transducer line) run between the transceiver unit and the display unit. They are outfitted with a connector and crimp-on lugs; but you need to ground the armor and fabricate the other end of the cable for connection to the junction box.

- 1) Power cable DPYC-2.0 (max. 25 m) or DPYC-3.5 (max. 50 m)  
(DPYC-xx is the Japan Industrial Standard cable. Refer to page 3-12.)




Fig. 3-4

- 2) 4 pair cable (66S1067, transducer line)

**CAUTION**

Carefully connect the wires to respective terminals, referring to the illustrations (next page) and the interconnection diagram (page S-1). Wrong connection can damage the transducer, thermal sensor and the JTX board.




Fig. 3-5

Cabling of 66S1067 inside of the unit




Fig. 3-6

3) Two cables run between the display unit and the transceiver unit.

The transceiver unit "end" of the cables is fitted with a connector and crimp-on lugs; however, you will need to fabricate the armor. See the previous section to fabricate the armor.

### 3.4 Junction Box

The transducer cable is connected to the junction box with an extension cable. After making the connection, seal the cable gland with putty for watertightness.

1) Transducer cable 66S1066 (without armor)




Fig. 3-7

2) 4 pair cable 66S1067 (extension cable, with armor)

Attach crimp-on lugs in the same manner as shown above. Fabricate the armor as follows.




Fig. 3-8




Fig. 3-9 Junction Box Inside View

## 3.5 External Equipment

### 3.5.1. Connection of external equipment to the display unit

A trumpet speaker and/or buzzer can be connected to the display unit for an external alarm. The trumpet speaker (4 Ω, max output level 800mW) is connected directly to pins A and B of connector J33. Contact closure signal for alarm is output from pins C and D of J33. Speaker volume is adjustable by R28 on the ICP board.





Fig. 3-10

### 3.5.2. Connection of external equipment to the transceiver unit



\*Cable clamp can be fitted in any direction.

Fig. 3-11 Cable Entries for External Equipment

#### 1) Signal cables for external KP and 200p/nm (CO-SPEVV-SB-C 0.2sq × 2p)

- Process the anticorrosive sheath and armor as shown below:

##### a. For external KP signal




Fig. 3-12

##### b. For 200p/nm signal




Fig. 3-13

● Fabrication of cores, shield and armor




Fig. 3-14

● Fixing the cable




Fig. 3-15

2) Fabrication of the signal cables for gyro signal and true bearing (CO-SPEVV-SB-C 0.2sq × 5p)

- Process the anticorrosive sheath and armor as follows. Fabricate the cable in the same manner as above.

a) For gyro signal




Fig. 3-16

b) For true bearing signal




Fig. 3-17

3) Signal cable for CIF data (CO-SPEVV-SB-C 0.2sq × 5p)




Fig. 3-18

4) Signal cable for NMEA data (CO-SPEVV-SB-C 0.2sq × 5p)





Fig. 3-19

5) Signal cable for distance indicator (TTYCY-2S)

- TTYCY-2S is Japan Industrial Standard (JIS) cable. Fabricate the cable as follows.



TTYCY-2S CABLE COMPOSITION




Fig. 3-20

### 3.6 DC-AC Inverter (TR-2450 or CSH-5050)

The cable connected between the ship's mains and the DC-AC inverter, and the transceiver unit and DC-AC inverter should meet the following requirements:

Connection	Distance between units	Cable to use
ship's mains ← DC-AC Inverter	less than 10 m	660V-DPYC-8
	more than 10 m	larger diameter than above
transceiver unit ← DC-AC Inverter	less than 25 m	DPYC-2.0
	more than 25 m	DPYC-3.5

*Note: For remote control of the DC-AC inverter, install a remote switch near the display unit and use cable type DPYC-1.25 for the connection between the remote switch and the DC-AC inverter.*

- DPYC-xx is the Japan Industrial Standard (JIS) cable. The conductor composition of these cables is as follows. If necessary, use equivalent cables.

Table 3-1 Conductor Composition

Cable Type	Nominal cross sectional area	Number of wires	Diameter of wire
660V-DPYC-8	8 m <sup>2</sup>	7	1.2 mm
250V-DPYC-3.5	3.5 m <sup>2</sup>	7	0.8 mm
250V-DPYC-2.0	2.0 m <sup>2</sup>	7	0.6 mm
250V-DPYC-1.25	1.25 mm <sup>2</sup>	7	0.45 mm

1) Fabrication of cable




Fig. 3-21

2) Connection

TR-2450





Fig. 3-22



- Note**
1. The remote terminals are connected parallel to the POWER switch of the unit. To turn the unit on/off by a remote switch, set the POWER switch to OFF.
  2. The unit is set at the factory for operation from 24 VDC mains. For 32 VDC, change transformer tap connection and adjust potentiometer setting for required output voltage. For further information, see the installation instructions attached to the unit.

Fig. 3-23

### 3.7 Matching Box

The transducer cable is relayed at the matching box to connect with the transceiver unit.

- 1) Transducer cable (coaxial cable).




Fig.3-24 Fabrication of coaxial cable

- 2) 4 pair cable 66S1067 (with armor)  
Attach crimp-on lugs. Fabricate the armor as bellows.




Fig. 3-25 Fabrication of 66S1067




Fig. 3-26 Junction box inside view

# CHAPTER 4 POST-INSTALLATION CHECK AND ADJUSTMENT

## 4.1 Line Voltage

### 1) Transceiver Unit

1. Turn the power switch on. Confirm that the POWER lamp lights and there is input voltage at the service outlet. Also confirm that 100 VAC is present between terminals # 10 and #11 of TB5.




Fig. 4-1 Transceiver Unit, Inside view

- Turn the power switch of the display unit on. Confirm that the power lamp (green) on the transceiver unit (see below) lights. Make sure the maintenance switch is off; then confirm the voltage at the following points.

PCB	Check Point	Rating	Adjustment Point
JPW 66P3220	CR8	Light (- 12V)	-
	TP1 (+) TP9 (-)	- 12.2V ± 0.1V	-
	TP2 (+) TP9 (-)	2.5V ± 15%	R10




Fig. 4-2

2) Display Unit

1. Turn on the power switch of the transceiver unit. Confirm that CR2 (green LED) on the IRE board 66P3202 lights.




Fig. 4-3 Check Lamps inside the Display Unit

2. Press the power switch on the front panel of the display unit. Confirm that the cooling fan rotates and CR1 (+5V), CR2 (+12V) and CR3 (-12) LEDs light.

Check point for the line voltages on ICP board	{	TP1: 0V
		TP2: + 5V
		TP3: +12V
		TP4: - 12V

## 4.2 LED Status Check

Note: Some LEDs have been deleted.

### 1) Transceiver Unit





Fig. 4-4 Location of parts inside the Transceiver Unit

#### a) JCN Board 66P3221



LED		Status	Remarks
No.	Signal		
CR1	LOG 200	◐	Brinks with ship's speed.
CR2	AUT-P	●	Normally OFF. Lights when ship's speed alarm sounds. After turning on the power, it lights until log pulse is output.
CR3	LOG IN	◐	Normally OFF. Blinks when external log signal is input.

Color of LED: orange


- : Lit
- ◐ : Blinking
- : Off

b. JIFA Board 66P3800


LED Location	LED		Status	Remarks
	No.	Signal		
	CR1	PASS	○ (GRN)	Lights when self-check of this board is OK.
	CR2	HALT	◐	Blinks with Halt command of CPU.
	CR3	DT1	○	Not used.
	CR4	TX1	◐	For factory check (Blinks once in every three seconds.)
	CR5	RX1	●	For factory check (Normally off).
	CR6	DS1	●	Not used.
	CR7	TXS	◐	Blinks or lights with transmission of echo data.
	CR8	CKS	◐	Blinks every 15 sec. with transmission of echo data clock.
	CR9	AUTX	◐	Blinks with output data from AUX port.
	CR10	AUTR	◐	Blinks with input data to AUX port.
	CR11	CIFT	◐	Blinks with output data from CIF port. (3 second interval)
	CR12	CIFR	◐	Blinks with input data to CIF port.
	CR13	NMET	◐	Blinks with output data from NMEA port. (3 second interval)
	CR14	NMER	●	Blinks with input data to NMEA port.
	CR15	GYRC	◐	Blinks with clock input from AD-10S.
	CR16	GYRD	◐ (GRN)	Blinks with gyro data input from AD-Converter. (looks lit)
	CR17	RELC	◐	Blinks with clock output of true bearing.
	CR18	RELD	◐ (GRN)	Blinks with data output of true bearing. (CR17 and CR18 synchronizes)
	CR19	LOG2	◐	Blinks with output of 200p/nm signal. (Synchronized with relay chatter)
	CR20	LOG1	◐	Blinks with external log pulse input.
	CR21	EXP1	(◐)	Blinks with external KP signal 1 input.
	CR22	EXP2	(◐)	Blinks with external KP signal 2 input.
	CR23	DPCS	◐	Blinks with internal signal.

Color of LED is orange unless noted otherwise.


c. JCP Board 66P3205

LED Location	LED		Status	Remarks
	No.	Signal		
	CR28	TXD	●	Blinks irregularly with data output to display unit.
	CR29	RXD	●	Blinks irregularly with data input from display unit.
	CR2	KP	●	Blinks with transmission KP output.
	CR3	ADKP (EST)	●	Blinks with echo level data transmission to display unit. (Lights once in every 15 sec.)
	CR4	EG	●	Blinks with echo gate. Synchronizes with KP.
	CR5	EXKP1	●	Blinks with external KP input.
	CR6	PASS1	○ (GRN)	Lights when self-check of this board is OK.

d. JFT board

LED Location	LED		Status	Remarks
	No.	Signal		
	CR1	RUN	●	Blinks irregularly at normal operation.
	CR2	PASS	○ (GRN)	Lights when self-check of this board is OK.
	CR3	TASK1	●	Some of these LEDs blink when the equipment is working normally.
	CR4	TASK2	●	
	CR5	TASK3	●	
	CR6	TASK4	●	
	CR7	TASK5	●	
	CR8	TASK6	●	
	CR9	TASK7	●	
	CR10	TASK8	●	

e. JTX Board 66P3209

LED Location	LED		Status	Remarks
	No.	Signal		
	CR2	BEAM1	◐	Blinks with transmission.  Lights when transmitter high voltage is applied.  Blinks with transmission. CR2, CR4 and CR7 synchronizes with KP (CR2 of JCP board).
	CR4	BEAM2	◐	
	CR5	+ B	○	
	CR7	BEAM3	◐	

2) Display Unit




Fig. 4-6

LED		Status	Remarks
No.	Signal		
CR1	+5V	○ (GRN)	Lights when line voltages are normal.
CR2	+12V	○ (GRN)	
CR3	-12V	○ (GRN)	
CR4	D0	◐	Blinks randomly. (Task status of CPU is displayed.)
CR5	D2	◐	
CR6	D4	◐	
CR7	D6	◐	
CR8	D8	◐	
CR9	D10	◐	
CR10	D12	◐	
CR11	D14	◐	
CR13	D1	◐	
CR14	D3	◐	
CR15	D5	◐	
CR16	D7	◐	
CR17	D9	◐	
CR18	D11	◐	
CR19	D13	◐	
CR20	D15	◐	
CR22	TXD	◐	Blinks irregularly with data output to transceiver unit.
CR23	RXD	◐	Blinks irregularly with data input from transceiver unit.
CR27	EDA	◐	Blinks with receive echo data from transceiver unit.
CR28	ECK	◐	Blinks with clock of receive echo data from transceiver unit.
CR29	EST	◐	Blinks with echo start signal. (CR27, 28 and 29: once every 15 seconds)
CR30	INT	◐	Blinks with interrupt signal to CPU.
CR34	STD.P	◐	Blinks with 1 second clock of internal timer.
CR38	RESET	● (RED)	Normally OFF. Just after the power is turned on or off, it lights momentarily (lights with reset signal of CPU).
CR42	HALT	◐	Blinks with halt command of CPU. (Looks OFF)

## 4.3 DIP Switch Setting

### 1) Transceiver Unit




Fig. 4-7 Location of DIP Switches

**DIP switch settings on each board**

PCB	Symbol No.	Factory Setting			Functions																					
		NO.	ON	OFF																						
JIFA 66P3800	S1	1		<input type="radio"/>	NMEA OFF: Ver. 2.0 (With check sum at last output data) ON: Ver. 1.5 (Without check sum)																					
		2		<input type="radio"/>	No use																					
		3		<input type="radio"/>	Log pulse out OFF: Forward only ON: Forward and Backward																					
		4		<input type="radio"/>	No use																					
		5		<input type="radio"/>	CH-35H: Receive data format for AUX port (Effective when S2-1/2 are set to ON.)																					
		6		<input type="radio"/>		CH-35: No use																				
		<table border="1"> <tr> <td>5</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>6</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>Data</td> <td>under</td> <td>DAT3</td> <td>DAT2</td> <td>DAT1</td> </tr> <tr> <td></td> <td>fined</td> <td></td> <td></td> <td></td> </tr> </table>					5	OFF	ON	OFF	ON	6	OFF	OFF	ON	ON	Data	under	DAT3	DAT2	DAT1		fined			
		5	OFF	ON	OFF	ON																				
	6	OFF	OFF	ON	ON																					
	Data	under	DAT3	DAT2	DAT1																					
		fined																								
	DAT1: TKC (<CR>DDDdd) DAT2: TKC (DDDd*<LF>) DAT3: Hokushin (\$HERHRC, DDDdd, +/-RRr*cs)																									
	7		<input type="radio"/>	Depth data format OFF: CIF, ON: NMEA																						
	8		<input type="radio"/>	Temperature data format OFF: CIF, ON: NMEA																						
	S2	Bearing data format																								
		1		<input type="radio"/>	<table border="1"> <tr> <td>1</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>2</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>Sensor</td> <td>ADC</td> <td>CIF</td> <td>NMEA</td> <td>AUX</td> </tr> </table>		1	OFF	ON	OFF	ON	2	OFF	OFF	ON	ON	Sensor	ADC	CIF	NMEA	AUX					
1		OFF	ON	OFF	ON																					
2		OFF	OFF	ON	ON																					
Sensor		ADC	CIF	NMEA	AUX																					
2			<input type="radio"/>	ACD: AD converter (Furuno clocked-serial)																						
3			<input type="radio"/>	Log pulse measurement layer OFF: Reference layer, ON: 1 <sup>st</sup> layer																						
4		<input type="radio"/>		Set to ON when S #3 is off.																						
5		<input type="radio"/>	Bearing output at slow speed (less than 0.5 kts) OFF: True bearing, ON: Heading																							
6		<input type="radio"/>	Bearing output data OFF: True bearing, ON: Heading																							
7		<input type="radio"/>	Signal level of AUX port OFF: Current loop, ON: RS-232C																							
8		<input type="radio"/>	CIF data ON/OFF OFF: Standard, ON: Option																							

PCB	Symbol No.	Factory Setting			Function															
		No.	ON	OFF																
JIFA 66P3800	S3.	1		<input type="radio"/>	CIF data output OFF: Data created by CI-35/35H only ON: CI-35/35H data combined with incoming CIF data (through-line)															
		2		<input type="radio"/>	Analog indicator OFF: for 30 kt range scale indicator ON: For 40 kt range scale indicator															
		3		<input type="radio"/>	Interference rejection by KP1 OFF: OFF ON: ON															
		4		<input type="radio"/>	Interference rejection by KP2 OFF: ON: ON															
		5		<input type="radio"/>	Synchronous transmission with KP1 input (available with #3 ON) OFF: OFF ON: ON															
		6		<input type="radio"/>	Inclinometer ON/OFF OFF: OFF ON: ON															
		7		<input type="radio"/>	Bearing sensor OFF: Yes ON: No (always HU)															
		8		<input type="radio"/>	CH-35: No use   CH-35H: NMEA port ON/OFF: OFF; OFF, ON; NMEA 0183 ON															
JCP 66P3205	S5	1		<input type="radio"/>	Selection of bottom tracking reference beam															
		2		<input type="radio"/>	<table border="1"> <tr> <td>1</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>2</td> <td>OFF</td> <td>OFF</td> <td>ON</td> <td>ON</td> </tr> <tr> <td>Beam</td> <td>Beam 1</td> <td>Beam 2</td> <td>Beam 3</td> <td>All</td> </tr> </table>	1	OFF	ON	OFF	ON	2	OFF	OFF	ON	ON	Beam	Beam 1	Beam 2	Beam 3	All
		1	OFF	ON	OFF	ON														
		2	OFF	OFF	ON	ON														
		Beam	Beam 1	Beam 2	Beam 3	All														
		3		<input type="radio"/>	Transmission output OFF: Level 2 (normal) ON: Level 1 (reduced)															
		4		<input type="radio"/>	TX repetition rate & pulse width in water tracking mode OFF: Fast rate/narrow pulse (Standard) ON: Slow rate/wide pulse (Deep)															
		5		<input type="radio"/>	Automatic compensation of sound velocity by thermal sensor OFF: Yes ON: No															
6		<input type="radio"/>	Smoothing response for current indication OFF: Slow (standard) ON: Fast (less stable)																	
7		<input type="radio"/>	Smoothing response for current indication in nav-aided mode (*Effective on CI-35/35H only) OFF: Fast (standard) ON: Slow (high stability)																	
8		<input type="radio"/>	Validity of GPS data when ship's speed is almost 0 kt. OFF: Valid ON: Invalid (reject)*																	

PCB	Symbol No.	Factory Setting			Functions
		No.	ON	OFF	
JCP 66P3205D	S6	1	<input type="radio"/>	<input type="radio"/>	Menu 4 screen presentation OFF: No (CI-35), ON: Yes (CI-35H)
		2		<input type="radio"/>	No function assigned (Keep these switches OFF.)
		3		<input type="radio"/>	
		4		<input type="radio"/>	
		5		<input type="radio"/>	
		6		<input type="radio"/>	
		7		<input type="radio"/>	
		8		<input type="radio"/>	
	S7 Rotary Switch	0			
	S1	0			TVG curve selection 0: For water temperature 12°C 1: For water temperature 26°C
	S2				Normally 0 (Keep these switches at "0" positions.)
	S3				
S4					
JFT 66P3206B	S1	1		<input type="radio"/>	Factory use (All switches should be kept OFF for normal operation.)
		2		<input type="radio"/>	
		3		<input type="radio"/>	
		4		<input type="radio"/>	
		5		<input type="radio"/>	
		6		<input type="radio"/>	
		7		<input type="radio"/>	
		8		<input type="radio"/>	

2) Display Unit

ICP board 66P3200 (Right side of the display unit)




Fig. 4-8

PCB	Symbol No.	Factory Setting			Functions
		No.	ON	OFF	
ICP 66P3200	S1	1		<input type="radio"/>	Bearing indication method OFF: 32-point notation in large characters ON: Degree notation in large characters
		2		<input type="radio"/>	Unit of distance/range OFF: nm ON: km
		3		<input type="radio"/>	Current vector pointing direction OFF: Direction flowing to ON: Direction flowing from
		4		<input type="radio"/>	Manual heading input OFF: Disable ON: Enable
		5	<input type="radio"/>		Display language (See S2 descriptions below.) OFF: Japanese ON: Other than Japanese
		6		<input type="radio"/>	Panel check OFF: Normal operation ON: Test
		7		<input type="radio"/>	Black/white gradation test OFF: Normal operation ON: Test
		8		<input type="radio"/>	Color gradation test OFF: Normal operation ON: Test
	S2	1	<input type="radio"/>		English display (OFF: No ON: Yes)
		2		<input type="radio"/>	Norwegian display (OFF: No ON: Yes)
		3		<input type="radio"/>	Spanish display (OFF: No ON: Yes)
		4		<input type="radio"/>	French display (OFF: No ON: Yes)
		5		<input type="radio"/>	Reserved for future expansion
		6		<input type="radio"/>	
		7		<input type="radio"/>	
		8		<input type="radio"/>	

## 4.4 TX Output Check

To check the TX output waveforms, turn DIP switch S5-#4 on JCP board 66P3205 (See page 4-11) to ON and set the [TRACK MODE] key on the front panel to “water tracking mode”.

### Check Point of TX Output Waveforms

	Check Point	
	JTR Board TB3	Junction Box
Beam 1	Terminal 1 (H) 2 (C)	Terminal 1 (H) 2 (C)
Beam 2	4 (H) 5 (C)	4 (H) 5 (C)
Beam 3	7 (H) 8 (C)	7 (H) 8 (C)

(If possible, check at the junction box.)




Fig. 4-9

Confirm that the + B voltage at the Echo Check Screen is  $175 \pm 25$ . (This value is approximately 105 when DIP switch S5-#3 is ON (level 1). See page 4-11.)

## 4.5 External Noise and Interference Check

### 4.5.1 External Noise Check

Noise level can be measured (without transmission) at the echo check screen.

#### 1) Preparation

1. Remove the 10 A fuse in the power block of the transceiver unit. See Fig. 4-1.
2. Dismount the JTX board. See Fig. 4-1.
3. Execute the echo check on menu 2.
4. Turn TVG SET off by operating the [MODE] key.
5. Set the ECHO DEPTH at 700 m by operating the [↕]




Fig.4-10

#### 2) Check at mooring

1. Adjust the ECHO SHIFT RANGE by the [◀▶] knob, noting the ECHO SHIFT RANGE when the color of echograms change from blue to black.
2. This value should be 7 or higher at normal noise level. If the value is less than 7, noise is excessive.

### 3) Check at cruising

1. Continuing the echo check with the same value of ECHO SHIFT RANGE, change the ship's speed.
2. Observe the echogram. The echogram is presented in 16 color gradations and one level of gradation corresponds to twice the input level. The color depends on the input level as follows:

Black (lowest) → blue → light-blue → cyan → light-cyan → light-green → green → yellow-green → yellow → yellow-orange → orange → vermilion → red → reddish brown → brown → dark brown (highest)

3. Confirm that the noise levels are almost even on all three beams and pulse-like periodic noise does not appear.
4. If the color changes by more than 4 gradations than that at mooring, the noise level is excessive. In this case check the ground of each unit. (If the cruising noise is too heavy, you must consider the transducer relocation or reshaping.)

### 4.5.2 Interference Check

Perform this check where the depth is greater than 50 meters (preferably about 100 meters) and there are no other ships.

1. Turn off all ultrasonic wave generating equipment (echosounder, sonar, etc).
2. Operate the CI-35/35H in the ground tracking mode. Confirm that the indications of ship's speed and direction are reasonable.
3. Observing the display, turn on and operate the echo sounder and sonar one by one with its output power and pulse length set at the maximum. For the sonar, change the tilt and train angles.
4. If the display changes abnormally when some equipment is turned on and operated, that equipment is interfering with the CI-35/35H.
5. The interference can be removed by connecting the interfering equipment to the built-in interference rejector in the transceiver unit, as explained on the next page.

*Note: Use of the Interference Rejector reduces the response against the change of tidal speed.*

#### **How to check the level of an interfering signal**

1. Set the equipment as described in paragraph 4.5.1 1). Set the ECHO SHIFT RANGE to the value which the color of the echograms just change from blue to black.

2. At a depth greater than 50 meters, operate other equipment (echo sounder, sonar) one by one and observe the echogram on the echo check screen.
3. When there is interference, string-like echoes appear on the screen.




Fig. 4-11

### 4.5.3 Interference Rejection

Up to two interfering equipments can be connected to the interference rejection circuit in the transceiver unit. This circuit receives the keying pulse (KP) from the interfering equipment to reject interference.




Fig. 4-12

(1) Check of keying pulse

The following keying pulse is required from the interfering equipment.






Fig. 4-13 Keying pulse needed

If the level is out of the ratings or KP output circuit is not provided, take the measures shown on the next two pages to prevent equipment malfunction.

- Buffer circuit for positive going KP.



- Buffer circuit for negative-going KP.



The following method also is available.




Fig. 4-14 Buffer Circuit for Keying Pulse (KP)

## 2) Adjustment

1. Set DIP switch S3 on the JIFA board 66P3800 as follows:

- A. When a KP is connected to EX KP (1) of TB1, set S3-#3 ON.
- B. When a KP is connected to EX KP (2) of TB1, set S3-#4 ON.  
(Refer to the interconnection diagram on pages S-1 and 4-11.)

2. Adjust the potentiometer on the JCN 66P3801 as follows:

A. When KP is fed to EX KP1;

Turn R31 on the JCN board CW gradually until CR21 on the JIFA board starts flickering. Then, turn R31 CW by one more step.




Fig. 4-15 Adjustment of R31;

B. When KP is fed to EX KP2;

Adjust R32 until CR22 starts flickering. Then, turn R32 CW by one more step.

3. Enter the distance (0.1 m) between the transducer of the CI-35/35H and that of the interfering equipment at the menu 3 screen.

- A. For EX KP 1, set it at EX KP 1 of the menu 3 screen.
- B. For EX KP 2, set it at EX KP 2 of the menu 3 screen.

Then, when the receive time of the transmission pulse of the interfering equipment coincides with a measuring period of current, receive data of that period is ignored, thus avoiding interference.

Note: When transmitting with the external transmission pulse (KP) taken from an external device (echosounder, sonar, etc.), the repetition rate of the KP should be more than 500 ms. The repetition rate may become shorter than 500 ms when the range setting on the external device is less than 100 m. Therefore, set the range on the external device to more than 100 m.

## 4.6 Sea Trial Check

### 4.6.1 Ship's Speed Test


Do the milepost test where ground tracking measurement can be done.

1. Reset the distance run at the moment the milepost test is initiated.
2. Read the distance run at the moment the milepost test is completed.
3. Calculate true ship's speed from the data of the milepost test and ship's speed of the CI-35/35H from that of the distance run.
4. If the error is more than  $\pm (1\% + 0.1 \text{ kt})$ , correct it. Record the data in Table 1.
5. Repeat the milepost test several times, and confirm that the error is within  $\pm (1\% + 0.1 \text{ kt})$ .
6. Record the ship's speed every 10 seconds in table 2.
7. Calculate the average ship's speed from the data in the table 2 to compute unit accuracy.

### 4.6.2 Current Information Check

Confirm that current speed/direction display is uniform in all directions and does not change whatever the ship's heading. Use the ground tracking mode to record the data.

- \* Before beginning this test, set TIDE AVERAGE to 2 minutes and TIDE HISTORY to 15 seconds at menu 1.
  - \* At sea trial, the ship's draft is shallow due to no "load," so air bubbles may affect equipment performance.
1. Run your boat at a speed around 12 kts, following square course shown below. Each side of the square is about 1 mile in length. It should take about 5 minutes to cover one side of the course. After completing a side of the course, turn, wait for course to stabilize, then run straight for five minutes.




Ship's route:  
Advance straight 1 mile approx.

Fig. 4-16

2. Record the ship's speed and tide data every 30 seconds in table 3. As a general rule, set the Mode to North Up. Only when there is no gyro signal should the data be recorded using the Heading Up Mode. If a wind meter is available, record the speed and direction of the wind.
3. On a separate of paper, plot the current speed and direction. Confirm the current reading is stable in any ship's heading.

Instead of plotting on paper, you may use the tide history function of CI-35/35H. Just after completion of test route, press the [HISTORY] key and observe the tide history. If it is working normally, the tide vectors should point almost constant direction.



1. When a "bearing sensor" is connected in lieu of a gyrocompass, accurate measurement of current direction is not expected because the bearing data itself is in error.
2. Because current speed/direction differ with season, sea area, and time of day, be sure to look at the entire data rather than just portions of it.

### 4.6.3 Course Calibration

The CI-35/35H has the nav-aided mode to measure absolute tides even in deep waters where ground tracking is unattainable. To achieve reliable measurements, however, you must supply accurate heading (gyro) information and ship's position (or speed/course) data to CI-35/35H. After installation, perform the course calibration to offset gyro data. (The calibration should be done by using ground tracking mode.)

1. Confirm that the gyrocompass has settled and all the necessary compensations (latitude compensation, weather compensation, etc.) are made correctly.
2. Manipulate the AD converter (gyro interface) to obtain the same reading as you read on the master gyrocompass. (Do not make adjustment while the ship is turning.)
3. Make sure the navaid (GPS) is working correctly and accurately.
4. Press the TRACKING MODE key to select "GT" (ground tracking) mode.
5. In Menu 4, set 'CRS CAL MODE" to "GT".
6. Run your boat at a speed around 10 kts, keeping the same direction. To minimize the effect of gyro speed error, it is preferable to run along parallels (i.e., eastward or westward).
7. In Menu 4, place the cursor on "START" (CRS CAL EXEC) and then press the EVENT key. As soon as you press the EVENT, "0.0" should appear in reverse text at the upper-right part of the display. After 2 mile-run, the display will show the course calibration angle in normal text.




Fig. 4-18

8. Perform the preceding Current Information check, using nav-aided mode, and confirm that current speed/direction display is uniform in all directions and does not change whatever the ship's heading.

Table 1 Ship's Speed Test

SHIP'S NAME \_\_\_\_\_ TEST SITE \_\_\_\_\_ SHIP'S LENGTH (m) \_\_\_\_\_ DRAFT \_\_\_\_\_ Fore \_\_\_\_\_ Aft \_\_\_\_\_ Mean \_\_\_\_\_ (m)

DATE	TIME	ENGINE OUTPUT		*1 MILEPOST		Current Indication			EM-LOG (kts)	DEPTH (m)	COURSE (Deg)	WIND (m/s)	SEA COND.	CURRENT (kts)	REMARKS
		RPM	TIME(s)	SPEED (kts)	*3 DIST. RUN (kts)	TIME(s)	*2 ERR. (%)								
AVG.															
AVG.															
AVG.															
AVG.															MEASURING MODE GROUND WATER
AVG.															

\*2 Error =  $\frac{\text{Speed measured by milepost} - \text{Current Indicator Speed}}{\text{Speed measured by milepost}} \times 100(\%)$

\*1 Milepost miles  
 \*3 Current Indicator Speed =  $\frac{\text{Mile (Milepost)}}{\text{Time (sec)}} \times 3600$

Table 2 Ship's Speed Test



TIME	SPD (kts)	REMARKS	TIME	SPD (kts)	REMARKS
00		SHIP'S NAME _____	00		SHIP'S NAME _____
10		DEPTH _____ (m)	10		DEPTH _____ (m)
20		TEST SITE _____	20		TEST SITE _____
30		WIND SPEED	30		WIND SPEED
40		△ _____ (m/s)	40		△ _____ (m/s)
50		COURSE _____	50		COURSE _____
00			00		
10			10		
20			20		
30			30		
40			40		
50			50		
00			00		
10			10		
20			20		
30			30		
40			40		
50			50		
00			00		
10			10		
20			20		
30			30		
40			40		
50			50		
00			00		
10			10		
20			20		
30			30		
40			40		
50			50		
00			00		

Table 3 Current Display Behavior Test


SHIP'S NAME \_\_\_\_\_ TEST DATE \_\_\_\_\_ TEST SITE \_\_\_\_\_ DEPTH \_\_\_\_\_  
 SETTING (m): LAYER 1 \_\_\_\_\_, LAYER 2 \_\_\_\_\_, LAYER 3 \_\_\_\_\_

No.	TIME	SHIP'S HDG. (deg.)	LAYER 1		LAYER 2		LAYER 3		SHIP'S SPD		WIND (Rel)		REMARKS (Depth, Sea conditions, etc.)
			DIR	SPD (kts)	DIR	SPD (kts)	DIR	SPD (kts)	F/A (kts)	L/R (kts)	DIR (deg)	SPD (m/s)	
1													
2													
3													
4													
5													
6													
7													
8													
9													
10													
1													
2													
3													
4													
5													
6													
7													
8													
9													
10													


A



B




取付寸法  
MOUNTING DIMENSION



上面図  
TOP VIEW

C




後面図  
REAR VIEW

\* : 推奨サービス空間  
RECOMMENDED SERVICE CLEARANCE

注 : 指定なき公差は1.5%  
TOLERANCE IS 1.5% UNLESS OTHERWISE SPECIFIED.

DRAWN	Jun. 27 '01	T.YAMASAKI	TITLE	CI-3500
CHECKED	Jun. 27 '01	Y.KIMURA	名称	指示器
APPROVED	Jun. 27 '01	Y.KIMURA		外寸図
SCALE	1/8	MASS 20±1 kg	NAME	DISPIAY UNIT
DWG.No.	C7242-G01-C			OUTLINE DRAWING



品番 ITEM	品名 NAME	材質 MATERIAL	数量 QTY	図番 DWG. NO.	備考 REMARKS
DRAWN Jun. 27 '01 T.YAMASAKI				TITLE CT-3510	
CHECKED Jun. 27 '01 Y.KIMURA				名称 送受信演算部	
APPROVED Jun. 27 '01 Y.KIMURA				外寸図	
SCALE 1/5	MASS 32 $\pm$ 1 kg			NAME TRANSCEIVER UNIT	
DWG.No. C7242-G02-C				OUTLINE DRAWING	




表 1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
0 < L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3

注記 指定なき寸法公差は表1による。

NOTE TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.

DRAWN Apr. 17 '00 T. YAMASAKI		TITLE CI-630
CHECKED Apr. 17 '00 Y. K.	DS-50	名称 接続箱
APPROVED Apr. 17 '00 Y. K.	CI-80	外寸図
SCALE 1/2	MASS ±10% 2 kg	NAME JUNCTION BOX
DWG. No. C7228-G03-D		OUTLINE DRAWING





表 1 TABLE 1

注記  
指定なき寸法公差は表 1 による。

NOTE  
TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.


寸法区分(mm) DIMENSION	公差(mm) TOLERANCE
$L \leq 120$	$\pm 3.0$
$120 < L \leq 250$	$\pm 3.5$
$250 < L \leq 400$	$\pm 4.5$
$250 < L \leq 400$	$\pm 5.5$

DRAWN May 30 '02 I.YAMASAKI	TITLE CI-3540
CHECKED May 30 '02 Y.KIMURA	名称 マッチングボックス
APPROVED May 30 '02 Y.Kimura	外寸図
SCALE 1/2	NAME MATCHING BOX
MASS 3.3 kg	OUTLINE DRAWING
DWG.No. C7242-G07-C	66-025-5000-G1



要目表 PRINCIPAL ITEMS		
位置 POSITION	船首から FROM BOW	m
	キールから FROM KEEL	mm
突出量H PROJECTION		mm
取付状態 FIXING CONDITION	走行時水平 HORIZONTAL AT RUNNING	
保護タンク PROTECTION TANK		

注：指定なき公差は1.5%  
TOLERANCE IS 1.5% UNLESS OTHERWISE SPECIFIED.




品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG. NO.	摘要 REMARKS
20	六角ナット HEX. NUT		4	M12	▲
19	バネ座金 SPRING WASHER		4	M12	
18	六角ボルト HEX. BOLT		4	M12×40~50	
17	パッキン GASKET		1		
16	呼び圧力5k差込溶接式フランジ 呼び径φ9	SS41	1	JISB2220	造船所手配 SHIPYARD SUPPLY
15	送受波器 TRANSDUCER		1	標準10mケーブル付 ID: W/10m CABLE	▲
14	六角ボルト HEX. BOLT	SUS304	4	M12×25	
13	六角ボルト HEX. BOLT	SUS304	2	M8×40	
12	バネ座金 SPRING WASHER	SUS304	2	M8	
11	六角ボルト HEX. BOLT	SUS304	5	M12×40	
10	防錆亜鉛 ZINC BLOCK	ZAP	1	B-1 1/2	
9	平ワッシャー FLAT WASHER	ジエラック RESIN	4	T-201-11	
8	平座金 FLAT WASHER	SUS304	4	M12	
7	バネ座金 SPRING WASHER	SUS304	9	M12	
6	六角ナット HEX. NUT	SUS304	8	M12	
5	電線貫通金物 THRU-HULL PIPE	SS400	1	CI-620-K-S	
4	スペーサ SPACER	SGP	4	66-017-1204	
3	押え板 FIXING PLATE	SGP	2	66-017-1203	
2	送受波器取付フランジ FIXING FLANGE	SGP	1	66-017-1202	
1	送受波器ケース CASING	SS41	1	66-017-1201	古野手配 MAKER SUPPLY

- 注
- ※：造船所支給
  - 送受波器ケースはθ（船底傾斜角）に合わせて切断してください。
  - 切断・溶接の際は、歪防止のため送受波器を取り外した状態で“送受波器取付フランジ”を必ず取り付けておいてください。
  - ※※：船尾側上端に通水孔（φ10～φ20程度）を開けてください。
  - 電線貫通金物はフレーム等の邪魔にならない所で送受波器に当らず、キャップナットが容易に締付けられる位置に取付けてください。
  - 網除け、保護タンクは必要に応じて造船所にて製作して下さい。
  - 送受波器面は塗装しないように注意してください。
  - 送受波器ケース取付の際には船首、船尾の確認をしてください。
  - 質量は古野手配のみで、タンク高さ450の場合を示す。

- NOTE
- ※：SHIPYARD SUPPLY.
  - CUT CASING FORθ (RISING ANGLE OF SHIP'S HULL.)
  - TO AVOID DISTORTION BY HEAT, PUT "FIXING FLANGE" (WITHOUT TRANSDUCER) ONTO CASING WHILE CUTTING AND/OR WELDING.
  - ※※：MAKE A HOLE OF 10 TO 20MM IN DIA. ON STERN SIDE TO ALLOW WATER TO PENETRATE.
  - ALLOW ENOUGH CLEARANCE AROUND THRU-HULL PIPE FOR EASY TIGHTENING AND SERVICING.
  - IF NECESSARY, HAVE SHIPYARD PROVIDE NET PROTECTOR AND PROTECTION TANK.
  - DO NOT PAINT TRANSDUCER FACE.
  - CONFIRM FORWARD DIRECTION OF TRANSDUCER.
  - STEEL WELDING PIPE FLANGE: JIS B 2220-5K-10-SS41

承認 APPROVED	APR. 24. '90 T. WAKANO	三角法 THIRD ANGLE PROJECTION	名称 TITLE	CI-620-T-S 送受波器装備図 (鋼船) TRANSDUCER INSTALLATION (STEEL HULL)
検図 CHECKED	APR. 23. '90 M. IKEDA	尺度 SCALE	1/5	
製図 DRAWN	APR. 23. '90 TAKAHASHI	質量 MASS	94 kg	図番 DWG. NO. C7228-T02-F



18	GASKET	RUBBER	1	TPB-1003
17	WASHER	SS41	1	TPB-1002-1

PRINCIPAL ITEM		
POSITION	FROM BOW	m
	FROM KEEL	mm
PROJECTION		mm
FIXING CONDITION		HORIZONTAL AT RUNNING
PROTECTION TANK		


16	FIXING NUT	SS400	1	TPB-1-03	
15	LOCK NUT	SS400	2	TPB-1-04	
14	CAP NUT	SS400	1	66-017-1506-1	
13	FLAT WASHER	PC	4		
12	FLAT WASHER	RESIN	4		
11	HEX. BOLT	SUS304	4		M12x25
10	TRANSDUCER		1		STD: WITH 10m CABLE
9	ZINC BLOCK		1		
8	FLAT WASHER	SUS304	8		
7	FIXING PLATE	SS400	1		
6	HEX. NUT	SUS304	8		M12
5	THRU-HULL PIPE	BC2	1	66-017-1501-0	
4	SPRING WASHER	BC2	8		M12
3	HEX. BOLT	SUS304	4		M12x40
2	FIXING FLANGE	SS400	1		
1	CASING	FRP	1		

品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG.NO.	摘要 REMARKS
------------	------------	----------------	------------	---------------	---------------

**NOTE**

- DECIDE PRINCIPAL ITEMS UPON DISCUSSING WITH SHIP'S OWNER OR SHIPYARD.
- CUT CASING FOR  $\theta$  (RING ANGLE OF SHIP'S HULL).
- ALLOW ENOUGH CLEARANCE AROUND THRU-HULL PIPE FOR EASY TIGHTENING AND SERVICING.
- FRP MOLD THRU-HULL PIPE ON BOTH SIDES OF HULL PLATE.
- DO NOT PAINT TRANSDUCER FACE.
- FRP MOLD INSIDE OF CASING.
- BEFORE FIXING CASING TO HULL PLATE, FIRST CLEAN HULL PLATE SURFACE WITH A SANDER UNTIL FIBER GLASS APPEARS ON FACE, THEN REMOVE DUSTS, OILS AND SO ON FROM SURFACE.
- \* MAKE A HOLE OF 10 TO 20MM DIA. ON STERN SIDE TO ALLOW WATER TO PENETRATE.

承認 APPROVED	APR. 24. '90 T. NAKANO	三角法 THIRD ANGLE PROJECTION	名称 TITLE	CI-620-T-F TRANSDUCER INSTALLATION (FOR FRP)
検図 CHECKED	APR. 23. '90 M. IKEDA	尺度 SCALE	1/5	
製図 DRAWN	APR. 23. '90 TAKAHASHI	重量 WEIGHT	41 kg	図番 DWG.NO. E7228-T01-B



16	平座金	FLAT WASHER	ジュラコン RESIN	12	T-201-11
15	六角ボルト	HEX. BOLT	"	12	M12 x 35
14	バネ座金	SPRING WASHER	"	12	FOR M12用
13	六角ナット	HEX NUT	"	24	M12 class 2
12	平座金	FLAT WASHER	SUS304	12	FOR M12用
11	防水ゴム	GASKET	CR	3	" -1104
10	押えリング	LINER	"	6	" -1103
9	締付用70ナット	CAP NUT	SUS304	3	" -1102
8	貫通金物胴体	THRU-HULL PIPE	"	1	" -1101
7	" (3)	FIXING FLANGE (3)	"	1	" -1030
6	" (2)	FIXING FLANGE (2)	"	1	" -1020
5	取付板 (1)	FIXING FLANGE (1)	"	1	" -1010
4	押え板	FIXING PLATE	"	3	" -1006-△
3	送受波器ケース	CASING	SS41	1	66-004-1000
2	ケーブル	CABLE	"	3	"
1	送受波器	TRANSDUCER	"	3	130KHZ
品番	品名	材質	数量	図番	摘要
ITEM	NAME	MATERIAL	Q'TY	DWG.NO.	REMARKS

\*1 船底補強板及び網除けは造船所手配。  
 (\*a, \*b, 板厚)は造船所で決定して下さい。  
 \*2 C面は走航時水平となること。  
 \*3 送受波器ケースは船首船尾方向に対して±1°  
 以内の誤差で取り付けること。


\*1. DOUBLING PLATE AND NET-PROTECTOR SHOULD BE  
 INSTALLED BY SHIPYARD (DIMENSIONS SHOULD BE  
 DECIDED BY SHIPYARD).  
 \*2. INSTALL THE CASING SO THAT THE SURFACE C  
 BECOMES HORIZONTAL AT NORMAL TRIM.  
 \*3. ERROR IN FORE-AFT DIRECTION SHOULD BE WITHIN ±1°.

承認	JUL. 20. 78	三角法	名称
APPROVED		THIRD ANGLE PROJECTION	TITLE
検図	MAY. 19. 78	尺度	CI-241
CHECKED		SCALE	1/6
製図	MAY. 19. 78	重量	140 kg
DRAWN		重量	140 kg
		図番	C7215-007-G
		DWG.NO.	C7215-007-G

NOTE

1. DECIDE PRINCIPAL ITEMS UPON DISCUSSING WITH SHIP'S OWNER OR SHIPYARD.
2. CUT CASING FOR 0 (RISING ANGLE OF SHIP'S HULL).
3. ALLOW ENOUGH CLEARANCE AROUND THRU-HULL PIPE FOR EASY TIGHTENING AND SERVICING.
4. FRP MOLD THRU-HULL PIPE ON BOTH SIDES OF HULL PLATE.
5. DO NOT PAINT TRANSDUCER FACE.
6. FRP MOLD INSIDE OF CASING.

PRINCIPAL ITEM		
POSITION	FROM BOW	m
	FROM KEEL	mm
PROJECTING		mm
FIXING CONDITION		HORIZONTAL AT RUNNING
PROTECTION TANK		




19	HEX. NUT	SUS304	24		
18	FLAT WASHER	SUS304	12		
17	WASHER	RESIN	12		
16	SPRING WASHER	SUS304	24		
15	HEX. BOLT	SUS304	12		
14	GASKET	CR	3	66-004-1104-0	
13	LINER	SUS304	6	66-004-1103-0	
12	CAP NUT	SUS304	3	66-004-1102-0	
11	PACKING	CR	1	66-910-0100	
10	WASHER	SS41	1	66-910-0099	
9	NUT	SS41	2	66-910-0098	
8	THRU-HULL PIPE	SS41	1	66-910-0097	
7	THRU-HULL PIPE	SS41	1	CI-241F-2	
6	FIXING FLANGE (3)	SS41	1	66-910-0103	
5	FIXING FLANGE (2)	SS41	1	66-910-0102	
4	FIXING FLANGE (1)	SS41	1	66-910-0101	
3	FIXING PLATE	SS41	3	66-910-0104	
2	CASING	FRP	1	66-910-0067	
1	TRANSDUCER		3	130kHz WITH 11m CABLE	
品番 ITEM	品名 NAME	材質 MATERIAL	数量 QTY	図番 DWG. NO.	備考 REMARKS

7. BEFORE FIXING CASING TO HULL PLATE, FIRST CLEAN HULL PLATE SURFACE WITH A SANDER UNTIL FIBER GLASS APPEARS ON FACE, THEN REMOVE DUSTS, OILS AND SO ON FROM SURFACE.

承認 APPROVED	<i>S. Takano</i>	三角法 THIRD ANGLE PROJECTION	名称 TITLE	TRANSUCER INSTALLATION (FOR FRP)
検閲 CHECKED	<i>S. Suda</i>	尺度 SCALE	TYPE	CI-241F
製図 DRAWN	<i>K. Takano</i>	重量 WEIGHT	図番 DWG. NO.	E7215-033-B





注：指定なき公差は1.5%


TOLERANCE IS 1.5% UNLESS OTHERWISE SPECIFIED.

- CI-3520-1 : 10mケーブル付 WITH 10m CABLE (22kg)
- CI-3520-2 : 20mケーブル付 WITH 20m CABLE (27kg)

DRAWN Aug 2 '96 K. Kusunoki				TYPE CI-3520
CHECKED Aug 2 '96 Y. Kimura				名称 送受波器
APPROVED Aug 2 '96 K. Ota		CI-35H		外寸図
SCALE 1/5	MASS kg	APPLICABLE TO; (MODEL)	BLOCK NO.	NAME TRANSDUCER
DWG NO. C7242-G03-C				OUTLINE DRAWING

**FURUNO**

**FURUNO ELECTRIC CO., LTD.**



寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
0 < L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3

表 1  
TABLE 1

注記

1) 指定なき寸法公差は表 1 による。

NOTE


1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS.

ケーブル長さ CABLE LENGTH (m)	質量 MASS (kg)
10	8.2
20	10.4
30	12.6


品番 ITEM	品名 NAME	材質 MATERIAL	数量 QTY	図番 DNG. NO.	備 REMARKS
7	六角ナット HEX NUT	SUS304	1	M3	
6	スパナワッシャー SPANNER WASHER	SUS304	1	M3	
5	平頭ネジ PANHEAD SCREW	SUS304	1	M3x8	
4	ジョイントクリップ JOINT CLIP	SUS304	1		
3	ケーブルリング CABLE RING	SUS304	1	66-004-0001	
2	ケーブル CABLE	CR	1	WSG-75045	
1	送受波器 TRANSDUCER		1		

DRAWN	品名	数量	図番	備
OKAZAKI TRAYASAKI	送受波器	1	C1-240	
CHOKKI TRAYASAKI	送受波器	1		
APPROVED	外寸図			
SCALE	NAME	TRANSDUCER		
1/3	MASS	kg		
C7215-G01-B	DWG. No.			




VENT HOLE  
 排風孔



No.	PART
1	INPUT/OUTPUT TERMINAL
2	BREAKER
3	RESET BUTTON
4	LED (POWER)
5	VOLTAGE METER
6	OUTPUT VOLTAGE ADJUSTER
7	FUSE (FOR OUTPUT)
8	TERMINAL COVER


番号	部品名称
1	入出力端子板
2	入力用ブレーカ兼用スイッチ
3	過電圧防止用リセットスイッチ
4	入力表示灯 (発光ダイオード)
5	出力電圧計
6	出力電圧調整用ボリューム
7	出力用ヒューズ
8	端子カバー

DRAWN July 19 '95 J. YamaSaka				TYPE TR-2450	
CHECKED July 19 '95 Maki				名称 DC-ACインバータ	
APPROVED July 19 '95 Okamoto				NAME DC-AC INVERTER	
SCALE 1/5	MASS 35 kg	APPLICABLE TO; (MODEL)	BLOCK NO.	DWG NO. C2007-G01-B	



9	サーキットプロテクタ CIRCUIT BREAKER
8	入力端子 INPUT TERMINAL
7	出力端子 OUTPUT TERMINAL
6	スイッチ SWITCH
5	ボリューム POTENTIOMETER
4	交流電圧計 AC VOLTMMETER
3	端子カバー TERMINAL COVER
2	発光ダイオード LED
1	リモート端子 REMOTE TERMINAL

品番 ITEM	品名 NAME	材質 MATERIAL	数量 QTY	図番 DWG. NO.	摘要 REMARKS
承認 APPROVED	JUN. 15. '90 T. NAKANO	三角法 THIRD ANGLE PROJECTION	名称 TITLE	DC/AC インバーター CSH-5050	
検 CHECKED	JUN. 12. '90 T. GODA	尺 SCALE		DC/AC INVERTER	
製 DRAWN	JUN. 12. '90 H. USUDA	重 WEIGHT	21 kg	図番 DWG. NO.	C1273 - G08 - A




00-2P : CO-SPEW-SB-C 0.2x2P, φ10.5  
 00-5P : CO-SPEW-SB-C 0.2x5P, φ13.5  
 00-10P : CO-SPEW-SB-C 0.2x10P, φ16.5

- 注記
- (\*)1 : 造船所支給。
  - (\*)2 : オプション支給。
  - (\*)3 : 出荷時コネクタプラグ接続済。
  - (\*)4 : 接続機器側が支給。
  - (\*)5 : コネクタクランプでアースに落とす。
  - (\*)6 : ケーブルクランプでアースに落とす。
  - (\*)7 : 分配器 (DS-370) 接続時は、4系統接続すること。
  - (\*)8 : a+b ≤ 50m

- NOTE
- (\*)1 : SHIPYARD SUPPLY.
  - (\*)2 : OPTION
  - (\*)3 : CONNECTOR PLUG FACTORY-FITTED.
  - (\*)4 : SUPPLIED BY EQUIPMENTS TO BE CONNECTED.
  - (\*)5 : GROUND THRU CONNECTOR CLAMP.
  - (\*)6 : GROUND THRU CABLE CLAMP.
  - (\*)7 : CONNECT DISTRIBUTION BOX DS-370 TO FOUR LOCATIONS WITH 4-PAIR TWISTED CABLE.
  - (\*)8 : a+b ≤ 50m


DRAWN June 7 '02 I. YAMASAKI	TITLE CI-35/35H
CHECKED Shige 7 '02 Y.K.	名称 音波ログ/カラー潮流観測装置
APPROVED June 7 '02 Y.K.	相互結線図
SCALE MASS kg	NAME DOPPLER SONAR CURRENT INDICATOR
DWG No. C7242-C01-E	INTERCONNECTION DIAGRAM



- 注記
- \* 1) 造船所手配。
  - \* 2) 分配器には任意の組合せで最大 7 枚の基板が組込み可能。
  - \* 3) 分配器 2 個を使用する場合は OTX 基板に接続。
  - \* 4) レンジ切換器は MF-22A の場合のみ必要。
  - \* 5) 2 台目の指示器は # 6 ~ # 8 に接続する。


- NOTE
- \*1. SHIPYARD SUPPLY.
  - \*2. DISTRIBUTION BOX CAN INCORPORATE SEVEN BOARDS IN ANY COMBINATION.
  - \*3. WHEN TWO DISTRIBUTION BOXES ARE USED, CONNECT SUCCEEDING ONE TO OTX BOARD.
  - \*4. RANGE SWITCH BOX REQUIRED FOR MF-22A ONLY.
  - \*5. USE #6 TO #8 FOR No. 2 DISPLAY.

DRAWN May. 9 '02 T. YAMASAKI	TYPE DS-370
CHECKED 02/5/02 Y. K.	名称 分配器
APPROVED 02/5/02 Y. K.	相互結線図 CI-60/60G CI-35/35H
DWG. No. C7242-C02-E	NAME DISTRIBUTION BOX
INTERCONNECTION DIAGRAM	



承認 APPROVED	名 稱 TITLE	指示器総合回路図 DISPLAY UNIT
検 図 CHECKED	製 図 DRAWN	CI-600 CI-3500
製 図 DRAWN	図 番 DWG. NO.	C7228-K01-B

FURUNO ELECTRIC CO., LTD.



承認 APPROVED		図面 DRAWN	名称 TITLE
AUG-30-90 T. AKAHARA		AUG-30-90 M. IKEDA	送受信演算部総合回路図 CI-610 TRANSCIVER UNIT
検閲 CHECKED		製図 DRAWN	図番 DWG. NO.
AUG-30-90 T. AKAHARA		AUG-30-90 M. IKEDA	C7228-K02-D

(※印は社外秘回路図  
MAR※): NOT PUBLISHED.

REV. TABLE  
FURUNO ELECTRIC CO., LTD.


外部機器へ  
AUX.  
予備  
NOT  
USED

外部機器  
EXTERNAL  
EQUIPMENTS

指示器  
DISPLAY  
UNIT


指示器  
DISPLAY  
UNIT

船内電源  
SHIPS  
MAINS




DRWING NO.	Nov 22 '96	T. YAMAGUCHI	TYPE	CI-610/CI-3510
CHECKED	Nov 22 '96	TAKAHASHI	名称	電源ブロック
APPROVED	Nov 25 '96	K. OKAMOTO	回路図	
SCALE	1/1	kg	BLOCK NO.	
APPLICABLE TO:			NAME	POWER_SUPPLY_BLOCK
DMG NO.	C7228-K05-D	66-017-2010-3		SCHEMATIC DIAGRAM

FURUNO ELECTRIC CO., LTD.



CI-60		品番 ITEM	品名 NAME	材質 MATERIAL	数量 QTY	図番 DWG.NO.	摘要 REMARKS
承認 APPROVED	SEP. 7 '90 T. YAKAUC	三角法 THIRD ANGLE PROJECTION		名称 TITLE		DC/AC インバータ INVERTER	
検 CHECKED	SEP. 6 '90 M. IYEDA	尺 SCALE	/	TR-2450			
製 DRAWN	SEP. 5 '90 TAKAHASHI	重 WEIGHT	kg	図 DWG.NO.	C7228-K11-A		



CI-60/CSH-5		品番 ITEM	品名 NAME	材質 MATERIAL	数量 Q'TY	図番 DWG.NO.	摘要 REMARKS
承認 APPROVED	SEP. 7 '90 T. NAKANO	三角法 THIRD ANGLE PROJECTION		名称 TITLE CSH-5050 DC/AC インバータ INVERTER			
検 CHECKED	SEP. 6 '90 M. IKEDA	尺 SCALE	/				
製 DRAWN	SEP. 5 '90 TAKAHASHI	重 WEIGHT	kg	図 DWG.NO.	C1273-K26-A		