

Eureka!

INSTRUCTIONS | Tetragon NX 4 (2629153)

1. Identify all tent components (see list below).





2. Spread out tent body and locate 4 corner webbing loops with ring and pin assemblies.




3. Assemble 2 frame poles. Insert 4 pins into each of the pole ends. Poles should be in an X orientation.

4. Attach all tent clips to poles.







5. Attach peak clip to top pole.



6. Stake out 4 corners of tent.




7. Assemble fly poles. Insert ends of fly poles into pole pockets located on underside of fly. Poles should be parallel.



8. Place fly over tent body. Match corresponding **BLACK** and **BLUE** webbing on fly and tent for correct orientation.

9. Connect hook and loop fasteners located on underside of fly around tent poles.

10. Hook fly to tent rings at 4 corners.





11. Stake out all guylines. Additional stakes and guylines required.

TENT CONTENTS

Tent body + Tent fly
Fiberglass frame poles (2) LONG
Fiberglass fly poles (2) SHORT
Steel stakes (4)
Gear loft

QUESTIONS?

Johnson Outdoors Gear, Inc.
USA: 1-800-572-8822
www.eurekacamping.com

Johnson Outdoors Canada
Canada: 1-800-263-6390
www.eurekatentscanada.com

TENT TIPS

- Always stake down tent, including all guyout points.
- Increase interior airflow by opening the windows in favorable weather.

TENT CARE

- Make sure the tent is completely dry, then store loosely rolled in a dry cool place.
- Clean your tent by setting it up and wiping it down with a mild soap and luke warm water. Never use laundry detergent, washing machines or dryers.

WARRANTY

- Your Eureka! tent is covered by a limited lifetime warranty. For more details please visit the website or contact customer service.