
Eureka!

INSTRUCTIONS | X-Loft 4 (2629034)

1. Identify all tent components (see list below).




2. Spread out tent body + locate 4 corner webbing loops with grommets.





3. Assemble 2 main poles and insert into pole sleeves located above front + rear doors.

4. Insert main pole tips into each of the 4 corner grommets.




5. Construct the roof pole assembly.












6. *With the hub clip attachment facing down,* insert roof pole tips into the 4 blue webbing grommets located on the main pole sleeves.



7. Locate tent peak clip + attach to underside of hub.



8. Attach all tent body clips to poles.






9. Stake out 4 corners and 2 sides of tent.



10. Place fly over tent body. Locate hook + loop fasteners on underside of fly and attach to tent poles. Attach tent body to fly via connectors on side of tent.

11. Connect matching buckles on fly + tent body at 4 corners. Adjust fly tension via corner webbing. Stake out vestibules. Stake out all guylines.



TENT CONTENTS

Tent body + Tent fly
Main poles (2)
Roof pole assembly (1)
Stakes (15)
Guylines (6)
Gear caddy

QUESTIONS?

Johnson Outdoors Gear, Inc.
USA: 1-800-572-8822
www.eurekacamping.com

Johnson Outdoors Canada
Canada: 1-800-263-6390
www.eurekatentscanada.com

TENT TIPS

- Always stake down tent, including all guyout points.
- Increase interior air flow by using the High/Low Air Exchange fly feature and/or fly zipper vents.

TENT CARE

- Make sure the tent is completely dry, then store loosely rolled in a dry cool place.
- Clean your tent by setting it up and wiping it down with a mild soap and luke warm water. Never use laundry detergent, washing machines or dryers.

WARRANTY

- Your Eureka! tent is covered by a limited lifetime warranty. For more details please visit the website or contact customer service.