www.reelschematic.com

SSB RADIOTELEPHONE
MODEL **FS-1562/1552**

OPERATOR'S GUIDE

MODE SELECTION(Select the class of emission and AGC on/off.)

Every press of MODE [1] key changes mode and AGC status as follows.

J3E AGC ON → J3E AGC OFF → H3E AGC ON → H3E AGC OFF
↓
TLX AGC ON → TLX AGC OFF → FAX AGC ON → FAX AGC OFF
↑

FREQUENCY SETTING

DIRECT KEY IN	TX	[TX] → (Enter freqency.) → [ENT]
	RX	[RX] → (Enter freqency.) → [ENT]
	TX/RX	[TX] → [RX] → (Enter freqency.) → [ENT]
USER CHANNEL	TX	[TX] → [RCL] → (Enter channel.) → [ENT]
	RX	[RX] → [RCL] → (Enter channel.) → [ENT]
	TX/RX	[RCL] → (Enter channel.) → [ENT]
ITU CHANNEL		Select mode before setting ITU channel.
	TX	[TX] → [RCL] → (Enter channel.) → [ENT]
	RX	[RX] → [RCL] → (Enter channel.) → [ENT]
	TX/RX	[RCL] → (Enter channel.) → [ENT]

RECEIVER SENSITIVITY

CLARIFY [3] → (Adjust FREQ/CH encoder.) → CLARIFY [3]

www.reelschematic.com

TX FREQ. WATCH (It automatically returns after 3 seconds.)

RX ➡ ENT (Tx freq. appears at the part of Rx indication.)

TRANSMISSION POWER REDUCTION

HI ⇄ LOW
8 ("LOW" appears.)

SCANNING (AGC:ON. After frequency or channel setting)

START	User channel	(Select a user channel.) ➡ SCAN 6
	ITU channel	(Select an ITU channel.) ➡ (Set cursor to band or channel to scan by CURS 2 key.) ➡ SCAN 6
STOP		SCAN 6 or PTT switch

SWEEPING (AGC:ON)

START	(Select a center frequency of sweep by direct key-in.) ➡ SCAN 6 ("SWEEP" appears.)
STOP	SCAN 6 or PTT switch

INTERCOM (with the RB-500(option) remote station)

START	INTERCOM 0 ➡ (Enter remote station number.) ➡ ENT ➡ (Press the PTT switch to talk.)
STOP	INTERCOM 0

DISTRESS CALLING (2182kHz Two-Tone Alarm)

2182 ➡ ALARM + ENT (45 seconds)

(To suspend, press the ENT key.)

950810KS PUB.NO.OSE-55722-B
(9411,TAYA) FS-1562/1552

0003062280 0