FISH TRAP BUILD VIDEO

WATCH NOW

ICE TEAM

KENAI THERMAL XT

SPECIFICATIONS

- Part Number: 116611
- Set Up Size: 90”L x 37”W x 73”H
- Packed Size: 48”L x 37”W x 25”H
- Weight: 56 lbs.
- Fishable Area: 11 sq.ft
- Instructions: 106967

CLAMOUTDOORS.COM

MODEL 16611

WARRANTY INFORMATION

STOP

Please contact customer service directly at the E-mail or phone number listed below for any quality issues. ***ONCE USED THIS PRODUCT CANNOT BE RETURNED TO STORE.***

***** Warranty cannot be honored without an original, dated receipt *****

***** REGISTER YOUR PURCHASE ONLINE AT CLAMOUTDOORS.COM *****

IMPORTANT-PLEASE READ:

This product is warranted to the original retail purchaser (from an authorized dealer) and is non-transferable. Clam Outdoors has a one-year ***manufacturer’s defect warranty*** from the date of original purchase. Warranty does not cover cracked or worn bases ***(if runner kits have not been installed as recommended)***, cracked windows, tent tears or cuts, or broken or bent hoops due to high wind weather conditions or unattended use. Defective parts will be replaced or repaired (at the manufacturer’s option) if found to be defective within one year from the date of original purchase. Warranty will be void if product has been subject to neglect, misuse, improper installation, misapplication, alteration, accident including but not limited to improper maintenance, or use of unauthorized parts or attachments. Please read the entire owner’s manual to ensure proper installation, use, storage and care of your Clam Shelter.

To submit a warranty claim request, please use one of the following methods:

- https://clamoutdoors.com/pages/warranty-form
- Email: customerservice@clamcorp.com

In your request, please include your full name, address, phone number, a copy of your receipt, a brief description of the problem, and pictures to clearly show the area(s) of concern. Our Warranty Department will review your request, and a Clam representative will contact you regarding your claim status. All returns must be shipped to us postage pre-prepaid.

LIMITATION OF LIABILITY

It is expressly understood that Clam Outdoors Inc., liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the repair of the product as stated above. Clam is not liable for any injury, loss, damage, or expense, whether direct or consequential, including but not limited to loss of use, income, profit, or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Clam products. Clam reserves the right to make alterations or modifications in its products at any time, which in its opinion, may improve the performance and efficiency of the product. Clam shall not be obligated to make such alterations or modifications to products already in service

Clam contact information

Customer Service Hrs: 9am to 4pm, Monday – Friday Central Standard Time

Clam Outdoors

Attn: Customer Service

12135 Brockton Lane

Rogers, MN 55369

Phone: 763-231-4120


PARTS LIST

QTY.	PART NO.	DESCRIPTION
1	106756	BASE, KENAI XT
1	106755	SEAT RAIL
2	106740	HOOP POLE, KENAI XT
2	106806	HALF HOOP POLE, KENAI XT
1	114272	SMALL DIMMABLE LIGHT STICK
2	106745	EXTENSION SUPPORT POLE, KENAI XT
1	106805	EXTENSION HOOP POLE, KENAI XT
1	106932	TENT, KENAI PRO THERMAL XT ICE TEAM
1	104165	DELUXE SEAT
2	104162	SEAT SLIDER
1	101074	REAR ADJUSTABLE SPREADER POLE
1	108829	BATTERY BRACKET
1	106861	HAMMOCK, ACCESSORY, KENAI XT (PACKAGED WITH TENT)
1	106410	LIGHT CORD STORAGE BAG
1	102814	U-CHANNEL
1	106617B	TRAVEL COVER, KENAI PRO THERMAL ICE TEAM
1	101095	ROPE, 3/8 DIA X 9 FT TOW
1	106967	INSTRUCTIONS, KENAI XT THERMAL
1	106859	INNERPACK, KENAI XT *(INCLUDES THE FOLLOWING)*
2	103770	SMALL RPSX COLLAR, 7/8” POLE
8	106748	PLASTIC HOOP SPACER
6	106743	CAP TUBE SPACER
2	106746	SWIVEL PLATE
2	106804	EXTENSION CLAMP
2	103833	MOUNTING BRACKET
1	106860	KIT, HRDWR, KENAI XT *(INCLUDES THE FOLLOWING)*
22	101148	SCREW, #6 X 0.38 PPH BZ
12	106286	SCREW, 1/4-20 X 0.75, BTN, HEX DRIVE
18	106284	NUT, 1/4-20, FLANGE, NYLOCK
8	101082	NUT, 1/4-20 THIN NYLOCK YZ
5	106457	SCREW, 1/4-20 X 2.125, FLAT HEAD, HEX DRIVE
7	106764	SCREW, 1/4-20 X 1.400, BTN, HEX DRIVE
3	106385	SCREW, 1/4-20 x 2.00, BTN, HEX DRIVE
2	103835	WASHER, PLASTIC LARGE
1	106294	ALLEN WRENCH, 5/32 HEX DRIVE, 1/4 THREADS



- **EXTRA FASTENERS INCLUDED WITH THE HARDWARE KIT #106860.**
- **INSTALL ANY RUNNER KIT OPTIONS BEFORE ASSEMBLING SHELTER. REFER TO RUNNER KIT INSTRUCTIONS**
- **USING A DROP OF OIL ON ALL NUTS WILL EASE THE ASSEMBLY.**


HARDWARE FASTENERS REFERENCE



12X 106286



18X 106284




7X 106764




8X 101082




3X 106385



2X 103835



5X 106457



1X 106294

ReelSchematic

STEP 1 – LIGHT STICK ASSEMBLY


Parts Needed for Step 1


Part Number	Description	Quantity
106806	HALF HOOP POLE	2
114272	LIGHT STICK SMALL, DIMMER	1
106410	LIGHT CORD STORAGE BAG	1


A. Install Light Stick #114272 into the Half Hoop Poles #106806 to make the light stick hoop assembly. Hardware to assemble is included with the light stick.

NOTE: Be mindful of where you will be installing the included Battery Bracket as the light stick cord should face that direction.

B. Attach Light Cord Storage Bag #106410 to pole assembly.







STEP 2 – EXTENSION HOOP POLE

NOTE: The Extension Hoop Pole #106805 is identified with a green zip tie. This pole is also shorter in length than the other hoop poles included with the shelter.


Parts Needed for Step 2

Part Number	Description	Quantity
106804	EXTENSION CLAMP	2
106745	EXTENSION SUPPORT POLE	2
106805	EXTENSION HOOP POLE	1
N/A	LIGHT STICK ASSEMBLY (from Step 1)	1
103770	RPSX COLLAR	2


DO NOT CUT ANY OF YOUR POLES


A. Remove included hardware from the Extension Clamps #106804.

B. Clip Extension Clamp around the Light Stick Hoop Pole Assembly from Step 1 with the molded coupling situated towards the inside. Slide the clamp into place and snap into the respective hole on the pole. Repeat this process on other side.




C. Attach Extension Support Poles #106745 with the notch of the pole facing inward. Use hardware provided with the Extension Clamps to secure. ***NOTE: Do not overtighten as this pole needs to move freely.***






D. Clip green zip tie on Extension Hoop Pole #106805 and install RPSX Collars #103770 onto the ends.

Align collar with holes the in the Hoop Pole as shown




Run electrical tape around the collar here to help hold in place

TIP: Twist the lever on the RPSX Collars 90 degrees to allow for easier installation onto Extension Hoop Pole.





E. Install Extension Hoop Pole onto Extension Support Poles (shown below).




STEP 3 – HOOP POLE ASSEMBLY

Parts Needed for Step 3

Part Number	Description	Quantity
106740	HOOP POLE	1
N/A	EXTENSION HOOP POLE ASSEMBLY (from Step 2)	1
106743	CAP TUBE SPACER	4
106746	SWIVEL PLATE	2
106748	PLASTIC HOOP SPACER	6
106385	SCREW, 1/4-20 x 2.00	2
106764	SCREW, 1/4-20 X 1.400	4
101082	NUT, 1/4-20 NYLOCK	4

A. Insert #106743 Cap Tube Spacers into ends of the Hoop Pole #106740 and Extension Hoop Pole Assembly (see next page).





Align cap and pole holes

B. Lay one Hoop Pole down and place the Extension Hoop Pole Assembly from Step 2 on top. Using the Plastic Hoop Spacers #106748 and hardware shown in the figure below, install poles onto the Swivel Plate #106746.

C. Repeat process for other side.


POLES AND PLATES SHOULD MOVE EASILY – DO NOT OVERTIGHTEN





Leave this bolt open

Completed Hoop Pole Assembly




STEP 3 – SEAT ASSEMBLY

Parts Needed for Step 3

Part Number	Description	Quantity
104165	DELUXE SEAT	1
104162	SEAT SLIDER	2
106755	SEAT RAIL	1
106861	HAMMOCK	1
106457	SCREW, 1/4-20 x 2.125	4
106286	SCREW, 1/4-20 x 0.75	4
106284	NUT, 1/4-20, NYLOCK	4

A. Attach Seat Sliders #104162 with the flat side of the slider facing inward (as shown below).


B. Secure using #106457 bolts and #106284 nuts.



F. Slide the Seat Rail #106755 through the Seat Sliders.

G. Locate Hammock #106861, which is a fabric accessory included inside the tent bag.


H. Velcro the back end of the Hammock to the Seat Rail (as shown below).



ReelSchematic

I. Install the Seat Assembly onto the base using #106286 bolts and #106284 nuts. The front of the Hammock sits between the lip of the base and the Seat Rail and is held by the two bolts. ***NOTE: HAMMOCKS ARE MEANT TO BE TIGHT. IT MAY BE NECESSARY TO USE A PLIERS TO STRETCH THE FRONT STRAPS SO THEY REACH THE MOUNTING LOCATION.***

Seat Covers are not included with Kenai-model shelters




STEP 4 – MOUNTING BRACKETS

Parts Needed for Step 4

Part Number	Description	Quantity
103833	MOUNTING BRACKET	2
106286	SCREW, 1/4-20 X 0.75	4
106284	NUT, 1/4-20, NYLOCK	4

A. Place Mounting Bracket #103833 with the 'L' facing outwards as shown below.

B. Insert #106286 bolts and secure to base using #106284 nuts.




ReelSchematic

STEP 5 – BATTERY BRACKET

A. Choose which location you'd prefer to have the battery located (battery not included). **Light stick cord will need to be able to reach battery.**

B. Install Battery Bracket #108829 as shown below. Refer to the installation manual included with the kit for additional information. Hardware for bracket is included in the kit.



STEP 6 – INSTALLING POLE ASSEMBLY


Parts Needed for Step 6


Part Number	Description	Quantity
N/A	HOOP POLE ASSEMBLY (from Step 3)	1
103835	LARGE PLASTIC WASHER	2
106284	NUT, 1/4-20, NYLOCK	2
101074	ADJ. SPREADER POLE	1

A. Lay the Hoop Pole Assembly on the top lip of the base. Place the Large Plastic Washer #103835 onto the longer mounting bracket bolt (from Step 3). ***NOTE: The washer is sandwiched between the plate and bracket.***

B. Insert the long bolt into the front hole of the Mounting Brackets and tighten nut (see below).


ReelSchematic





Need to have space between bracket and hardware

COMPLETED HOOP POLE ASSEMBLY AT THIS POINT SHOULD MOVE FREELY AND LOOK LIKE THE FOLLOWING PICTURE.



STEP 6 – TENT INSTALLATION

FOR AN ALTERNATIVE OPTION FOR INSTALLING THE TENT, PLEASE REFER TO THE SETUP VIDEO INSTRUCTIONS FOUND THROUGH THE QR CODE ON PAGE 1 OF THIS MANUAL

Parts Needed for Step 6

Part Number	Description	Quantity
106931	TENT, KENAI PRO THERMAL XT	1
106740	HOOP POLE	1
106748	PLASTIC HOOP SPACER	2
106764	SCREW, 1/4-20 X 1.400	2
101082	NUT, 1/4-20 THIN NYLOCK	2
102814	U-CHANNEL	1
101148	SCREW, #6 X 0.38	22


TIPS


- For best results, set tent in a warm environment
- Use of a cordless drill is advised for installing U-channel screws
- Before installing tent, place a heavy weight in the center of the base to ensure proper tent installation
- Do not leave spreader poles attached while installing tent. Only use them for placing tent over the shelter's frame during the assembly process

A. Drape the tent over the hoop poles. Attach the tent to the poles on the inside with the Velcro straps.

B. Slide the remaining hoop pole through the sleeve in the front of the tent.

C. Attach the last hoop pole to the front bracket as shown. **DO NOT OVERTIGHTEN MUST MOVE FREELY.**






SLIDE HOOP POLE THROUGH SLEEVE IN FRONT OF TENT


ReelSchematic


Soaking the U-Channel #102814 in hot water will make it much more pliable and easier to wrap around shelter.



THE FRONT HOOP POLE SHOULD TOUCH THE FLOOR WHEN THE TENT IS SET CORRECTLY WITH SOME SLACK IN THE FRONT PART OF THE TENT

REMOVE REAR SPREADER POLE WHILE INSTALLING U-CHANNEL





D. After connecting the Velcro tent loops to the frame, pull tent material over the back of the base and temporarily attach using clamps.

E. Walk around shelter to verify the tent is fitted to the frame properly & adjust as needed before continuing.

F. To properly set the tent, pull down on the rear corners of the tent to adjust the front hoop pole position. When set correctly, the front hoop pole should touch the floor and the tent material should have some slack. Once satisfied with how the tent is sitting, re-clamp rear corners to maintain proper position of the tent.

G. Before installing U-Channel #102814, place in hot water for a minimum of two minutes or until molding is pliable.

H. Find rear midpoint of the shelter and center of U-Channel. Press the middle of the molding over tent material and base lip (see Detail "A"). Insert one #6 phillips screw into the center of the U-Channel molding. Next, press the molding in around the base and cut 8" from the rear of the pole mounting bracket (see Detail "B").

I. Install remaining screws through U-Channel until it's fully secured to the base and is holding the tent tight to the tub.

TIPS FOR USE

▪Use travel cover to help prolong the life of the unit.

▪We recommend the optional Runner Kit be mounted to the base of your shelter
NOTE: Pulling behind an ATV or snowmobile may result in premature wear of the base.

▪In windy conditions it is advised to secure your shelter to the ice using Clam's Ice Anchor Kit (PN 108064) and Ice Anchor Installation Tool (PN 108348).

Make sure your ice shelter is completely dried out after each use. Store your shelter in a cool, dry place. Keep away from rodents.

Q: What is the proper way to set up and take down my Fish Trap?

Set-Up:

- Face the seats. Grab the floor hoop pole and pull on it until you feel and hear the RPSX collar pins engaging in the fully open position. Grab the next hoop and do the same until all the hoops are fully open. When finished, you should be inside the shelter.
- Install the roof spreaders, then front spreader, and finally the rear spreader. (Spreader count varies with shelter style/configuration – some smaller shelters use only a rear spreader).

Take-Down:

- Remove all spreaders - snug the tension knobs after compacting so they don't vibrate out during transit.
- From inside the shelter, start with the rear wall hoop. Compress both collars and retract hoop, then the same with next inward hoop, etc. Continue until all upright hoops are collapsed.
- Step out of the shelter, disengage the porch hoop collars and swing the porch hoop onto the previously retracted hoops. Make sure the tent does not catch on the mount brackets while collapsing the porch hoop.
- Go around the shelter and tuck the tent material in between the rested hoops the best you can to keep the tent material from dragging during transit – a travel cover works great to help hold everything together.

***Note: Make sure tent material is clear of the canopy brackets to minimize rubbing or possible tearing.

ReelSchematic

SAFETY INSTRUCTIONS



Please fully understand and follow all safety instructions as outlined. Failure to do so could result in severe injury or death.

▪DO NOT USE OPEN FLAME HEATERS IN YOUR ICE SHELTER. INJURY OR DEATH MAY RESULT FROM FIRE IF TENT FABRIC IS EXPOSED TO OPEN FLAME. THE TENT IS NOT FIREPROOF, BUT THE FABRIC IS TREATED WITH A FIRE RETARDANT THAT MEETS CPAI-84 SPECIFICATIONS. APPLICATION OF ANY FOREIGN SUBSTANCE MAY RENDER THE FLAME RETARDANT PROPERTIES INEFFECTIVE. TENT FABRIC WILL MELT WHEN CONTACT IS MADE WITH HOT SURFACES (I.E., HEATERS).

▪DEATH FROM ASPHYXIATION MAY RESULT FROM USE OF OXYGEN DEPLETING HEATERS. OPEN ALL VENTS FOR FRESH AIR VENTILATION.

▪NEVER LEAVE SHELTER UNATTENDED WHEN SET UP.

▪DUE TO THE INCREASE IN TRAFFIC (SNOWMOBILES, AUTOS, ETC.) ON AREA LAKES, ICE FISHING CAN BE HAZARDOUS AT NIGHT. IF YOU CHOOSE TO FISH AT NIGHT OR IN POOR VISIBILITY CONDITIONS, BE SURE TO TAKE PRECAUTIONS WITH LIGHTS OR REFLECTORS TO SHOW DRIVERS YOUR WHEREABOUTS. NIGHTTIME: EXTERIOR REFLECTORS MUST BE VISIBLE TO REDUCE RISK OF COLLISIONS.

FREQUENTLY ASK QUESTIONS

Fish Trap FAQ's

Q: Should I install a runner kit/hyfax to the base of my shelter?
A: The warranty on our shelters does not cover cracked or worn bases if a runner kit has not been installed. Additionally, bases will wear much quicker without a runner kit installed.

Q: The zipper on my shelter freezes up and/or sticks. Is there anything I can use to help prevent this from happening?
A: There are lubricants available that can work well, including various silicone sprays, ChapStick and other zipper lubricant sticks and brushes.

Q: The sliding seat poles, frame poles, or spreader poles of my shelter are sticking. Is there anything to put on these poles to help them slide better?
A: Silicone spray lubricants can help prevent poles from sticking. When poles slide against each other sometimes burrs are created. If this happens separate the affected poles and use a fine file or sandpaper to deburr the pole(s) and then apply a thin coat of lubricant before rejoining the poles.

Q: Do you have a replacement tent, base, poles, quick connects or other parts for my Fish Trap?
A: Retailers typically don't carry replacement parts, but we have replacement parts available for purchase direct at www.clamoutdoors.com. We are limited on parts for older model shelters.

Q: The poles to my Fish Trap have bent out of place. Should I try to bend them back?
A: It might be possible to bend the poles back into their proper place. If your bent pole is not creased lay it on a flat surface and bend it back into shape. Replacement poles can be ordered online from our website if needed.

Q: Should I put screws through the U-channel molding and tent of my shelter?
A: Putting screws through the U-channel will help to securely fasten the tent of your shelter to the base. This is a necessary step for proper installation and failure to do so will void the warranty.

Q: I am trying to attach the U-channel molding to my shelter, but am having difficulty getting it started, as it seems too stiff and will not stay attached to the edge of the sled. What can be done to help?
A: It is difficult to attach the U-channel in cold conditions. Assembly of the shelter should be done indoors with the U-channel warmed in a bucket of hot water for several minutes so it's more pliable.

Q: I can see pinholes of light through the fabric of my tent. Is my shelter waterproof and will my fish house leak?
A: Pinholes may be seen along seams or where the tent fabric is bonded to the thermal material on an insulated shelter. In either case, this has no effect on the function of the fabric or performance of the unit. While the fabric of the tent is water resistant it is not waterproof, so some water from rain or melting snow may come through your tent. A waterproofing spray such as Kiwi Camp Dry can be applied to the tent fabric to make the shelter more water repellent.

Q: There are cracks on the inside finish of the fabric of my shelter. Is this normal? Can anything be done to fix this?
A: It is normal for some of the dark colored coating to come off the inside of the tent, particularity on a non-thermal tent. Over time, as you set up and take down the shelter, the dark coating can begin to flake off, especially along the folds in the fabric when the shelter is collapsed. This does not affect the function of the fabric. If you feel that too much light is now entering your shelter in the places where some of the coating has come off, you may wish to apply a new layer of rubberized coating. A thin layer of Loctite Color Guard (black), found online or at home improvement stores, works well.

Q: Would it be best to completely dry out my shelter after every time it gets used?
A: It is recommended your tent be dried out completely after each use. If it is not dried out, moisture may cause some damage to the shelter. This is especially important if the shelter is being stored for a long period of time.

Q: What will help keep mice or rodents from eating the tent of my Fish Trap?
A: We recommend keeping your tent in a sealed plastic tote with laundry dryer sheets or moth balls. If the shelter is stored in a barn or shed, take the tent off and store it in a more rodent-free environment.

Q: How do I wash the tent of my ice fishing shelter?
A: We recommend using a mild bleach and water solution (1 part bleach to 10 parts water), or a mild soap detergent and water solution to help get rid of mildew and odor in your tent. Be sure to dry the tent thoroughly. We do not recommend using a washing machine to clean the tent as it may cause damage.

Q: Will using a heater help to eliminate or reduce water vapor and condensation in my shelter?
A: No. A byproduct of burning propane is water. A bigger heater will produce more water vapor. Also, the colder the temperature outside the more condensation there will be inside the unit.

Q: Are patch kits available and how do I apply them to my shelter?
A: Yes, patch kits are available for purchase on our website. When applying a patch, it works best to spray adhesive (we recommend using 3M #77 or 3M #90 spray adhesive) on to both surfaces - the part of the tent where the patch is going to be applied and the patch itself. Wait until the adhesive begins to dry and becomes tacky, then place the patch on the tent. Make sure to apply the patch evenly and smoothly since wrinkles or uneven areas will be very difficult to correct once the two surfaces with the adhesive come into contact with each other.

Q : Do you ship outside of the United States?
A: We can ship to Canada, but note that all prices on our website are listed in US dollars. Canadian orders will include the cost of the item plus shipping, taxes & duties.