FISH TRAP BUILD VIDEO

WATCH NOW

VOYAGER THERMAL XT

SPECIFICATIONS

- Part Number: 118021
- Set Up Size: L93” x W72” x H79”
- Packed Size: L72” x W40” x H26”
- Weight: 113 lbs.
- Fishable Area: 26 sq.ft
- Instructions: 107346

MODEL 16606

CLAMOUTDOORS.COM

WARRANTY INFORMATION

STOP

Please contact customer service directly at the E-mail or phone number listed below for any quality issues. ***ONCE USED THIS PRODUCT CANNOT BE RETURNED TO STORE.***

***** Warranty cannot be honored without an original, dated receipt *****

***** REGISTER YOUR PURCHASE ONLINE AT CLAMOUTDOORS.COM *****

IMPORTANT-PLEASE READ:

This product is warranted to the original retail purchaser (from an authorized dealer) and is non-transferable. Clam Outdoors has a three-year ***manufacturer’s defect warranty*** from the date of original purchase. Warranty does not cover cracked or worn bases ***(if runner kits have not been installed as recommended)***, cracked windows, tent tears or cuts, or broken or bent hoops due to high wind weather conditions or unattended use. Defective parts will be replaced or repaired (at the manufacturer’s option) if found to be defective within three years from the date of original purchase. Warranty will be void if product has been subject to neglect, misuse, improper installation, misapplication, alteration, accident including but not limited to improper maintenance, or use of unauthorized parts or attachments. Please read the entire owner’s manual to ensure proper installation, use, storage and care of your Clam Shelter.

To submit a warranty claim request, please use one of the following methods:

- https://clamoutdoors.com/pages/warranty-form
- Email: customerservice@clamcorp.com

In your request, please include your full name, address, phone number, a copy of your receipt, a brief description of the problem, and pictures to clearly show the area(s) of concern. Our Warranty Department will review your request, and a Clam representative will contact you regarding your claim status. All returns must be shipped to us postage pre-prepaid.

LIMITATION OF LIABILITY

It is expressly understood that Clam Outdoors Inc., liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the repair of the product as stated above. Clam is not liable for any injury, loss, damage, or expense, whether direct or consequential, including but not limited to loss of use, income, profit, or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Clam products. Clam reserves the right to make alterations or modifications in its products at any time, which in its opinion, may improve the performance and efficiency of the product. Clam shall not be obligated to make such alterations or modifications to products already in service

Clam contact information

Customer Service Hrs: 9am to 4pm, Monday – Friday Central Standard Time

Clam Outdoors

Attn: Customer Service

12135 Brockton Lane

Rogers, MN 55369

Phone: 763-231-4120

PARTS LIST

QTY.	PART NO.	DESCRIPTION
1	103883	BASE, JM THERMAL X/VOYAGER
3	106888	HOOP POLE, VOYAGER XT
1	106889	EXTENSION HOOP POLE, VOYAGER XT (Green Zip Tie)
1	106898	TENT, VOYAGER THERMAL XT
1	102506	SEAT RAIL
2	102759	DELUXE SEAT
1	107269	SPREADER POLE KIT (INCLUDES THE FOLLOWING)
1	106901	FRONT SPREADER POLE-81 IN
2	107266	ADJUSTABLE ROOF SPREADER POLE 31-55 IN
1	101840	REAR ADJUSTABLE SPREADER POLE
1	102814	U-CHANNEL
2	107352	SEAT COVER, BOTTOM
2	107351	SEAT COVER, BACK
1	101095	TOW ROPE, 3/8 DIA X 9 FT
2	101466	HAMMOCK, ACCESSORY (PACKAGED WITH TENT)
1	107346	INSTRUCTIONS, VOYAGER XT THERMAL
1	106894	INNERPACK. VOYAGER XT (INCLUDED THE FOLLOWING)
2	101430	CAP TUBE
4	103599	STRAIGHT CANOPY SUPPORT POLE
2	103597	BENT PORCH SUPPORT POLE
2	106800	MOUNTING BRACKET
2	106784	EXTENSION CLAMP
8	103605	LARGE RPSX COLLAR
8	101429	SEAT TUBE PLUG
4	104674	BLOCK, SLIDE OVAL
2	106896	EXTENSION SUPPORT POLE
2	102083	RAIL SUPPORT BRACKET
4	101146	EXTRUSION CHANNEL
4	101652	SEAT TUBE
4	101048	BLOCK, SLIDE CIRCLE
2	101420	FRONT RETAINER BRACKET
2	102430	REAR RETAINER BRACKET
2	105478	SWIVEL, SEAT
1	106895	KIT, HRDWR, VOYAGER XT (INCLUDED THE FOLLOWING)
38	106284	NUT, 1/4-20, FLANGE, NYLOCK
21	106286	SCREW, 1/4-20 X 0.75, BTN, HEX DRIVE
7	106331	SCREW, 1/4-20 X 2.50, PT, BTN, HEX DRIVE
11	106456	SCREW, 1/ 4-20 X 1.75, BTN, HEX DRIVE
21	101148	SCREW, #6 X 0.38 PPH BZ
9	101147	SCREW, #10 x 1.00 PPHTCHL YZ
9	101470	SCREW, 1/4-20 X 0.50 SER HXFLGHD GR5
1	106294	ALLEN WRENCH, 5/32 HEX DRIVE, L-SHAPE, 1/4 THREADS




- **EXTRA FASTENERS INCLUDED WITH THE HARDWARE KIT #106895**
- **INSTALL ANY RUNNER KIT OPTIONS BEFORE ASSEMBLING SHELTER. REFER TO RUNNER KIT INSTRUCTIONS**
- **USING A DROP OF OIL ON ALL NUTS WILL EASE THE ASSEMBLY**

HARDWARE FASTENERS REFERENCE




21X 101148




9X 101470




38X 106284




21X 106286




1X 106294



9X 101147



11X 106456



7X 106331

ReelSchematic


STEP 1 - SEAT ASSEMBLY

Parts Needed for Step 1

Part Number	Description	Quantity
101652	SEAT TUBE	4
101429	SEAT TUBE PLUG	8
101048	BLOCK, SLIDE (CIRCLE)	4
104674	BLOCK, SLIDE (OVAL)	4
101146	EXTRUSION CHANNEL	4
105478	SWIVEL, SEAT	2
102759	DELUXE SEAT	2
101420	FRONT RETAINER BRACKET	2
102430	REAR RETAINER BRACKET	2
101466	HAMMOCK, ACCESSORY	2
107352	SEAT COVER, BOTTOM	2
107351	SEAT COVER, BACK	2
101147	SCREW, #10 x 1.00	8
101470	SCREW, 1/4-20 X 0.50	8
106286	SCREW, 1/4-20 X 0.75	8
106456	SCREW, 1/ 4-20 X 1.75	8
106284	NUT, 1/4-20, NYLOCK	16


ReelSchematic

A. Insert Seat Tube Plugs #101429 into ends of Seat Tubes #101652. ***TIP: Use allen wrench to straighten tube plugs within the seat tubes to line up pre-drilled holes.***



B. Assemble the Block Slides #101048 (circle) and #104674 (oval) onto Extrusion Channels #101146.


C. Install #101147 screws into Block Slides.




SAME BLOCK STYLE MUST BE ALIGNED TO EACH OTHER (*e.g. oval aligned with oval*)

D. Rotate Seat Swivel #105478 45 degrees so its star shaped and all slotted holes are accessible.


E. Use #106286 bolts and #106284 nuts to secure Extrusion Channels to Swivel.




F. Attach swivel assembly to bottom of Deluxe Seat #102759 with #101470 screws and tighten.



G. Slide the seat tubes through the block slides. ***TIP: APPLY SILICONE SPRAY TO SEAT TUBES TO ALLOW ASSEMBLY TO SLIDE EASIER.***




H. Installing the Front Retainer #101420 and Rear Retainer #102430 brackets – Line up holes of retainer brackets to seat rail tubes and insert #106456 bolts. ***NOTE: REAR RETAINER BRACKET CONTAINS THE SEAT LATCH CLIP.***



I. Locate Hammock #101466, which is a fabric accessory included inside the tent bag.


J. Connect two corners of the hammock over the #106456 bolts on one end of the seat assembly (see figure below). Next, connect the hammock on the opposite end of the seat assembly. Thread #106284 nuts onto the four bolts and tighten. ***NOTE: HAMMOCKS ARE MEANT TO BE TIGHT. IT MAY BE NECESSARY TO USE A PLIERS TO STRETCH THE STRAPS SO THEY REACH THE BOLTS.***

Hammock Install – Front of Seat Assembly



THE FABRIC HAMMOCK IS PACKAGED WITH THE TENT

Hammock Install – Back of Seat Assembly



K. Insert Seat Cover Back #107351 and Bottom #107352 onto completed deluxe seat assembly, starting with the bottom cushion, and secure Velcro.

L. Repeat Step 1 to complete second seat assembly.

STEP 2 – EXTENSION HOOP POLE

DO NOT CUT ANY OF YOUR POLES


NOTE: The Extension Hoop Pole #106889 is identified with a green zip tie. This pole is also shorter in length than the other hoop poles included with the shelter.

Parts Needed for Step 2


Part Number	Description	Quantity
106784	EXTENSION CLAMP	2
106896	EXTENSION SUPPORT POLE	2
106889	EXTENSION HOOP POLE	1
106888	HOOP POLE	1
103605	LARGE RPSX COLLAR	4

A. Remove included hardware from the Extension Clamps #106784.

B. Clip Extension Clamp around the Hoop Pole #106888 (no green zip tie) with the molded coupling situated towards the inside. Slide the clamp into place and snap into the respective holes on the Hoop Pole. Repeat this process on other side of the pole.



C. Install RPSX Collar #103605 onto both sides of Hoop Pole #106888.



Align RPSX Collar with the holes in the Hoop Pole as shown

Collar tab is placed on inside of tube


ReelSchematic

TIP: Twist the lever on the RPSX Collars 90 degrees to allow for easier installation onto Hoop Pole.




D. Attach Extension Support Poles #106896 with the notch of the pole facing inward. Use hardware provided with the Extension Clamps to secure. ***NOTE: Do not overtighten as this pole needs to move freely.***

Hardware included with Extension Clamp



Head of bolt facing outward




Extension Support Pole

E. Clip green zip tie and install RPSX Collars #103605 onto Extension Hoop Pole #106889.

F. Install Extension Hoop Pole #106909 onto Extension Support Poles #106896.

Extension Hoop Pole #106889



Hoop Pole #106888

STEP 3 – SEAT RAIL

Parts Needed for Step 3


Part Number	Description	Quantity
102083	RAIL SUPPORT BRACKET	2
101430	CAP TUBE	2
102506	SEAT RAIL	1
106286	SCREW, 1/4-20 X 0.75	4
106284	NUT, 1/4-20, NYLOCK	6
106456	SCREW, 1/ 4-20 X 1.75	2

A. Line up Rail Support Bracket #102083 with predrilled holes on interior wall of sled.

B. Insert #106286 bolt through the top hole and line up bracket so it's straight.

C. Once bracket is straight, insert another bolt into bottom hole and secure bolts with #106284 nuts.


D. Repeat process on opposite side.



ReelSchematic

E. Install Cap Tubes #101430 into the ends of the Seat Rail #102506.

F. Connect the Seat Rail the brackets using one #106456 bolt and #106284 nut on either end.
NOTE: Head of bolt needs to face the front of the shelter.



Install cap and align slot with the bolt hole of the Seat Rail


STEP 4 – POLE MOUNTING BRACKETS

Parts Needed for Step 4

Part Number	Description	Quantity
106800	MOUNTING BRACKET	2
106286	SCREW, 1/4-20 X 0.75	6
106284	NUT, 1/4-20, NYLOCK	6

A. Run #106286 bolts through Mounting Bracket #106800 and predrilled holes. Hand tighten #106284 nuts onto bolts, straighten bracket, then tightly secure. ***TIP: Start with bolt closest to the rear of the shelter so the bracket can be straightened.***

B. Repeat process on opposite end of sled.





STEP 5 – CANOPY SUPPORT POLES


NOTE: Ensure that all Canopy Support Poles (#103597 and #103599) have slots facing inward.

Parts Needed for Step 5


Part Number	Description	Quantity
103597	BENT PORCH SUPPORT POLE	2
103599	STRAIGHT CANOPY SUPPORT POLE	4
106331	SCREW, 1/4-20 X 2.50	6
106284	NUT, 1/4-20, NYLOCK	6

A. Install Bent Porch Support Poles #103597 to the bottom position of the Mounting Bracket using #106331 bolts and #106284 nuts.

B. Once Bent Porch Support Poles are secured on both sides, install remaining Straight Canopy Support Poles. ***TIP: All support poles should be snug, but not too tight as they need to be able to fall freely.***



Slots in poles must face inward as shown



DO NOT overtighten Support poles - they should move easily

STEP 6 – HOOP POLES

Parts Needed for Step 6

Part Number	Description	Quantity
106888	HOOP POLE	2
103605	LARGE RPSX COLLAR	4
101840	REAR SPREADER POLE	1
107266	ROOF SPREADER POLE	2
N/A	EXTENSION HOOP POLE ASSEMBLY	1

A. Put the remaining RPSX Collars #103605 onto the Hoop Poles #106888.

B. Install one Hoop Pole onto the BACK set of Support Poles.


C. Next, install the Extension Hoop Pole Assembly to the next set of support poles.

D. Lastly, clip Rear Spreader Pole #101840 and two Roof Spreader Poles #107266 into place.


NOTE: DO NOT INSTALL BOTTOM HOOP (PORCH) POLE. THIS WILL BE DONE DURING THE TENT INSTALLATION STEP.

COMPLETED HOOP POLE ASSEMBLY AT THIS POINT SHOULD MOVE FREELY AND LOOK LIKE THE FOLLOWING PICTURE.

Extension Hoop Pole location





Slide Hoop Poles over Canopy Support Poles and lock into place with RPSX Collars



STEP 7 – PUTTING SEATS INTO SHELTER

A. Put seat assembly into shelter. Connect the front retaining bracket around the lip of the tub first, then the rear bracket. The rear retaining bracket has the spring latch.





USE LATCH TO SECURE SEAT

STEP 8 – TENT INSTALLATION

FOR AN ALTERNATIVE OPTION FOR INSTALLING THE TENT, PLEASE REFER TO THE SETUP VIDEO INSTRUCTIONS FOUND THROUGH THE QR CODE ON PAGE 1 OF THIS MANUAL

Parts Needed for Step 8

Part Number	Description	Quantity
106898	TENT, VOYAGER THERMAL XT	1
102814	U-CHANNEL	1
101148	SCREW, #6 X 0.38	21


TIPS FOR INSTALLING TENT

- For best results, set tent in a warm environment.
- Use of a cordless drill is advised for installing U-channel screws.
- Before installing tent, place a heavy weight in the center of the base to ensure proper tent installation.
- Do not leave spreader poles attached while installing tent. Only use them for placing tent over the shelter's frame during the assembly process.

A. Drape the tent over the Hoop Poles. Attach the tent to the poles on the inside with the Velcro straps.


B. Slide the remaining front Hoop Pole through the sleeve in the front of the tent.

Slide Hoop Pole through sleeve in front of tent




Connect Hoop Pole to Support Pole

Soaking the U-Channel #102814 in hot water will make it much more pliable and easier to wrap around shelter.



The front Hoop Pole should touch the floor when the tent is set correctly with some slack in the front part of the tent

Remove Spreader Poles while installing U-Channel



C. After connecting the Velcro tent loops to the frame, pull tent material over the back of the base and temporarily attach using clamps.

D. Walk around the shelter to verify the tent is fitted to the frame properly and adjust as needed before continuing.

E. To properly set the tent, pull down on the rear corners of the tent to adjust the front hoop pole position. When set correctly, the front hoop pole should touch the floor and the tent material should have some slack. Once satisfied with how the tent is sitting, re-clamp rear corners to maintain proper position of the tent.

F. Before installing U-Channel #102814, place in hot water for a minimum of two minutes or until molding is pliable.

G. Find rear midpoint of the shelter and center of U-Channel. Press the middle of the molding over tent material and base lip (see Detail “A”). Insert one #6 phillips screw #101148 into the center of the U-Channel molding. Next, press the molding in around the base. There should be an 8” gap from the end of the U-Channel to the back of the Mounting Bracket, so it may be necessary to cut the channel (see Detail “B”).

H. Install remaining screws through U-Channel until it is fully secured to the base and is holding the tent tight to the tub.

TIPS FOR USE

Folding and transporting your Clam Ice Fishing shelter is easy:

▪Unsnap the spreader poles and lay them in the bottom of the base.

▪Push the RPSX Collar and retract each hoop, starting with the rear hoop and working towards the front. Rotate all retracted hoops to the resting position. Tuck the tent into the base and between the hoops so that no material is left hanging on the ground for transport.

▪Cover with a travel cover to help prolong the life of the unit (travel cover not included with shelter).

▪We recommend the optional Runner Kit be mounted to the base of your shelter
NOTE: Pulling behind an ATV or snowmobile may result in premature wear of the base.

▪In windy conditions it is advised to secure your shelter to the ice using Clam's Ice Anchor Kit (PN 108064) and Ice Anchor Installation Tool (PN 108348).

Make sure your shelter is completely dried out after each use. Store your shelter in a cool, dry place. Keep away from rodents.

ReelSchematic

Q: What is the proper way to set up and take down my Fish Trap?

Set-Up:

- Face the seats. Grab the floor hoop pole and pull on it until you feel and hear the RPSX collar pins engaging in the fully open position. Grab the next hoop and do the same until all the hoops are fully open. When finished, you should be inside the shelter.
- Install the roof spreaders, then front spreader, and finally the rear spreader. (Spreader count varies with shelter style/configuration – some smaller shelters use only a rear spreader).

Take-Down:

- Remove all spreaders - snug the tension knobs after compacting so they don't vibrate out during transit.
- From inside the shelter, start with the rear wall hoop. Compress both collars and retract hoop, then the same with next inward hoop, etc. Continue until all upright hoops are collapsed.
- Step out of the shelter, disengage the porch hoop collars and swing the porch hoop onto the previously retracted hoops. Make sure the tent does not catch on the mount brackets while collapsing the porch hoop.
- Go around the shelter and tuck the tent material in between the rested hoops the best you can to keep the tent material from dragging during transit – a travel cover works great to help hold everything together.

***Note: Make sure tent material is clear of the canopy brackets to minimize rubbing or possible tearing.

SAFETY INSTRUCTIONS



Please fully understand and follow all safety instructions as outlined. Failure to do so could result in severe injury or death.

▪DO NOT USE OPEN FLAME HEATERS IN YOUR ICE SHELTER. INJURY OR DEATH MAY RESULT FROM FIRE IF TENT FABRIC IS EXPOSED TO OPEN FLAME. THE TENT IS NOT FIREPROOF, BUT THE FABRIC IS TREATED WITH A FIRE RETARDANT THAT MEETS CPAI-84 SPECIFICATIONS. APPLICATION OF ANY FOREIGN SUBSTANCE MAY RENDER THE FLAME RETARDANT PROPERTIES INEFFECTIVE. TENT FABRIC WILL MELT WHEN CONTACT IS MADE WITH HOT SURFACES (I.E., HEATERS).

▪DEATH FROM ASPHYXIATION MAY RESULT FROM USE OF OXYGEN DEPLETING HEATERS. OPEN ALL VENTS FOR FRESH AIR VENTILATION.

▪NEVER LEAVE SHELTER UNATTENDED WHEN SET UP.

▪DUE TO THE INCREASE IN TRAFFIC (SNOWMOBILES, AUTOS, ETC.) ON AREA LAKES, ICE FISHING CAN BE HAZARDOUS AT NIGHT. IF YOU CHOOSE TO FISH AT NIGHT OR IN POOR VISIBILITY CONDITIONS, BE SURE TO TAKE PRECAUTIONS WITH LIGHTS OR REFLECTORS TO SHOW DRIVERS YOUR WHEREABOUTS. NIGHTTIME: EXTERIOR REFLECTORS MUST BE VISIBLE TO REDUCE RISK OF COLLISIONS.

FREQUENTLY ASK QUESTIONS

Fish Trap FAQ's

Q: Should I install a runner kit/hyfax to the base of my shelter?
A: The warranty on our shelters does not cover cracked or worn bases if a runner kit has not been installed. Additionally, bases will wear much quicker without a runner kit installed.

Q: The zipper on my shelter freezes up and/or sticks. Is there anything I can use to help prevent this from happening?
A: There are lubricants available that can work well, including various silicone sprays, ChapStick and other zipper lubricant sticks and brushes.

Q: The sliding seat poles, frame poles, or spreader poles of my shelter are sticking. Is there anything to put on these poles to help them slide better?
A: Silicone spray lubricants can help prevent poles from sticking. When poles slide against each other sometimes burrs are created. If this happens separate the affected poles and use a fine file or sandpaper to deburr the pole(s) and then apply a thin coat of lubricant before rejoining the poles.

Q: Do you have a replacement tent, base, poles, quick connects or other parts for my Fish Trap?
A: Retailers typically don't carry replacement parts, but we have replacement parts available for purchase direct at www.clamoutdoors.com. We are limited on parts for older model shelters.

Q: The poles to my Fish Trap have bent out of place. Should I try to bend them back?
A: It might be possible to bend the poles back into their proper place. If your bent pole is not creased lay it on a flat surface and bend it back into shape. Replacement poles can be ordered online from our website if needed.

Q: Should I put screws through the U-channel molding and tent of my shelter?
A: Putting screws through the U-channel will help to securely fasten the tent of your shelter to the base. This is a necessary step for proper installation and failure to do so will void the warranty.

Q: I am trying to attach the U-channel molding to my shelter, but am having difficulty getting it started, as it seems too stiff and will not stay attached to the edge of the sled. What can be done to help?
A: It is difficult to attach the U-channel in cold conditions. Assembly of the shelter should be done indoors with the U-channel warmed in a bucket of hot water for several minutes so it's more pliable.

Q: I can see pinholes of light through the fabric of my tent. Is my shelter waterproof and will my fish house leak?
A: Pinholes may be seen along seams or where the tent fabric is bonded to the thermal material on an insulated shelter. In either case, this has no effect on the function of the fabric or performance of the unit. While the fabric of the tent is water resistant it is not waterproof, so some water from rain or melting snow may come through your tent. A waterproofing spray such as Kiwi Camp Dry can be applied to the tent fabric to make the shelter more water repellent.

Q: There are cracks on the inside finish of the fabric of my shelter. Is this normal? Can anything be done to fix this?
A: It is normal for some of the dark colored coating to come off the inside of the tent, particularity on a non-thermal tent. Over time, as you set up and take down the shelter, the dark coating can begin to flake off, especially along the folds in the fabric when the shelter is collapsed. This does not affect the function of the fabric. If you feel that too much light is now entering your shelter in the places where some of the coating has come off, you may wish to apply a new layer of rubberized coating. A thin layer of Loctite Color Guard (black), found online or at home improvement stores, works well.

Q: Would it be best to completely dry out my shelter after every time it gets used?
A: It is recommended your tent be dried out completely after each use. If it is not dried out, moisture may cause some damage to the shelter. This is especially important if the shelter is being stored for a long period of time.

Q: What will help keep mice or rodents from eating the tent of my Fish Trap?
A: We recommend keeping your tent in a sealed plastic tote with laundry dryer sheets or moth balls. If the shelter is stored in a barn or shed, take the tent off and store it in a more rodent-free environment.

Q: How do I wash the tent of my ice fishing shelter?
A: We recommend using a mild bleach and water solution (1 part bleach to 10 parts water), or a mild soap detergent and water solution to help get rid of mildew and odor in your tent. Be sure to dry the tent thoroughly. We do not recommend using a washing machine to clean the tent as it may cause damage.

Q: Will using a heater help to eliminate or reduce water vapor and condensation in my shelter?
A: No. A byproduct of burning propane is water. A bigger heater will produce more water vapor. Also, the colder the temperature outside the more condensation there will be inside the unit.

Q: Are patch kits available and how do I apply them to my shelter?
A: Yes, patch kits are available for purchase on our website. When applying a patch, it works best to spray adhesive (we recommend using 3M #77 or 3M #90 spray adhesive) on to both surfaces - the part of the tent where the patch is going to be applied and the patch itself. Wait until the adhesive begins to dry and becomes tacky, then place the patch on the tent. Make sure to apply the patch evenly and smoothly since wrinkles or uneven areas will be very difficult to correct once the two surfaces with the adhesive come into contact with each other.

Q : Do you ship outside of the United States?
A:We can ship to Canada, but note that all prices on our website are listed in US dollars. Canadian orders will include the cost of the item plus shipping, taxes & duties.