BIG FOOT™ SPORTSMAN XL2000T

SPECIFICATIONS

- **Part Number: 110137**
- **Center Height: 80”**
- **Footprint: 56 SQ. FT.”**
- **Hub to Hub: 96” x 96”**
- **Weight: 42lbs**
- **Instructions Document No: 105091**

MODEL 10137

WARRANTY INFORMATION

Please contact customer service directly at the E-mail or phone number listed below for any quality issues. ***ONCE USED THIS PRODUCT CANNOT BE RETURNED TO STORE.***

***** Warranty cannot be honored without an original, dated receipt *****

***** REGISTER YOUR PURCHASE ONLINE AT CLAMOUTDOORS.COM AND BE ENTERED INTO DRAWING *****

IMPORTANT-PLEASE READ:

This product is warranted to the original retail purchaser (not transferable) to be free from manufacturers defects for one (1) year from the date of the original purchase. *Warranty does not cover cracked windows tent tears, broken or bent poles due to high wind weather conditions or unattended use .*The part will be replaced or repaired (manufacturer’s option) if found defective within the one (1) year time frame. Warranty will be void if product has been subject to neglect, misuse, improper installation, misapplication, alteration, or accident including, but not limited to, improper maintenance or use of unauthorized parts or attachments. Please read this entire owner’s manual to ensure proper installation, use, storage, and care for your Clam shelter.

To submit a warranty claim request, please use one of the following methods:

- Customer Service Hrs: 9am to 4pm, Monday – Friday Central Standard Time
- Clam Outdoors, Inc.
  Attn: Customer Service – Warranty Department
  12135 Brockton Lane
  Rogers, MN 55369
- Phone: 763-231-4120
- Fax: 763-231-4121
- Email: customerservice@clamcorp.com
- Website: Clamoutdoors.com

In your request, please include your full name, address, phone number, a copy of your receipt, a brief description of the problem, and pictures to clearly show the area(s) of concern. Our Warranty Department will review your request, and a Clam representative will contact you regarding your claim status. All returns must be shipped to us postage pre-prepaid.

LIMITATION OF LIABILITY

It is expressly understood that Clam Outdoors Inc., liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the repair of the product as stated above. Clam is not liable for any injury, loss, damage, or expense, whether direct or consequential, including but not limited to loss of use, income, profit, or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Clam products. Clam reserves the right to make alterations or modifications in its products at any time, which in its opinion, may improve the performance and efficiency of the product. Clam shall not be obligated to make such alterations or modifications to products already in service

SAFETY INSTRUCTIONS

Please fully understand and follow all safety instructions outlined in this booklet. Failure to do so could result in severe injury.

- Do not use open flame heaters in your screen tent.
- Tent fabric will melt when contact is made with hot surfaces (i.e., heaters).
- Use external tie-downs and stakes during excessive wind conditions(15+mph)

⚠ WARNING

Injury or death may result from fire if tent fabric is exposed to open flame.

Tent fabric is not fireproof. Fabric will burn with extended exposure to open flame. Do not use open flame products inside tent. Tent fabric is treated with fire retardant. Application of any foreign substance may render the flame retardant properties ineffective.

This tent is made with flame resistant fabric which meets CPAI-84 specifications.

PARTS LIST

Customer service hours:
9am – 4pm, (CST)
Monday-Friday.
customerservice@clamcorp.com

ITEM #	DESCRIPTION	QTY.	PART NO.
1	HUB ASSY - Walls	6	103507
2	HUB ASSY - Roof	1	103750
3	STAKE, SCREEN HUB	7	103802
4	ICE ANCHORS	7	109750
5	EXTERNAL ANCHOR STRAPS	5	104238
6	HUB & POLE KIT WALLS (4 POLES & 1 HUB)	6	109077
7	HUB & POLE KIT ROOF (6 POLES & 1 HUB)	1	109221
8	CARRY BAG	1	105036
9	INSTRUCTIONS/OWNER'S MANUAL	1	105091

Replacement parts can be ordered on-line at www.clamcorp.com.

SET UP INSTRUCTIONS

BEFORE ATTEMPTING TO USE THIS PRODUCT go to www.clamoutdoors.com, click on your shelter model, and watch the set-up video provided. Then practice setting up and taking down at home in an area such as a garage or basement. Repeat several times until comfortable. This will make your set-up much easier.

NO TOOLS ARE NEEDED FOR SET-UP OF YOUR CLAM SCREEN TENT.

NOTE: When setting up your shelter, poles should be on the inside of the tent. Only pull outward on the hub pulls (loops) on the exterior of the tent.

Unzip the storage bag completely and remove the shelter. Use care not to misplace the stake & or accessories. It is advised to store your stakes, and accessories, in your carry bag until they're needed.

SET UP INSTRUCTIONS

IT IS ADVISED TO HAVE AT LEAST TWO PEOPLE TO SET UP A SPORTSMAN.

MAKE SURE THAT THE TENT IS NOT TWISTED OR OVERLAPPING ANY OF THE POLES. ***DO NOT FORCE*** THE TENT WHILE UNFOLDING.



1. SELECT MIDDLE POLE AND GRASP POLE END AS SHOWN. THEN LIFT THAT LEG UPWARDS AND OUTWARDS EXPOSING ROOF PANELS.

ReelSchematic

2. GRASP THE LOOP FABRIC LOOPED FABRIC AND EYELET LOCATED IN CENTER OF THE WALL PANEL. PULLING UPWARDS AND OUTWARDS UNTIL WALL PANEL POPS OUTS AND LOCKS IN POSITION



3 WALK AROUND THE ENTIRE SCREEN TENT AND PULL EACH LOOP SEWN ONTO THE EYELET IN THE CENTER OF THE WALL UNTIL ALL SIDES ARE POPPED OUT

SET UP INSTRUCTIONS

4 .WALK INSIDE OF THE SHELTER AND PUSHES THE CEILING HUBS STRAIGHT UP UNTIL THE CEILING POPS UP**.**



5. AT THIS POINT SECURE SHELTER TO GROUND AREA

Hunting blind-use BLACK ABS STACKS

Ice Hub-use THREADED STEEL ICE ANCHORS

SECURE ALL FOUR CORNERS STRAPPED GROMMENT FROM INSIDE OF SHELTER.

EXTERNAL ANCHORS AND STRAPS SHOULD BE USED IN WIND IN EXCESS OF 15+ MPH. OTHERWISE, DAMAGE CAN OCCUR TO YOUR SHELTER.

VIEW OF TENT AT THIS POINT



Step-5

SET UP INSTRUCTIONS

6 SCREENS AND TPU PLASTIC WINDOWS CAN BE REMOVED BY PULLING AWAY FROM VELCRO STRIPS AND RE ATTACHING TO VELCRO STRIPS.



TEAR DOWN INSTRUCTIONS

1. TPU PLASTIC WINDOWS AND SCREENS SHOULD BE SECURED TO TENT.

2. REMOVE ANY TENT ANCHORS BEING USED TO SECURE TENT IN PLACE.

3. FROM INSIDE OF TENT PULL DOWN CENTER HUB OF ROOF TO COLLASPE ROOF.

4. FROM OUTSIDE OF TENT PUSH THE CENTER HUB OF EACH SIDE INWARD TO COLLASPE EACH SIDE.

5. BUNDLE TENT TOGETHER AND PLACE INSIDE CARRING BAG.

ReelSchematic

- Safety Instructions -

Please fully understand and follow all safety instructions as outlined. Failure to do so could result in severe injury or death.

- ***Do not use open flame heaters in your screen tent. Injury or death may result from fire if tent fabric is exposed to open flame. The tent is not fireproof, but the fabric is treated with a fire retardant that meets CPAI-84 specifications. Application of any foreign substance may render the flame retardant properties ineffective. Fabric will melt when contact is made with hot surfaces (i.e., heaters).***

⚠ WARNING

Injury or death may result from fire if tent fabric is exposed to open flame.

Tent fabric is not fireproof. Fabric will burn with extended exposure to open flame. Do not use open flame products inside tent. Tent fabric is treated with fire retardant. Application of any foreign substance may render the flame retardant properties ineffective.

Night time: exterior reflectors must be visible to reduce risk of collisions.

This tent is made with flame resistant fabric which meets CPAI-84 specifications.

For replacement parts, frequently asked questions, shelter information, videos, and all of your ice fishing or screen tent needs visit our web site at www.clamoutdoors.com.

FREQUENTLY ASKED QUESTIONS

Q: How do I set-up my hub shelter/screen tent?

A: Go to www.clamoutdoors.com to watch an instructional video on the proper & simplest way to set-up and take-down a hub style shelter/screen tent.

Q: Is there anything can be put on outside of the tent to prevent water from coming through, when we are using it? A: Customers have been known to spray or apply water repellant on the outside of the shelter that you would use for camping tents or boots. (Camp Dry would be an example of this type of product). These products will not damage your tent in anyway.

Q: What will help keep mice or rodents from eating my Clam screen tent?
A: Some of our customers have had success with the following ways to keep mice out.

- Keep your tent in a sealed plastic tote with DRYER SHEETS and or MOTH BALLS

Q: The zipper on my tent freezes up and or sticks; is there anything I can use to help prevent this from happening? A: Yes, there are a couple of zipper lubricants out there that our customers and pro staff have had good luck with.

- Zipper Lube - A gel that you can apply just by squeezing it onto the zipper and moving the zipper back and forth. This brand can be found in the camping section of most sporting goods store.
- Silicone spray may also be used as well.

Q: Would it be best to completely dry my screen tent for storage if it gets wet?
A: It is recommended to dry your tent out completely, if not dried completely moisture may cause damage to your tent.

Q: How do I wash my screen tent?
A: You can use a bleach and water solution (10 parts water to 1 part bleach) to get rid of the mildew smell. If you want to wash the tent you can use a standard soap to wash it.
*** Please note - We **do not** recommend placing your shelter canvas/tent into a washing machine for cleaning.

Q: Am I able to order parts and accessories from your website?
A: Absolutely, if you would like to order parts you can go to www.clamcorp.com under "Resources" "Parts"

Q: Although this shelter has already been treated for waterproofing, is there anything I can do to make it more water repellant?

A: Yes. Even though the roof seams have been stitched with waterproof taping, you can treat the roof with a coating of
3M Scotchguard spray or treat the seams and Velcro loops for the roof poles' stitching with Seam Grip.

Due to Clam's continued product development, Clam reserves the right to change specifications without notice. For complete details, see the assembly and/or operating instructions that are provided and packaged with the purchased product.