



NS - 200LX Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	41000272	14100017-04002	LOW OKM0026		705-1	47050008	14705003-01002	TRANSMISSION GEAR	
105	41050003	14105002-01002	WORM SHAFT BUSHING		711	47110019	1471100201003A	GUIDE SLIDE BASE ASSY	
117	41170002	14117001-031	NUT		712	47120007	14712004-03001	WORM SHAFT	
119	41190007	14119002-01726	BODY COVER		713	47130005	14713002-04001	LINE GUIDE PAWL CAP	
200	42000121	1420000804003	HANDLE SIDE PLATE		715	47150003	14715002-06001	LINE GUIDE PAWL	
202	42020003	14202002-06002	RATCH		720	47200004	14720002-06002	DRIVE GEAR SHAFT BUSHING	
206	42060003	14206002-01002	CONTROL PIN CAP		725	47250001	14725001-06001	TRANSMISSION GEAR PIN	
207	42070001	14207001-01001	HOLDED PLATE		800	48000006	14800002-06001	CLUTCH SHAFT	
220	42200008	14222002-06001	SIDE PLATE HOLDED SCREW		801	48010005	14801004-06001	CLUTCH SHAFT SPRING	
226	42260001	14226001-03001	CONTROL PIN		804	48040005	14804004-06001	CLUTCH SLIDER	
300	43000076	14300005-01003	SIDE PLATE		804	48040010	14804006-02001	CLUTCH SLIDER	
302	43020004	14302001-1	WASHER		805	48050007	14805003-01002	PINION GEAR YOKE	
306	43060002	14306002-03001	CLICK BUTTON SPRING PIN		806	48060002	14806002-06001	YOKE SPRING	
313	43130002	14313002-06001	VICE SIDE PLATE FIXER		807	48070007	14807004-01001	YOKE BRAKED PLATE	
314	43140001	14314001-06001	CONTROL PIN		808	48080005	14808004-06001	YOKE BRAKED PLATE SPRING	
315	43150003	14315001xx	SIDE HOLDED PLATE		809	48090007	14809002-01003	CLUTCH BAR WASHER	
318	43180001	14318001-03001	CONTROL PIN BUSHING		812	48120004	14812004-06001	BRAKED PLATE HOLDER	
400	44000097	1440000904003	SPOOL ASSY.		813	48130001	14813001-07003	CLUTCH BAR CAP	
401	44010005	14401003-01001	SPOOL CLICK GEAR		9101	0910209	01030804-615	BALL BEARING	
500	45000026	1450000204006A	HANDLE ARM ASSY		9102	0910236	01050903-612	BALL BEARING	
516	45160009	14516001-0A915	HANDLE NUT RETAINER		9103	0910170	01101612-63	BALL BEARING	
600	46000021	14600003-04005A	CAST CONTROL CAP		9106	0910005	01031004-601	BALL BEARING	
603	46030003	14603002-07	O RING		9108	0910221	01040725-615	BALL BEARING	
608	46080003	14608002-06001	RETAINER		9201	0920105	025.1x10.5x.2-6	WASHER	
608-1	46080002	14608001-06001	RETAINER		9201-1	0920162	028x10x0.5-6	WASHER	
609	16090003	11609003-06001	DRAG SPRING WASHER		9201-2	0920326	028.1x12x0.5-0	WASHER	
610	16100018	11610004-006A	DRAG WASHER		9204	0920292	025.9x12x0.2-6	WASHER	
610-1	16100037	1161000301	DRAG WASHER		9205	0920332	028.2x20x1-9	WASHER	
610-2	16100038	1161000401	DRAG WASHER		9207	0920066	022x4.9x0.2-3	WASHER	
611	16110006	11611005-061	EARED WASHER		9301	0930368	03112.6x8-617	SCREW	
612	16120027	11612007-06001	KEY WASHER		9301-1	0930355	03112.6x10-617	SCREW	
612-1	16120030	11612007-06004	KEY WASHER		9309	0930704	03412x4-61	SCREW	
615	46150054	14615005-01003A	STAR DRAG		9314	0930508	03212x8-617	SCREW	
618	46180002	14618002-07	WASHER		9314-1	0930146	03212x3.2-61	SCREW	
619	46190003	14619002-01001	WASHER		9316	0930763	03422.6x6.5-61	SCREW	
700	47000018	14700006-03003	DRIVE GEAR		9319	0930226	03412.6x4-61	SCREW	
701	47010010	14701005-03002	DRIVE GEAR SHAFT		9401	29000001	12900001-06	E RETAINER	
702	47020032	14702009-03002	PINION GEAR		9401	19000002	11900002-06	E RETAINER	
703	47030013	14703004-01001	WORM SHAFT GUARD		9407-1	49010001		E RETAINER	
705	47050010	14705004-01002	TRANSMISSION GEAR						