
SHIMANO

ANTARES S A-RB

ANT-L



(51RH741000U)

Please note that the number of adjusting washers may not be the same as shown in the exploded views. (Adjustment will vary with each individual product.)

Part No.	Description	Part No.	Description	Part No.	Description	
BNT0015	Drag Spring Washer	BNT4034	Anti-Thrust Washer	BNT4733	Screw	
BNT0032	Bearing Retainer	BNT4036	Line Guide Pawl	BNT4734	Screw	
BNT0060	Spacer	BNT4116	Screw	BNT4735	Worm Bushing B	
BNT0623	Screw	BNT4187	Ball Bearing	BNT4737	Spool Assembly	
BNT0664	Spacer B	BNT4194	Ball Bearing	BNT4738	Brake Shoe M	
BNT0686	E Lock	BNT4316	Screw	BNT4739	Brake Ring Gear	
BNT1302	Screw	BNT4389	Yoke Spring	BNT4740	Screw	
BNT1671	Washer	BNT4416	Yoke	BNT4742	Washer	
BNT1672	E Lock	BNT4417	Clutch Cam	BNT4744	Brake Case Washer	
BNT1696	Cast Control Spacer	BNT4431	Washer	BNT4745	Screw	
BNT2120	Click Plate Retainer	BNT4613	Handle Knob Seal	BNT4747	BR Dial Gear	
BNT2122	Click Pin	BNT4661	Handle Knob	BNT4748	Idle Gear	
BNT2123	Click Spring	BNT4672	Clutch Pawl	BNT4758	Handle Nut	
BNT2127	Star Drag Spacer	BNT4693	Handle Nut Plate	BNT4759	Handle Assembly	
BNT2128	Bearing Washer	BNT4695	Handle Knob Pipe	BNT4760	Star Drag	
BNT2144	Washer	BNT4696	Handle Shank Assembly	BNT4761	Star Drag Nut	
BNT2253	Screw	BNT4699	Star Drag Spring	BNT4762	Clutch Button Attachment	
BNT2717	E Lock	BNT4702	Cast Control Cap	BNT4763	Left Side Plate	
BNT2819	Washer	BNT4703	Retainer Sheet	BNT4764	Drive Gear	
BNT3036	Level Wind Guard	BNT4704	Cast Control Click Plate	BNT4765	Drive Shaft	
BNT3076	O Ring	BNT4705	Cast Control Click Holder	BNT4766	Pinion Gear	
BNT3217	Idle Gear	BNT4706	Cast Control Cap Assembly	BNT4767	Clutch Plate	
BNT3219	Idle Gear	BNT4707	Bearing Spacer	BNT4768	Clutch Guard	
BNT3481	Drag Washer	BNT4708	Damper Spring	BNT4769	Clutch Bar Guide B	
BNT3548	Drag Washer	BNT4710	Roller Clutch Inner Tube	BNT4770	Quick-Fire II Clutch Bar	
BNT3577	Clutch Pawl Spring	BNT4713	Drive Shaft Retainer	BNT4771	Level Wind Protector	
BNT3623	Cast Control Cap Retainer	BNT4714	Ball Bearing	BNT4772	Thumb Rest	
BNT3627	Ball Bearing	BNT4715	Worm Bushing A	BNT4773	One-Piece Frame	
BNT3744	Screw	BNT4716	Worm Shaft	BNT4774	Brake Case	
BNT3748	Screw	BNT4717	Stabilizer Bar	BNT4775	Side Plate Cam Lever	
BNT3814	Key Washer	BNT4719	Clutch Cam Retainer	BNT4776	BR Dial	
BNT3816	Anti-Reverse Ratchet	BNT4720	Clutch Pawl Bushing	BNT4777	Right Side Plate	
BNT3825	Screw	BNT4723	Screw	BNT5021	Roller Clutch Bearing	
BNT3918	Washer	BNT4726	Screw	BNT5860	Star Drag Click	
BNT3927	Ball Bearing	BNT4728	Pawl Cap			
BNT3936	Click Spring	BNT4729	O Ring	BNT3660	Reel Wrench	(accessory)
BNT3937	Click Pin	BNT4730	Line Guide	BNT4692	B-100 Oil	(accessory)
BNT4033	Washer	BNT4731	Spacer	BNT4750	Brake Shoe S	(accessory)

(191212)_003