Parts List

QUANTUM ACCURIST AC500CX/AC400C/AC500PT PART LIST									
		Part No.					Part No.		
Key #	Description	AC500CX	AC400C	AC500PT	Key #	Description	AC500CX	AC400C	AC500PT
1	Palm Side Cover Assembly	HV323-01	HV323-02	HV323-03	40	Kick Lever	HV077-01	⇦⇦⇦	⇦⇦⇦
2	Palm Side Cover Locking Spring	QV096-01	⇦⇦⇦	⇦⇦⇦	41	Release Slider	HV039-01	⇦⇦⇦	⇦⇦⇦
3	Palm Side Cover Locking Pin	HV095-01	⇦⇦⇦	⇦⇦⇦	42	Release Slider Guide Pin	HV102-01	⇦⇦⇦	⇦⇦⇦
4	Palm Side Cover Release Button	HV119-01	⇦⇦⇦	⇦⇦⇦	43	Kick Lever Guide Pin	HV118-01	⇦⇦⇦	⇦⇦⇦
5	Centrifugal Dial Spring	HV108-01	⇦⇦⇦	⇦⇦⇦	44	Thumb Bar Screw	ZW053-01	⇦⇦⇦	⇦⇦⇦
6	Centrifugal Dial	HV026-01	⇦⇦⇦	⇦⇦⇦	45	Crank Shaft Bearing (L)	SW017-01	⇦⇦⇦	⇦⇦⇦
7	Spool Cover	HV051-01	⇦⇦⇦	⇦⇦⇦	46	Crank Shaft Retainer	QW120-01	⇦⇦⇦	⇦⇦⇦
8	Spool Cover Screw	QV125-02	⇦⇦⇦	⇦⇦⇦	47	E-Clip	HV002-01	⇦⇦⇦	⇦⇦⇦
9	Spool Shaft Washer	QW032-04	⇦⇦⇦	⇦⇦⇦	48	Crank Shaft Retainer Screw	QV125-02	⇦⇦⇦	⇦⇦⇦
10	Spool Shaft Bearing (Palm)	QV017-01	⇦⇦⇦	⇦⇦⇦	49	Crank Shaft	HV008-01	⇦⇦⇦	⇦⇦⇦
11	Clip Ring	HV080-01	⇦⇦⇦	⇦⇦⇦	50	O/S Drive Gear	ZW112-01	⇦⇦⇦	⇦⇦⇦
12	Spool Assembly	HV321-01	HV321-02	BX321-01	51	Trip Ratchet	QW083-01	⇦⇦⇦	⇦⇦⇦
13	Clip Ring	HV080-01	⇦⇦⇦	⇦⇦⇦	52	Trip Ratchet Washer	QW111-01	⇦⇦⇦	⇦⇦⇦
14	Spool Shaft Bearing (Gear)	JX108-01	⇦⇦⇦	⇦⇦⇦	53	Drive Gear	HV012-01	XV012-01	HV012-01
15	E-Clip	NX092-01	⇦⇦⇦	⇦⇦⇦	54	Drag Disc	HV059-01	⇦⇦⇦	⇦⇦⇦
16	E-Clip	NX092-01	⇦⇦⇦	⇦⇦⇦	55	Drag Key Washer	HV045-01	⇦⇦⇦	⇦⇦⇦
17	Frame	HV001-01	⇦⇦⇦	⇦⇦⇦	56	Link	HV038-01	⇦⇦⇦	⇦⇦⇦
18	Thumb Bar	HV009-01	⇦⇦⇦	⇦⇦⇦	57	One Way Bearing Sleeve	HV052-01	⇦⇦⇦	⇦⇦⇦
19	E-Clip	NX092-01	⇦⇦⇦	⇦⇦⇦	58	Gear Side Cover Assembly	HV324-01	HV324-02	HV324-06
20	Worm Shaft Washer	QW035-03	⇦⇦⇦	⇦⇦⇦	59	Gear Side Cover Screw	BV123-02	BV123-01	⇦⇦⇦
21	Worm Shaft Bushing (Palm)	HV067-01	⇦⇦⇦	⇦⇦⇦	60	Drag Click Spring Assembly	ZW4114	⇦⇦⇦	⇦⇦⇦
22	Worm Shaft	HV072-01	⇦⇦⇦	HV072-02	61	Tension Knob O-Ring	QW101-01	⇦⇦⇦	⇦⇦⇦
23	Stablizer Bar	ZW061-01	⇦⇦⇦	⇦⇦⇦	62	Tension Knob Bearing	SW117-01	N/A	SW117-01
24	Worm Shaft Guide	HV016-01	⇦⇦⇦	⇦⇦⇦	62	Tension Knob Bushing	N/A	QW117-01	N/A
25	Hood Screw	QV125-02	⇦⇦⇦	⇦⇦⇦	63	Spool Tension Washer	QW032-04	⇦⇦⇦	⇦⇦⇦
26	Hood Assembly	HV327-01	HV327-02	HV327-03	64	Spool Cushion Washer	QW082-01	⇦⇦⇦	⇦⇦⇦
27	Line Guide Carrier Assembly	HV347-02	HV347-01	⇦⇦⇦	65	Spool Tension Knob	HV033-02	HV033-01	⇦⇦⇦
28	Line Guide Pawl	ZW008-01	⇦⇦⇦	CX008-01	65	Spool Tension Knob Assy	N/A	N/A	CX333-01
29	Line Guide Carrier Washer	BV035-01	⇦⇦⇦	⇦⇦⇦	66	Spring "D" Washer	QW046-02	⇦⇦⇦	⇦⇦⇦
30	Line Guide Carrier Screw	ZW007-01	⇦⇦⇦	⇦⇦⇦	67	Star Drag Assembly	HV355-02	HV355-01	HV355-05
31	Worm Shaft Bushing (Gear)	HV068-01	⇦⇦⇦	⇦⇦⇦	68	Handle Washer	QW054-01	⇦⇦⇦	⇦⇦⇦
32	O/S Pinion Gear	HV065-01	⇦⇦⇦	⇦⇦⇦	69	Handle Assembly	HV318-02	HV318-01	⇦⇦⇦
33	E-Clip	NX090-01	⇦⇦⇦	⇦⇦⇦	70	Handle Nut	RV003-01	⇦⇦⇦	⇦⇦⇦
34	Pinion Yoke	HV025-01	⇦⇦⇦	⇦⇦⇦	71	Handle Nut Cap	RV034-02	RV034-01	⇦⇦⇦
35	Pinion Yoke Spring	QW040-01	⇦⇦⇦	⇦⇦⇦	72	Centrifugal Dial Washer	QV111-01	⇦⇦⇦	⇦⇦⇦
36	Pinion Gear Assembly	VW311-01	ZW311-01	VW311-01	73	Brake Ring Assembly	HV342-01	⇦⇦⇦	⇦⇦⇦
37	Release Slider Spring	HV104-01	⇦⇦⇦	⇦⇦⇦	74	Brake Ring Slider Spring	QV070-01	⇦⇦⇦	⇦⇦⇦
38	Flippin Switch	HV087-02	HV087-01	⇦⇦⇦	75	Brake Ring Retainer Screw	QV076-01	⇦⇦⇦	⇦⇦⇦
39	Kick Lever Spring	QV097-01	⇦⇦⇦	⇦⇦⇦	76	Spool Tension Collar	QW081-01	⇦⇦⇦	⇦⇦⇦

www.reelschematic.com