Parts List

QUANTUM ACCURIST LEFT HAND AC501CX/AC401C/AC501PT PART LIST

Key #	Description	Part No. AC501CX	AC401C	AC501PT
1	Palm Side Cover Assembly	BX323-01	BX323-02	BX323-03
2	Palm Side Cover Locking Spring	QV096-01	⇦⇦⇦	⇦⇦⇦
3	Palm Side Cover Locking Pin	BX095-01	⇦⇦⇦	⇦⇦⇦
4	Palm Side Cover Release Button	BX119-01	⇦⇦⇦	⇦⇦⇦
5	Centrifugal Dial Spring	HV108-01	⇦⇦⇦	⇦⇦⇦
6	Centrifugal Dial	BX026-01	⇦⇦⇦	⇦⇦⇦
7	Spool Cover	BX051-01	⇦⇦⇦	⇦⇦⇦
8	Spool Cover Screw	QV125-02	⇦⇦⇦	⇦⇦⇦
9	Spool Shaft Washer	QW032-04	⇦⇦⇦	⇦⇦⇦
10	Spool Shaft Bearing (Palm)	QV017-01	⇦⇦⇦	⇦⇦⇦
11	Clip Ring	HV080-01	⇦⇦⇦	⇦⇦⇦
12	Spool Assembly	HV321-03	HV321-04	BX321-02
13	Clip Ring	HV080-01	⇦⇦⇦	⇦⇦⇦
14	Spool Shaft Bearing (Gear)	JX108-01	⇦⇦⇦	⇦⇦⇦
15	E-Clip	NX092-01	⇦⇦⇦	⇦⇦⇦
16	E-Clip	NX092-01	⇦⇦⇦	⇦⇦⇦
17	Frame	BX001-01	⇦⇦⇦	⇦⇦⇦
18	Thumb Bar	BX009-01	⇦⇦⇦	⇦⇦⇦
19	E-Clip	NX092-01	⇦⇦⇦	⇦⇦⇦
20	Worm Shaft Washer	QW035-03	⇦⇦⇦	⇦⇦⇦
21	Worm Shaft Bushing (Palm)	HV067-01	⇦⇦⇦	⇦⇦⇦
22	Worm Shaft	HV072-01	⇦⇦⇦	HV072-02
23	Stablizer Bar	ZW061-01	⇦⇦⇦	⇦⇦⇦
24	Worm Shaft Guide	HV016-01	⇦⇦⇦	⇦⇦⇦
25	Hood Screw	QV125-02	⇦⇦⇦	⇦⇦⇦
26	Hood Assembly	BX327-01	BX327-02	BX327-03
27	Line Guide Carrier Assembly	HV347-02	HV347-01	⇦⇦⇦
28	Line Guide Pawl	ZW006-01	⇦⇦⇦	CX006-01
29	Line Guide Carrier Washer	BV035-01	⇦⇦⇦	⇦⇦⇦
30	Line Guide Carrier Screw	ZW007-02	⇦⇦⇦	⇦⇦⇦
31	Worm Shaft Bushing (Gear)	HV068-01	⇦⇦⇦	⇦⇦⇦
32	O/S Pinion Gear	HV085-01	⇦⇦⇦	⇦⇦⇦
33	E-Clip	NX090-01	⇦⇦⇦	⇦⇦⇦
34	Pinion Yoke	BX025-01	⇦⇦⇦	⇦⇦⇦
35	Pinion Yoke Spring	QW040-01	⇦⇦⇦	⇦⇦⇦
36	Pinion Gear Assembly	VW311-02	ZW311-02	VW311-02
37	Release Slider Spring	BX104-01	⇦⇦⇦	⇦⇦⇦
38	Flippin Switch	BX087-02	BX087-01	⇦⇦⇦
39	Kick Lever Spring	QV097-01	⇦⇦⇦	⇦⇦⇦

Key #	Description	Part No. AC501CX	AC401C	AC501PT
40	Kick Lever	BX077-01	⇦⇦⇦	⇦⇦⇦
41	Release Slider	BX039-01	⇦⇦⇦	⇦⇦⇦
42	Release Slider Guide Pin	HV102-01	⇦⇦⇦	⇦⇦⇦
43	Kick Lever Guide Pin	HV118-01	⇦⇦⇦	⇦⇦⇦
44	Thumb Bar Screw	ZW053-01	⇦⇦⇦	⇦⇦⇦
45	Crank Shaft Bearing (L)	SW017-01	⇦⇦⇦	⇦⇦⇦
46	Crank Shaft Retainer	QW120-01	⇦⇦⇦	⇦⇦⇦
47	E-Clip	HV002-02	⇦⇦⇦	⇦⇦⇦
48	Crank Shaft Retainer Screw	QV125-02	⇦⇦⇦	⇦⇦⇦
49	Crank Shaft	HV008-02	⇦⇦⇦	⇦⇦⇦
50	O/S Drive Gear	ZW112-01	⇦⇦⇦	⇦⇦⇦
51	Trip Ratchet	QW083-01	⇦⇦⇦	⇦⇦⇦
52	Trip Ratchet Washer	QW111-01	⇦⇦⇦	⇦⇦⇦
53	Drive Gear	HV012-02	XV012-02	HV012-02
54	Drag Disc	HV059-01	⇦⇦⇦	⇦⇦⇦
55	Drag Key Washer	HV045-01	⇦⇦⇦	⇦⇦⇦
56	Link	HV036-01	⇦⇦⇦	⇦⇦⇦
57	One Way Bearing Sleeve	HV052-01	⇦⇦⇦	⇦⇦⇦
58	Gear Side Cover Assembly	BX324-01	BX324-02	BX324-03
59	Gear Side Cover Screw	BV123-02	BV123-01	⇦⇦⇦
60	Drag Click Spring Assembly	ZW4114	⇦⇦⇦	⇦⇦⇦
61	Tension Knob O-Ring	QW101-01	⇦⇦⇦	⇦⇦⇦
62	Tension Knob Bearing	SW117-01	N/A	SW117-01
62	Tension Knob Bushing	N/A	QW117-01	N/A
63	Spool Tension Washer	QW032-04	⇦⇦⇦	⇦⇦⇦
64	Spool Cushion Washer	QW082-01	⇦⇦⇦	⇦⇦⇦
65	Spool Tension Knob	HV033-02	HV033-01	⇦⇦⇦
65	Spool Tension Knob Assembly	N/A	N/A	CX333-01
66	Spring "D" Washer	QW046-02	⇦⇦⇦	⇦⇦⇦
67	Star Drag Assembly	HV355-04	HV355-03	HV355-06
68	Handle Washer	QW054-01	⇦⇦⇦	⇦⇦⇦
69	Handle Assembly	HV318-02	HV318-01	⇦⇦⇦
70	Handle Nut	RV003-02	⇦⇦⇦	⇦⇦⇦
71	Handle Nut Cap	RV034-02	RV034-01	⇦⇦⇦
72	Centrifugal Dial Washer	QV111-01	⇦⇦⇦	⇦⇦⇦
73	Brake Ring Assembly	BX342-01	⇦⇦⇦	⇦⇦⇦
74	Brake Ring Slider Spring	QV070-01	⇦⇦⇦	⇦⇦⇦
75	Brake Ring Retainer Screw	QV076-01	⇦⇦⇦	⇦⇦⇦
76	Spool Tension Collar	QW081-01	⇦⇦⇦	⇦⇦⇦

www.reelschematic.com