



411 West Congress St., Maple Lake, MN 55358 Toll Free 877-466-8837 [www.rhinomade.com](http://www.rhinomade.com)

### ASSEMBLY INSTRUCTIONS FOR SMALL ATV MONSTER BOX

Parts List:	Tools	Required:
Square U-Bolts (2)		Drill with 5/16" bit
Flat Strap (2)		Marker to layout holes
1/4" Nylock Nuts (4)		7/16" Wrench

#### Installation:

1. Set and square Monster Box (item 5) on rack (item 4) of ATV.
2. Layout holes (one on each side of bar) to be drilled in bottom of box, according to rack Configuration. (Best to use outside edge bars for ease of assembly).
3. Hole centers should be 1 1/2" apart to fit u-bolts provided.
4. Drill 5/16 holes through the box
5. Slide U-Bolts (item 1) through box and around bar.
6. Slide Flat Strap (item 2) up on U-Bolt
7. Tighten 1/4" Nylock Nuts (item 3) down to Flat Strap.

