

## MODEL: ABU SP EMAXSP20

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1488099	39	BUSHING	1404814
2	STOP RING	1488053	40	WASHER	1207718
3	KEY WASHER (2REQ)	1446956	41	SCREW (3REQ)	1210692
4	EARED WASHER	1446957	42	BEARING COVER	1378806
5	DRAG WASHER	1225637	43	BEARING (4REQ)	1378807
6	SPOOL	1488116	44	BEARING SLEEVE	1488070
6A	SPOOL ASSY	1488117	45	ONE WAY CLUTCH	1380128
7	LINE CLIP SPRING	1378772	46	CLUTCH SPRING	1378810
8	LINE CLIP	1488056	47	PINION GEAR ASSY	1488107
9	SPOOL CLICK	1446960	48	BUSHING	1488072
10	SPOOL SPRING	1214415	49	SCREW	1380156
11	SCREW	1216396	50	N-R CAM	1488108
12	SHEET WASHER	1201745	51	SCREW	1488074
13	CLICK GEAR	1446961	52	SWITCH SPRING	1378885
14	SPOOL SHAFT WASHER	1378777	53	IAR SWITCH	1488109
15	MAIN SHAFT	1488102	54	DUST CAP	1488076
16	SCREW	1378779	55	SCREW (6REQ)	1378818
17	BAIL HOLDER	1488093	56	BEARING RETAINER (2REQ)	1488110
18	BAIL WIRE ASSY	1488118	57	SIDE COVER	1488111
19	LOWER BUSHING	1380122	58	DRIVE GEAR	1380133
20	UPPER BUSHING	1380123	59	SHIM	1378824
21	LINE ROLLER	1488060	60	HANDLE ASSY	1488112
22	BEARING	1200781	61	O/S SLIDER	1409748
23	LINE ROLLER COLLAR	1378846	62	SCREW	1395731
24	SCREW	1488062	63	O/S GEAR PIN	1378827
25	BAIL ARM	1488063	64	O/S GEAR BEARING	1216643
26	SCREW	1378789	65	O/S GEAR	1403867
27	SCREW	1488064	66	O/S GEAR BUSHING	1378829
28	BAIL ARM COVER	1488119	67	SCREW	1395732
29	BAIL ARM SPRING	1378792	68	UPPER O/S SLIDER GUIDE	1488081
30	SPRING SEAT	1378793	69	LOWER O/S SLIDER GUIDE	1488082
31	PIVOT LEVER	1378794	70	TRANSFER GEAR	1403857
32	TRIP PLUNGER	1488120	71	REAR COVER	1488122
33	ROTOR BRAKE	1378796	72	BODY ASSY	1488123
34	ROTOR BRAKE SPRING	1378797	73	HANDLE SUB-ASSY	1488115
35	ROTOR	1488121	74	BUSHING (2REQ)	1438531
36	ROTOR NUT	1488068	75	T KNOB	1446970
37	ROTOR NUT WASHER	1378802	76	SCREW	1241728
38	SCREW	1378803	77	HANDLE KNOB COVER	1446971

### EXPLODED VIEW

