



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	F09-9403	L/S OUTER RING	48	E31-5403	CAST CONTROL CAP
2	F09-3602	L/S PLT SCREW	49	F73-3501	DRIVE SHAFT WASHER A
3	F78-8503	L/S PLT	50	B73-8001	BUSHING
4	E36-1302	CLICK BUTTON	51	G29-1001	DRIVE SHAFT
5	373-1602	CLICK BUTTON WASHER	52	F09-8401	DRIVE SHAFT RET
6	030-6222	CLICK PAWL	53	E31-6701	DRIVE SHAFT RET SCREW
7	320-1402	CLICK PAWL RET	54	F65-7801	O RING B
8	F13-2602	SPACER A	55	F55-5102	A/R RATCHET
9	375-7411	BEARING WASHER A	56	F73-3701	DRIVE SHAFT WASHER B
10	160-7922	CLICK SPRING	57	F73-3801	DRIVE GEAR
11	F13-1801	CLICK SPRING RET	58	F87-7501	DRAG WASHER
12	B83-4402	CLICK SPRING SCREW	59	E31-7001	KEY WASHER
13	G28-9901	SPOOL	60	E31-7101	EARED WASHER
14	637-2101	BALL BEARING A	61	F65-7801	O RING C
15	B35-2801	BRAKE COLLAR A	62	F73-3901	WATER SHIELD
16	B35-2701	BRAKE COLLAR B	63	F94-7401	COLLAR B
18	F73-6804	STABILIZER BAR	64	F82-7801	HANDLE METAL PLT
19	F77-4701	COLLAR A	65	E24-8101	HANDLE METAL PLT SCREW
20	F21-6201	BEARING RET A	66	F82-7101	SPACING SLEEVE
21	F05-5503	BALL BEARING B	67	F82-7601	HANDLE METAL
22	F94-7101	SPACER B	68	F36-6802	HANDLE METAL COLLAR
23	G28-9701	FRAME	69	F05-5502	BALL BEARING D
24	F09-7901	YOKE PLT	70	F36-6803	BEARING WASHER B
25	E25-2102	YOKE	71	E25-3501	DRAG SPRING WASHER
26	E03-7706	YOKE WASHER	72	F17-0501	CLICK LEAF SPRING HOLDER
27	F93-5201	YOKE SPRING	73	B74-7702	CLICK LEAF SPRING
28	F09-8201	A/R PAWL PIN	74	F55-0419	STAR DRAG
29	F77-4401	A/R PAWL SPRING	75	E25-3901	FRICITION WASHER
30	F73-3401	A/R PAWL	76	F97-6001	HANDLE
31	F94-7201	PINION GEAR	77	B86-2102	HANDLE NUT
32	B09-5601	BEARING RET B	78	F47-1207	HANDLE NUT PLT
33	F79-8402	BALL BEARING C	79 *	F18-7701	ROD BRACE NUT
34	F09-7301	CLUTCH CAM	80 *	041-5601	ROD CLAMP
35	F38-5801	CLUTCH SPRING	81 *	F18-7801	CLAMP NUT
36	F94-6704	R/S PLT	82 *	F18-7601	CLAMP BOLT
37	E42-6812	CLUTCH LEVER			
38	160-8001	CLUTCH LEVER LOCK WASHER			
39	E00-7601	CLUTCH LEVER SCREW			
40	F09-7204	R/S OUTER RING			
41	F09-3602	R/S PLT SCREW A			
42	F73-4301	R/S PLT SCREW B			
43	B05-5201	O RING A			
44	F94-6901	PINION SHAFT			
45	F73-2801	PIN			
46	375-7501	SPACER C			
47	B17-5503	SPACER D			

GW-Z50HW SPECIAL PARTS

Key No.	Parts No.	Parts Name
3	F78-8504	L/S PLT
13	G29-0101	SPOOL
18	F09-9304	STABILIZER BAR
23	G29-0001	FRAME
36	F94-6705	R/S PLT
83	E31-8302	ROD CLAMP
84	E31-8401	CLAMP BOLT

(*) Parts for GW-Z40HW only