


OPUS PLUS 4500/5000



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	W39-0001	BODY	41	W31-1701	BAIL TRIP LEVER SPRING
2	W30-6401	HANDLE LOCK SCREW WASHER	42	W39-2801	BAIL TRIP LEVER COLLAR
3	W39-0101	HANDLE SCREW	43	W39-2901	BAIL TRIP LEVER
4	W39-0201	REAR COVER	44	W31-1801	BAIL TRIP LEVER WASHER
5	W39-0301	REAR COVER SCREW	45	W39-3001	BAIL TRIP LEVER SCREW
6	W36-0301	A/R LEVER	46	W39-3101	BAIL SPRING HOLDER
7	W36-0401	A/R LEVER SCREW	47	W39-3201	BAIL SPRING
8	W30-5601	OSC GEAR COLLAR	48	W39-3301	BAIL SPRING SHAFT
9	W30-5401	OSC GEAR	49	W39-3401	BAIL SPRING COVER
10	W30-5301	OSC SLIDER	50	W36-7401	BAIL SPRING COVER SCREW
11	W30-5101	OSC SLIDER SCREW	51	W36-7601	LINE ROLLER SCREW
12	W30-5001	OSC SLIDER HOLDING PLT	52	W36-7501	BAIL ARM SCREW
13	W39-0601	OSC SLIDER HOLD PLT SCREW	53	W39-3501	BAIL ARM
14	W30-3501	BALL BEARING A	54	W30-6201	LINE ROLLER WASHER B
15	W39-0701	A/R CAM SPRING	55	W36-8001	BALL BEARING D
16	W30-3401	DRIVE GEAR	56	W36-8101	LINE ROLLER
17	W30-4401	DRIVE GEAR WASHER	57	W30-6101	LINE ROLLER WASHER A
18	W30-3901	BALL BEARING B	58	W39-3601	BAIL
19	W39-0801	SIDE COVER	59	W36-7501	BAIL HOLDER SCREW
20	W39-0901	SIDE COVER SCREW A	60	W36-7401	BAIL HOLDER COVER SCREW
21	W39-1001	SIDE COVER SCREW B	61	W39-3701	BAIL HOLDER COVER
22	W39-1101	HANDLE	62	W30-8201	ROTOR NUT HOLD PLT
23	W39-1201	A/R PAWL SPRING A	63	W30-8701	ROTOR NUT
24	W39-1301	A/R PAWL A	64	W30-6501	ROTOR NUT WASHER
25	W39-1401	A/R PAWL A SCREW	65	W36-8901	ROTOR NUT HOLD PLT SCREW
26	W39-1501	A/R CAM	66	W39-3801	MAIN SHAFT
27	W39-1601	A/R PAWL B	67	W39-3901	CLICK GEAR
28	W39-1701	PINION GEAR	68-72	W39-4001	SPOOL
29	W39-1801	PINION WASHER	68-72	W39-4021	SPOOL (EXTRA)
30	W30-1501	BALL BEARING C	69	W36-9601	DRAG WASHER
31	W39-1901	BEARING RET	70	W36-9701	KEY WASHER
32	W30-9501	BEARING RET SCREW	71	W36-9801	EARED WASHER
33	W39-2001	SPACING SLEEVE	72	W36-9901	DRAG WASHER RET
34	W39-2101	BALL BEARING WASHER	73	W36-9501	DRAG KNOB
35	W39-2201	ROLLER CLUTCH			
36	W39-2301	ROLLER CLUTCH WASHER			
37	W39-2401	COLLAR A			
38	W39-2501	COLLAR B			
39	W39-2601	A/R PAWL SPRING B			
40	W39-2701	ROTOR			

SPECIAL PART FOR OPP5000

Key No.	Parts No.	Parts Name
68-72	W39-4002	SPOOL
68-72	W39-4022	SPOOL (EXTRA)