



Key No.	Parts No.	Parts Name	Key No.	Parts No.	Parts Name
1	6W3900520	Body	41	6W3117010	Bail Trip Lever Spring
2	6W3064010	Washer (A)	42	6W3928010	Collar (C)
3	6W3901010	Handle Screw	43	6W3929020	Bail Trip Lever
4	6W3902520	Rear Cover	44	6W3118010	Washer (F)
5	6W3903010	Screw (A)	45	6W3930010	Screw (I)
6	6W3603010	Anti-Reverse Lever	46	6W3931010	Bail Spring Holder
7	6W3604010	Screw (B)	47	6W3932020	Bail Spring
8	6W3056010	Bushing (A)	48	6W3933020	Bail Spring Shaft
9	6W3055010	Oscillating Gear	49	6W3934520	Cover (A)
10	6W3052010	Oscillating Slider	50	6W3674010	Screw (J)
11	6W3051010	Screw (C)	51	6W3676010	Screw (K)
12	6W3050010	Plate	52	6W3675010	Screw (L)
13	6W3906010	Screw (D)	53	6W3935020	Bail Arm
14	6W3037010	Bushing (B)	54	6W3062010	Collar (D)
15	6W3907020	Anti-Reverse Cam Spring	55	6W3680510	Bushing (D)
16	6W3033010	Drive Gear	56	6W3681010	Line Roller
17	6W3043010	Washer (B)	57	6W3061010	Washer (G)
18	6W3041010	Bushing (C)	58	6W3936520	Bail Assembly
19	6W3908520	Side Cover	59	6W3675010	Screw (M)
21	6W3910010	Screw (F)	60	6W3674010	Screw (N)
22	6W3911520	Handle Assembly	61	6W3937520	Cover (B)
23	6W3912010	Anti-Reverse Pawl Spring (A)	62	6W3082010	Washer (H)
24	6W3913010	Anti-Reverse Pawl (A)	63	6W3087010	Rotor Nut
25	6W3914010	Screw (G)	64	6W3065010	Rotor Nut Holding Plate
26	6W3915510	Anti-Reverse Cam	65	6W3689010	Screw (O)
27	6W3916010	Anti-Reverse Pawl (B)	66	6W3938510	Main Shaft
28	6W3917510	Pinion Gear	67	6W3939010	Click Gear
30	6W3015010	Ball Bearing	68-72	6W3940530	Spool Assembly
31	6W3919020	Bearing Retainer	69	6W3696010	Drag Washer
32	6W3095010	Screw (H)	70	6W3697010	Key Washer
33	6W3920010	Spacing Sleeve	71	6W3698010	Eared Washer
34	6W3921010	Washer (D)	72	6W3699010	Drag Washer Retainer
35	6W3922010	Roller Clutch	73	6W3695010	Drag Knob Assembly
36	6W3923010	Washer (E)			
37	6W3924010	Collar (A)			
38	6W3925010	Collar (B)			
39	6W3926020	Anti-Reverse Pawl Spring (B)			
40	6W3927520	Rotor			

OPUS 6000 SPECIAL PARTS

Key No.	Parts No.	Parts Name
68-72	6W3940540	Spool Assembly