


# CONVENTIONAL REEL

SAGLD10H

\*Please order by parts number, not key number.



Key No	Part No	Description
1	E77-1201	FRAME
2	E67-0012	FRAME PLATE
3	E73-0001	FRAME PLATE SCREW
4	G21-1701	FRAME PIN
5	E77-0301	SPOOL
6	E76-6901	DRAG WASHER
7	E77-0401	MAIN SHAFT
8	E57-8301	BEARING WASHER
9	E64-1201	DRAG SPRING WASHER
10	G53-6001	SPOOL BALL BEARING (A)
11	E76-7302	DRAG CLICK CAP
12	E64-3802	DRAG CLICK CAP SCREW
13	G49-8511	SPOOL BALL BEARING (B)
14	E66-5501	TENTION SPRING
15	G53-6001	SPOOL BALL BEARING (C)
16	E66-5602	DRAG PLATE
17	E66-6001	DRAG WASHER COVER
18	E66-8901	DRAG WASHER COVER SCREW
19	E66-5801	DRAG WASHER COVER PACKING
20	E64-1601	MAIN SHAFT PIN
21	E77-0002	RIGHT SIDE PLATE
22	E68-7801	ONEWAY CLUTCH
23	G47-2501	DRIVE SHAFT BALL BEARING
24	E77-0701	DRIVE SHAFT
25	E64-9201	DRIVE SHAFT PIN
26	E64-9301	DRIVE SHAFT BEARING WASHER
27	E64-9301	DRIVE GEAR WASHER
28	E77-0801	DRIVE GEAR
29	E68-7201	DRIVE SHAFT NUT
30	E64-4301	DRAG LEVER STOPPER COLLAR

Key No	Part No	Description
31	E59-1601	DRAG LEVER STOPPER SCREW
32	E76-7401	CLICK GEAR
33	E17-5802	PINION BALL BEARING
34	E77-2201	PINION GEAR
35	E65-6701	PINION METAL
36	E76-7801	ANTI REVERSE RATCHET
37	E76-7901	ANTI REVERSE PAWL PIN
38	E64-3501	ANTI REVERSE PAWL
39	E64-3701	ANTI REVERSE PAWL RETAINER
40	E64-3801	ANTI REVERSE PAWL SCREW
41	E76-8001	DRAG LEVER WASHER
42	E73-9102	SIDE PLATE SCREW
43	E76-8101	DRAG LEVER
44	E75-9401	CLICK PAWL
45	M16-3301	CLICK PAWL SPRING
46	E72-8201	CLICK PAWL COLLAR
47	E76-8401	PRESET CAM (A)
48	E76-8501	BUSHING
49	E76-8701	BUSHING RETAINER
50	E76-8901	PRESET CAM (B)
51	E76-8801	PRESET CAM (B) O RING
52	E76-9001	CLICK LEAF SPRING
53	E76-9201	DRAG KNOB SPRING
54	E76-9101	PRESET DRAG KNOB
55	G52-2801	HANDLE BALL BEARING
56	E66-8101	HANDLE CAP
57	E77-0901	HANDLE ASSEMBLY
58	E76-0301	HANDLE NUT
59	G21-8201	HANDLE LOCK SCREW