


CONVENTIONAL REEL

SAGLD35JH

*Please order by parts number, not key number.



Key No Part No Description

1	E76-4601	FRAME
2	E76-3103	FRAME PLATE
3	F50-5703	FRAME PLATE SCREW
4	E73-2501	FRAME PIN
5	E76-4901	SPOOL
6	E76-3301	DRAG WASHER
7	E76-5001	MAIN SHAFT
8	E73-1001	BEARING WASHER
9	E73-1201	DRAG SPRING WASHER
10	H42-8701	SPOOL BALL BEARING (A)
11	G53-6001	SPOOL BALL BEARING (B)
12	E73-6701	TENTION SPRING
13	F81-2104	SPOOL BALL BEARING (C)
14	E73-6901	DRAG METAL
15	351-1008	DRAG METAL SCREW
16	E76-3601	DRAG PLATE
17	E76-3701	DRAG WASHER COVER
18	E73-7201	DRAG WASHER COVER SCREW
19	E73-1601	DRAG WASHER COVER PACKING
20	E73-7301	MAIN SHAFT PIN
21	E76-5201	RIGHT SIDE PLATE
22	E68-7801	ONEWAY CLUTCH
23	E73-1701	DRIVE SHAFT
24	F64-1602	DRIVE SHAFT BALL BEARING
25	E74-2401	DRIVE SHAFT PIN
26	G20-5501	DRIVE SHAFT BEARING WASHER
27	E68-7002	DRIVE GEAR WASHER
28	E76-5301	DRIVE GEAR
29	E68-7201	DRIVE SHAFT NUT
30	E75-9601	PUSH BUTTON
31	E68-6201	PUSH BUTTON SPRING
32	B33-9801	PUSH BUTTON RETAINER

Key No Part No Description

33	E64-4301	DRAG LEVER STOPPER COLLAR
34	E59-1601	DRAG LEVER STOPPER SCREW
35	E75-8201	CLICK GEAR
36	E68-5601	PINION BALL BEARING
37	E76-5401	PINION GEAR
38	E76-5501	PINION METAL
39	E73-1901	ANTI REVERSE RATCHET
40	E75-9001	ANTI REVERSE PAWL PIN
41	E75-9301	ANTI REVERSE PAWL
42	E76-1101	ANTI REVERSE PAWL RETAINER
43	E64-3802	ANTI REVERSE PAWL SCREW
44	E73-2101	DRAG LEVER WASHER
45	E73-9101	SIDE PLATE SCREW
46	E76-5701	DRAG LEVER
47	E75-9501	DRAG LEVER COLLAR
48	E75-9401	CLICK PAWL
49	M16-3301	CLICK PAWL SPRING
50	E72-8201	CLICK PAWL COLLAR
51	E76-2001	PRESET CAM (A)
52	E73-1101	BUSHING
53	E73-9801	BUSHING RETAINER
54	E73-9001	PRESET CAM (B)
55	E72-9001	PRESET CAM (B) O RING
56	E68-4801	CLICK LEAF SPRING
57	H48-4801	DRAG KNOB SPRING
58	E74-0201	PRESET DRAG KNOB
59	G52-2801	HANDLE BALL BEARING
60	E75-9701	HANDLE CAP
61	E76-5801	HANDLE ASSEMBLY
62	E76-0301	HANDLE NUT
63	G21-8201	HANDLE LOCK SCREW