



PARTS LIST OF MITCHELL COPPERHEAD 2000T

NO.	DESCRIPTION	MCH2000T	NO.	DESCRIPTION	MCH2000T
1	DRAG KNOB ASSY	1152516	35	SCREW	1102139
2	RETAINER RING	1085295	36	SILENT RING	1109423
3	KEY WASHER	1085296	37	CENTER HUB	1109424
4	EARED WASHER	1085297	38	WASHER	1102186
5	WASHER	1128342	39	BALL BEARING	1085280
6	SPOOL ASSY	1152517	40	PINION GEAR	1102145
7	CLICK GEAR	1117946	41	SCREW	1109425
8	CLICK SPRING	1117947	42	SCREW	1109426
9	"O" RETAINER	1117948	43	CLUTCH	1109427
10	CLICK GEAR WASHER	1102115	44	SPRING	1109428
11	CLICK GEAR	1085271	45	SPRING	1102147
12	MAIN SHAFT	1102116	46	ANTI-REVERSE PIN	1113426
13	ROTOR	1152518	47	ANTI-REVERSE BUTTON	1152523
14	ROTOR COVER	1152519	48	SCREW	1092777
15	ROTOR NUT	1085273	49	BODY	1152524
16	SCREW	1085900	50	HANDLE SCREW CAP	1152525
17	SCREW	1109413	51	WASHER	1092781
18	TRIGER	1109414	52	BALL BEARING	1092725
19	SPRING	1109415	53	DRIVE GEAR	1085286
20	ROTOR COVER	1152520	54	WASHER	1085287
21	BAIL ARM	1109417	55	BALL BEARING	1085344
22	SCREW	1109418	56	OSCILLATION GEAR	1102167
23	SCREW	1085322	57	WASHER	1098662
24	LINE ROLLER BUSHING	1098664	58	BUSHING	1102169
25	LINE ROLLER	1092773	59	SCREW	1092783
26	BALL BEARING	1085326	60	SLIDER	1102170
27	LINE ROLLER BUSHING	1085327	61	SCREW	1085341
28	BAIL ASSY	1152521	62	BODY COVER	1152526
29	BUSHING	1102129	63	SCREW	1102175
30	SCREW	1102128	64	SCREW	1085342
31	BAIL LEVER	1109420	65	HANDLE	1152527
32	SPRING	1109421	66	REAR COVER	1152528
33	BAIL LEVER	1109422	67	SCREW	1102182
34	ROTOR COVER	1152522			