



NO	PARTS DESCRIPTION	M300	M308
11	BUSHING(2)	1188261	1308736
12	ROTOR	1308723	1308714
13	BAIL TRIP LEVER	1308698	126272
14	BAIL ARM SPRING GUIDE	1126272	1252713
15	BAIL ARM SPRING SHAFT	1252713	1308737
16	BAIL ARM COVER	1308737	119106
17	BAIL ARM SPRING	119106	1125962
18	BAIL ARM COVER SCREW	1125962	1308716
19	BAIL WIRE	1308716	1112125
20	ROLLER BALL BEARING(2)	1112125	1252705
21	LINE ROLLER	1252705	1110165
22	ROLLER WASHER	1110165	1308725
23	BAIL ARM	1308725	1126261
24	ROLLER SCREW	1126261	1102139
25	BODY HEAD COVER SCREW	1102139	1308726
26	BODY HEAD COVER	1308726	1114764
27	ONE WAY CLUTCH WASHER	1114764	1122123
28	ONE WAY CLUTCH SCREW(3)	1122123	1308727
29	ONE WAY CLUTCH COVER	1308727	1252717
30	BALL BEARING(4)	1252717	1280475
31	ONE WAY CLUTCH SUPPORT	1280475	1102144
32	ONE WAY CLUTCH ASSY (including sleeve)	1102144	1308704
33	A/R PULLING SPRING	1308704	1308728
34	PINION GEAR	1308728	1131798
35	A/R SWITCH SCREW	1131798	1279733
36	A/R SWITCH BUSHING	1279733	1252722
37	A/R SPRING	1252722	1308729
38	A/R SWITCH	1308729	1252732
39	REDUCTION GEAR	1252732	1279734
40	MAIN GEAR	1279734	1114764
41	MAIN GEAR WASHER	1114764	1308730
42	SIDE COVER ASSY	1308730	1117984
43	SIDE COVER SCREW	1117984	1308755
44	SIDE COVER SCREW(3)	1308755	1308731
45	HANDLE ASSY	1308731	1188428
46	SCREW(2)	1188428	1121651
47	SLIDE CLIP	1121651	1266332
48	SLIDE SCREW	1266332	1279756
49	SLIDE	1279756	1085326
50	OSCILLATION GEAR BALL BEARING	1085326	1253701
51	OSCILLATION GEAR	1253701	1092781
52	HANDLE RETRIEVE WASHER	1092781	1308732
53	HANDLE SCREW	1308732	1308733
54	MAIN BODY ASSY	1308733	1308734
55	REAR COVER	1308734	

NO	PARTS DESCRIPTION	M300	M308
1	DRAG KNOB ASSY	1308720	1308720
2	SPOOL ASSY	1308721	1308735
3	MAIN SHAFT WASHER	1178949	1178949
4	MAIN SHAFT RATCHET	1126316	1126316
5	MAIN SHAFT	1308694	1279725
6	ROTOR RETAINER SCREW	1131700	1308695
7	ROTOR RETAINER PLATE	1308695	1308695
8	ROTOR NUT	1085273	1085273
9	ROTOR ARM SCREW(2)	1308754	1308754
10	BAIL HOLDER	1308722	1308722