



DMG - 15 Spare Parts

key no	new part no	old part no	parts name	lot no	key no	new part no	old part no	parts name	lot no
100	11000650		MAIN BODY		704	17040024	11704015-03001	LINE GUIDE SUPPORT BAR	
102	11020037	11102005-06005	BODY FOOT		705	17050011	11705006-06	TRANSMISSION GEAR	
105	11050006	11105003-01	WORM SHAFT BUSHING		706	17060003	11706002-06	TRANSMISSION GEAR	
105-1	11050007	11105004-01	WORM SHAFT BUSHING		707	17070009	11707008-11	TRANSMISSION GEAR	
117	11170012	11117007-03001	NUT		708	17080003	11708003-11	TRANSMISSION GEAR	
200	12000930		MAIN SIDE PLATE		709	17090004	11709002-03	TRANSMISSION GEAR BUSHING	
201	12010011	11201008-06	ANTI-RE PAWL		710	17100044	1171001206917	LINE GUIDE ASSY.	
207	12070052	11207017-03001	HOLDED PLATE		712	17120049		WORM SHAFT	
211	12110009	11211003-03001	ANTI-RE PAWL PIN		713	17130001	11713001-03907	LINE GUIDE PAWL CAP	
212	12120009	1121200101	COUNTER COVER		715	17150008	11715003-06001C	LINE GUIDE PAWL	
215	12150015	11215011-03001	HOLD PLATE BUSHING		720	17200002	11720002-06001	DRIVE GEAR SHAFT BUSHING	
216	12160001	11216001-06	ANTI-RE PAWL SPRING		800	18000008	11800002-12002	CLUTCH CAM	
216-1	12160003	11216002-06	ANTI-RE PAWL SPRING		801	18010001	11801001-06	CLUTCH SPRING	
219	12190013	11219011-03	SIDE PLATE BUSHING		802	18020038	11802005-01	CLUTCH BAR	
219-1	12190020	11219017-03001	SIDE PLATE BUSHING		804	18040005	11804005-06	CLUTCH SLIDER	
221	12210001	11221001-07	"O"RING		805	18050002	11805002-01	PINION GEAR YOKE	
224	12240004	11224001-02905	ONE WAY BEARING CAP		806	18060001	11806001-06	YOKE SPRING	
300	13000464		VICE SIDE PLATE		910	19100004	11910001-01003	DEPTH COUNTER	
302	13020011	11302008-03	BUSHING		9103	0910170	01101612-63	BALL BEARING	
302-2	13020014	11302002-06001	WASHER		9106	0910227	01041104-61	BALL BEARING	
302-3	13020017	11302006-03	WASHER		9107	0910248	01061335-61	BALL BEARING	
303	13030047		CLICK BUTTON		9201	0920283	025.1x8x0.5-6	WASHER	
304	13040001	11304003-06	CLICK PAWL		9201-1	0920154	028.1x12x0.5-6	WASHER	
305	13050007	11305001-01003	CLICK PAWL SPRING		9202	920291	025.9x10x0.2-6	WASHER	
311	13110029	11311007-06002	SIDE PLATE COVER		9204	0920291	025.9x10x0.2-6	WASHER	
400	14000486		SPOOL		9205	0920328	028.1x22x1-1	WASHER	
401	14010026	1140101101	CLICK GEAR		9206	0920085	024.05x10x0.2-8	WASHER	
418	14180001	11418001-01001	SPOOL BEARING FIXED PLATE		9207	920066	022x4.9x0.2-3	WASHER	
500	15000168		HANDLE ASSY.		9209	0920282	025.1x8x0.2-6	WASHER	
500-1	15000103		HANDLE ASSY.		9301	0930693	03412.6x14-647	SCREW	
516	15160002	11516001-011	HANDLE NUT RETAINER		9302	0930219	03327.52.6x6-61	SCREW	
600	16000040	11600014-03002	CAST CONTROL CAP		9302-1	0930298	03422.6x13-61	SCREW	
608	16080006	11608004-06	DRAG WASHER RETAINER		9307	0930696	03412.6x4-64	SCREW	
609	16090002	11609001-06001	WASHER		9310	0930161	03213x8-61003	SCREW	
610	16100010	11610004-006	DRAG WASHER		9311	0930483	03212.6x11-647	SCREW	
610-1	16100032	11610013-000	DRAG WASHER		9312	0930210	03325.2x2x4.561	SCREW	
611	16110005	11611005-06	EARED WASHER		9314	0930501	03212x5-617	SCREW	
612	16120027	11612007-06001	KEY WASHER		9316	0930734	03414x5-647	SCREW	
612-1	46120002	14612001-06001	KEY WASHER		9319	0930196	03312x5-61	SCREW	
614	16140001	11614001-06	WASHER		9320	0930427	03122x26-64	SCREW	
615	46150015	14615002-04003C	STAR DRAG		9320-1	0930439	03122x8-64	SCREW	
617	16170009	11617007-03	DRIVE GEAR SHAFT BUSHING		9321	0930202	03319.4x3x7-61	SCREW	
700	17000210	1170000803006	DRIVE GEAR		9323	0930171	03222.6x4.5-61	SCREW	
701	17010122	1170102813001A	DRIVE GEAR SHAFT		9326	0930605	03312.6x6-617	SCREW	
702	17020310	1170203603002	PINION GEAR		9404-1	19000002	11900002-06	E RETAINER	
703	17030011	11703011-03001	WORM SHAFT GUARD		9406	29000006	12900006-06001	E RETAINER	