



MA-20DLXT PARTS LIST

| KEY NO | PARTS NO | PARTS NAME | KEY NO | PARTS NO | PARTS NAME |
|--------|----------|--------------------------|----------|----------|---------------------|
| 100 | 11001960 | Main body assy | 710 | 17100040 | Line guide assy. |
| 105 | 11050007 | Worm shaft bushing | 712 | 17120096 | Worm shaft |
| 105-1 | 11050006 | Worm shaft bushing | 713 | 17130002 | Line guide pawl cap |
| 117 | 11170012 | Retainer nut | 715 | 17150009 | Line guide pawl |
| 200 | 12002082 | Handle side plate | 800 | 18000018 | Clutch shaft |
| 201 | 12010026 | Anti-re pawl | 801 | 18010011 | Clutch spring |
| 204 | 12040016 | Compression spring | 802 | 18020156 | Clutch bar |
| 207 | 12070099 | Holed plate | 804 | 18040010 | Clutch slider |
| 211 | 12110009 | Anti-re pawl pin | 805 | 18050006 | Pinion gear yoke |
| 212 | 12120095 | Counter cover assy | 806 | 18060003 | Yoke spring |
| 215 | 12150015 | Hold plate bushing | 807 | 18070002 | Yoke braked plate |
| 215-1 | 12150029 | Hold plate bushing | 910 | 19100145 | Depth counter assy |
| 216 | 12160005 | Anti-re pawl spring | 29000001 | 29000001 | E retainer |
| 300 | 13000613 | Vice side plate | 29000006 | 29000006 | C retainer |
| 302 | 13020002 | Washer | 19000002 | 19000002 | E retainer |
| 303 | 13030048 | Click button | 0910099 | 0910099 | Ball bearing |
| 304 | 13040001 | Click pawl | 0910227 | 0910227 | Ball bearing |
| 305 | 13050007 | Click pawl spring | 0920111 | 0920111 | Washer |
| 400 | 14000308 | Spool assy. | 0920114 | 0920114 | Washer |
| 401 | 14010053 | Spool click gear | 0920126 | 0920126 | Washer |
| 500 | 15000466 | Handle assy. | 0920282 | 0920282 | Washer |
| 516 | 15160002 | Handle nut retainer | 0920076 | 0920076 | Washer |
| 600 | 16000039 | Cast control cap | 0920332 | 0920332 | Washer |
| 609 | 16090003 | Drag spring washer | 0920085 | 0920085 | Washer |
| 610 | 16100038 | Drag washer | 0920066 | 0920066 | Washer |
| 610-1 | 16100045 | Drag washer | 0920160 | 0920160 | Washer |
| 610-2 | 16100055 | Drag washer | 0920315 | 0920315 | Washer |
| 611 | 16110005 | Eared washer | 0930747 | 0930747 | Screw |
| 612 | 16120027 | Key washer | 0930058 | 0930058 | Screw |
| 612-3 | 26120056 | Key washer | 0930210 | 0930210 | Screw |
| 614 | 16140003 | Drag washer | 0930732 | 0930732 | Screw |
| 615 | 16150010 | Star darg | 0930609 | 0930609 | Screw |
| 617 | 16170002 | Drive gear shaft bushing | 0930196 | 0930196 | Screw |
| 618 | 16180002 | Washer | 0930219 | 0930219 | Screw |
| 700 | 17000213 | Drive gear | 0930426 | 0930426 | Screw |
| 701 | 17010196 | Drive gear shaft assy. | 0930618 | 0930618 | Screw |
| 702 | 17020329 | Pinion gear assy. | 0930438 | 0930438 | Screw |
| 703 | 17030008 | Worm shaft guard | 0930298 | 0930298 | Screw |
| 704 | 17040012 | Line guide support bar | 0930626 | 0930626 | Screw |
| 705 | 17050016 | Transmission gear | 0930226 | 0930226 | Screw |
| 707 | 17070011 | Transmission gear | 0940025 | 0940025 | O ring |
| 708 | 17080003 | Transmission gear | | | |