



- | | | | |
|--------------------------|----------------------|------------------------------------|-------------------------------|
| 1. Handles | 9. Drag Washer | 17. Clicker Spring | 25. Line Guide Screws |
| 2. Handle Screws | 10. Fiber Washers | 18. Clicker Spring Bushings | 26. Spool Retaining Nut |
| 3. Handle Plates | 11. Spring Washer | 19. Clicker Spring Screws | 27. Spool Shaft |
| 4. Handle Nuts | 12. Spool Assembly | 20. Reel Seat | 28. End Plate Assembly |
| 5. Handle Bushings | 13. Clicker | 21. Upper & Lower Reel Seat Screws | 29. Line Counter Drive Gear * |
| 6. Handle Plate Screws | 14. Clicker Bushing | 22. Upper & Lower Reel Seat Nuts | 30. Line Counter Window * |
| 7. Spool Retaining Screw | 15. Clicker Assembly | 23. Center Reel Seat Screws | 31. Line Counter * |
| 8. Drag Nut | 16. Clicker Screws | 24. Line Guide | * Recorder Model Only |

DEETZ
MANUFACTURING (1977) LTD.