



| No.  | PART NAME                   | No. | PART NAME                    | No.  | PART NAME                 | No.  | PART NAME                |
|------|-----------------------------|-----|------------------------------|------|---------------------------|------|--------------------------|
| 1    | Frame                       | 24  | Front Cover Screw-A          | 45   | Pinion Yoke Spring(*2)    | 66   | Star Drag                |
| 2    | Clutch Bar Plate            | 25  | Yoke Holder                  | 46   | Ratchet                   | 67   | Leaf Spring              |
| 3    | Clutch Bar Assembly         | 26  | Clutch Spring Bushing        | 47   | Ratchet Washer            | 69   | Handle Assembly          |
| 4    | Clutch Link                 | 27  | Clutch Spring                | 48   | Drive Gear                | 69-a | Handle Nut               |
| 5    | Clutch Bar Screw            | 28  | Return Pawl                  | 49   | Drag Washer(B)            | 69-b | Handle Nut Cap           |
| 6    | Clutch Bar Support          | 29  | Return Pawl Spring           | 50   | Drag Washer(D)            | 69-c | Handle Nut Cap Screw     |
| 7    | Line Guide Assembly         | 30  | Clutch Cam                   | 51   | Sleeve Washer(Optional)   | 70   | Spool Assembly(INCL.1BB) |
| 8    | Worm Shaft                  | 31  | Cam Plate                    | 52   | Sleeve                    | 71   | Brake Collar(White)(*6)  |
| 12   | Idler(S)                    | 32  | Cam Plate Screw(A)(*2)       | 53   | Right Side Cover          | 72   | Lever Plate              |
| 13   | Worm Shaft Pin              | 33  | Cam Plate Screw(B)           | 53-a | O-Ring                    | 73   | Lever Plate Spring(*4)   |
| 14   | Line Guide Pipe             | 34  | Ball Bearing                 | 54   | One Way Clutch            | 74   | Lock Lever               |
| 15   | Worm Shaft Bushing(B)       | 35  | Crank Shaft                  | 55   | Right Side Cover Screw(A) | 75   | Lock Lever Screw(*2)     |
| 16   | Worm Shaft Washer(Optional) | 36  | Idler(L)                     | 56   | Right Side Cover Screw(B) | 76   | Left Side Cover          |
| 17   | E-Ring                      | 37  | Idler(L) Washer(A)           | 57   | Right Side Cover Screw(C) | 77   | Lock Pin                 |
| 18   | Pillar                      | 38  | Bearing Plate                | 57-a | Click Plate Assembly      | 78   | Lock Pin Spring          |
| 18-a | O-Ring                      | 39  | Idler(L) Washer(B)           | 58   | Cast Control Cap          | 79   | Spool Cover              |
| 19   | Line Guide Pawl             | 40  | E-Ring                       | 59   | Tension Washer            | 80   | Spool Cover Screw(*2)    |
| 20   | Spacer(Optional)            | 41  | Crank Shaft Spacer(Optional) | 60   | Spool Spacer(B)           | 81   | Spool Spacer(A)          |
| 21   | Pawl Cap                    | 42  | Bearing Plate Screw          | 61   | Ball Bearing              | 82   | Ball Bearing             |
| 22   | Front Cover                 | 43  | Pinion Yoke                  | 62   | Bushing Retainer          | 83   | Bearing Retainer         |
| 23   | Hood Assembly               | 44  | Pinion Geart                 | 63   | Drag Spring Washer(*2)    |      |                          |