



No.	PART NAME	No.	PART NAME	No.	PART NAME	No.	PART NAME
001	Spool Assembly	22	Bail Holder Screw	44	Body Cover Screw(C)25/30	160	Rear Cover Screw
2	Main Shaft	23	Bearing Plate	48	Click Gear	173	Sleeve
3	Rotor Nut	25	Ratchet	56	Drag Assembly	174	One Way Assembly
4	Rotor Washer	26	Pinion	58	Handle Assembly	175	Washer
5	Rotor Assembly	29	Body	59	Handle Screw	176	Ball Bearing
6	Bail Holder Cover	30	Anti Reverse Cam Spring	60	Oscillating Slider	177	Spool Collar
9	Kick Lever	31	Anti Reverse Lever	63	Spool Adjust Washer	178	Stop Washer
13	Bail Spring	35	Anti Reverse Claw Adjust	64	Oscillating Slider Screw	180	Ball Bearing
14	Arm Lever Cover	36	Drive Gear	65	Anti Revers Cam	209	Pinion Collar
15	Arm Lever Cover Screw	37	Oscillating Gear	69	Anti Revers Lever Screw	210	Ball
16	Line Slider Screw	38	Drive Gear Adjust Washer	75	Bearing Plate Screw	211	Ball Spring
17	Arm Lever	39	Anti Reverse Claw	93	Ball Bearing	212	Handle Screw Cap-1
18	Line Roller Collar	41	Anti Reverse Claw Screw	94	Ball Bearing	226	Collar
19	Line Roller	43	Body Cover	148	Bail Spring Link		
20	Arm Lever Screw	44	Body Cover Screw(A)	149	Bail Spring Holder		
21	Bail Assembly	44	Body Cover Screw(B)	159	Rear Cover		