


QUANTUM[®]

BSP100PTsE





BSP100PTsE

Quantum BSP100PTsE Spinning Reel Part List

Key #	Description	Part No.	Qty.	Key #	Description	Part No.	Qty.
1	Drag Knob Assembly	RAB332-02	1	29	O-Ring	VBP164-01	1
2	Spool Kit Include	TAB420-01	1	30	Pinion Bushing "Top"	TAB214-01	1
	2A - Retaining Ring	RAB038-01	1	31	Pinion Ball Bearing	DP058-01	1
	2B - Drag Washer "D"	RAB080-01	4				
	2C - Drag Washer "B"	RAB033-01	7	32-A	One Way Clutch	VBP063-01	1
	2D - Drag Washer "A"	RAB081-01	4	32-B	Clutch Sleeve	TAB139-01	1
	2E - Spool Bushing	RAB022-02	1	33	Spacer	TAB141-01	1
	2F - Spool	TAB020-01	1	34	Ratchet	TAB060-01	2
	2G - Spool Click Spring Holder	SAB114-01	1				
	2H - Spool Click Spring	TAB069-01	1	35-A	Pinion Gear	TAB011-01	1
	2J - Spool Clicker Bushing	UAB167-01	1	35-B	Drive Gear Assembly	TAB312-01	1
	2K - Spool Clicker	TAB103-01	1	36	Pinion Bushing "Bottom"	VBQ058-01	1
	2M - Spool Clicker Screw	TAB146-01	1	37	Screw	CF107-02	2
3	Spool Adjust Washer	RAA065-01	1	38	Breaking Pad "A"	TAB145-01	1
4	Main Shaft Assembly	TAB315-01	1	39	Handle Screw Cap	RAB054-01	1
5	Screw	JX125-01	2	40	Body Assembly	TAB301-02	1
6	RotorNut Retainer	TAB118-01	1	41	Washer	TAB048-01	1
7	Rotor Nut	TAB006-01	1	42	Drain Cap	TAB238-01	1
8	Washer	TAB110-01	1	43	AR Pawl Pad	TAB122-01	1
9	Rotor Assembly	TAB309-02	1	44	Anti Reverse Pawl	TAB063-01	1
10	Rotor Bushing	RAB106-02	1	45	AR Pawl Screw	TAB111-01	1
11	E-Clip	KQ034-01	1	46	Seal	TAB262-01	2
12	Rotor Bushing	RAB106-01	1	47	Ball Bearing	CF017-02	2
13	Kick Lever Unit	TAB419-01	1	48	Drive Gear Adjust Washer	DF035-01	1
14	Rotor Cover	TAB087-01	1	49	Side Cover	TAB023-02	1
15	Rotor Cover Screw	QW053-04	2	50	Seal - Side Cover	TAB254-01	1
16	Pin	RAB042-02	1	51	Breaking Pad "B"	TAB140-01	1
17	Bushing	SAB106-01	2	52	Screw	CF107-02	2
18	Bail Assembly	TAB347-02	1	53	Side Cover Cosmetic Washer	TAB075-01	1
19	Ball Bearing	CT157-02	2	54	Side Cover Cosmetic Ring	TAB142-01	1
20	Line Roller	RAB004-01	1	55	Side Cover Screw	VBP057-03	4
21	Line Roller Washer	RAB102-01	2	56	O/S Gear Bushing	UAB158-01	1
22	Arm Lever Assembly	TAB307-02	1	57	O/S Gear Assembly	TAB353-01	1
23	Pin	RAB042-01	1	58	O/S Gear Ball Bearing	CH027-01	1
24	Washer	VBP167-01	1	59	O/S Gear Screw	VAB111-01	1
25	Screw	BAA108-02	1	60	O/S Slider Assembly	TAB325-01	1
26	Washer	XAB110-01	1	61	Main Shaft Screw	RQ100-01	2
27	Screw	JX107-03	3	62	Handle Assembly	TAB318-02	1
28	Ball Bearing Holder Assembly	RAB3190-01	1	63	Spool Click Gear	SAB103-01	1