


# SHIMANO

## Bantam

### MGL

## BTM MGL-HGR



(51RL104000X)

| #    | Part No. | Description              | #    | Part No. | Description              | #    | Part No. | Description                     |
|------|----------|--------------------------|------|----------|--------------------------|------|----------|---------------------------------|
| 0015 | 10D60    | Drag Spring Washer       | 4938 | 10B27    | Click Pin                | 5795 | 1001J    | Clutch Guard                    |
| 0032 | 10GEW    | Bearing Retainer         | 4939 | 10988    | Click Spring             | 5796 | 100QL    | Line Guide Pawl Holder Assembly |
| 0060 | 10CFW    | Spacer                   | 4956 | 10PVT    | Screw                    | 5797 | 1000Z    | Clutch Bar Guide B              |
| 0623 | 103C0    | Screw                    | 4959 | 10GFJ    | Washer                   | 5798 | 10TT2    | Clutch Lever Assembly           |
| 0664 | 1057S    | Spacer B                 | 4981 | 10LA8    | O Ring                   | 5799 | 101GQ    | Screw                           |
| 1465 | 10N1Z    | Clutch Pawl Spring       | 5109 | 10FNX    | Idle Gear                | 5800 | 103LN    | Screw                           |
| 1672 | 105NC    | E Lock                   | 5132 | 10GN1    | Washer                   | 5801 | 100Q8    | Frame Assembly                  |
| 1696 | 10896    | Cast Control Spacer      | 5189 | 10D3J    | Pressure Plate           | 5802 | 10TNF    | O Ring                          |
| 2127 | 10J1N    | Star Drag Spacer         | 5211 | 10EZE    | Bearing Pressure Spring  | 5803 | 10MD0    | Spool Clutch Pin                |
| 2128 | 105PW    | Bearing Washer           | 5218 | 10EZ7    | O Ring                   | 5804 | 1005D    | Ball Bearing                    |
| 2224 | 1085F    | Spool Tension Spacer     | 5310 | 10HJG    | Idle Gear Pin            | 5805 | 10TB0    | Spool Assembly (With Bearing)   |
| 2429 | 108WK    | O Ring                   | 5505 | 10LVJ    | Screw                    | 5806 | 10S37    | Ball Bearing                    |
| 3926 | 10G8C    | Washer                   | 5558 | 10R1Q    | Screw                    | 5807 | 1026U    | Screw                           |
| 3927 | 10EX8    | Ball Bearing             | 5560 | 10FMM    | Handle Knob Seal         | 5808 | 10TUC    | Cam Lever Retainer              |
| 4116 | 103E9    | Screw                    | 5582 | 1021G    | Drive Gear               | 5809 | 10TUB    | Br Dial Retainer Plate          |
| 4117 | 10PXY    | Bushing                  | 5641 | 10SSK    | Handle Nut Plate         | 5810 | 10TB6    | Brake Pipe Gear Assembly        |
| 4187 | 104VX    | Ball Bearing             | 5770 | 1007H    | Handle Nut               | 5812 | 1006Q    | Washer                          |
| 4194 | 105BP    | Ball Bearing             | 5771 | 10TB7    | Handle Shank Assembly    | 5813 | 1000Y    | Br Dial                         |
| 4224 | 10BN3    | Roller Clutch Inner Tube | 5772 | 10TTN    | Handle Assembly          | 5814 | 108WZ    | O Ring                          |
| 4380 | 1057X    | Retainer                 | 5773 | 1007F    | Star Drag Click Plate    | 5815 | 10TB8    | Brake Case Assembly             |
| 4389 | 104BU    | Yoke Spring              | 5774 | 1006Y    | Star Drag                | 5816 | 1006P    | O Ring                          |
| 4431 | 10G8G    | Washer                   | 5776 | 1001K    | Clutch Button Attachment | 5817 | 10073    | Washer                          |
| 4538 | 10F42    | Clutch Cam Retainer      | 5778 | 10060    | Cast Control Cap         | 5818 | 10078    | Washer                          |
| 4564 | 10LZD    | Screw                    | 5779 | 1055D    | Screw                    | 5819 | 10013    | Left Side Plate Cam Lever       |
| 4614 | 10329    | Handle Knob              | 5780 | 1005E    | Roller Clutch Bearing    | 5820 | 100KB    | Left Side Plate Assembly        |
| 4628 | 10D6Y    | Anti-Reverse Ratchet     | 5783 | 1027W    | Drag Washer              | 5837 | 1005V    | Right Side Plate                |
| 4630 | 10JDX    | Idle Gear Spring         | 5784 | 10059    | Drive Shaft              | 5838 | 1006R    | Worm Shaft                      |
| 4637 | 1046T    | Yoke                     | 5785 | 10057    | Idle Gear                | 5839 | 1006A    | Pinion Gear                     |
| 4638 | 105ZU    | Clutch Pawl              | 5786 | 10MT4    | Screw                    | 5857 | 1027V    | O Ring                          |
| 4699 | 10A71    | Star Drag Spring         | 5787 | 1005S    | Drive Shaft Retainer     | 5892 | 10211    | Line Guide Pawl                 |
| 4700 | 10A0B    | Star Drag Nut            | 5788 | 10R3Z    | Washer                   | 6539 | 10SX6    | Clutch Cam                      |
| 4729 | 108WQ    | O Ring                   | 5790 | 1005Z    | Level Wind Guard         | 7079 | 10CG0    | O Ring                          |
| 4795 | 10CJ1    | Drag Washer              | 5791 | 1006J    | Level Wind Guide         |      |          |                                 |
| 4874 | 10FJB    | Pawl Cap                 | 5794 | 10067    | Clutch Plate             | 4692 | 10LQ0    | B-100 Oil (Accessory)           |

Please note that the number of adjusting washers may not be the same as shown in the exploded views.  
(Adjustment will vary with each individual product.)

(240329)\_011