


SHIMANO

CURADO

CU150MGM



(51RL781A60X)

#	Part No.	BNT No.	Description	#	Part No.	BNT No.	Description	#	Part No.	BNT No.	Description
1	10DV5	6913	Screw	39	10JDY	5327	Idle Gear Spring	76	14AYP		Frame Assembly
2	101E6	6914	Handle Nut Plate	40	10HJG	5310	Idle Gear Pin	77	100UT	5956	Stabilizer Bar
3	10SSU	5642	Handle Nut	41	101K8	5654	Idle Gear A	78	100G7	6931	Level Wind Guard Bushing
4	100NC	6126	Handle Knob Seal	42	108WU	6924	O Ring	79	10FJZ	4588	Washer
5	10LFA	5714	Screw	43	10S3Y	5756	Screw	80	105NC	1672	E Lock
6	10PXZ	5334	Bushing	44	109T1	5329	Drive Shaft Retainer	81	108PY	4893	Washer
7	104FH	6555	Washer	45	10KHG		E Lock	82	100BH	6932	O Ring
9	10KXW	5314	Click Plate Retainer	46	149BE		Click Spring	83	10TM7	7202	O Ring
10	10J26	5860	Star Drag Click Plate	47	1497E		Level Wind Protector	84	10MD0	5803	Spool Clutch Pin
11	10MFC	5316	Click Pin	48	10FJB	4874	Pawl Cap	85	10EZ7	5218	O Ring
12	10BT2	2123	Click Spring	49	10CFU	6701	Washer	86	1497F		Spool Assembly
13	14972		Star Drag	50	10BHQ	5383	Line Guide Pawl	87	10EX5	5346	Spacer
14	10A70	4124	Star Drag Spring	51	108WQ	4729	O Ring	88	101DR	5676	Brake Ring Gear
15	10A3T	4863	Star Drag Nut	52	10R51	6907	Line Guide Pawl Holder Assembly	89	100GW	5971	O Ring
16	10J1P	6450	Star Drag Spacer	53	105NK	7199	E Lock	90	10L1Q	5348	Screw
17	109F5	5376	Washer	54	10SRL	5659	Idle Gear	91	10S8R	6911	Brake Case
18	100SE	6655	Washer	55	10S8K	6926	Worm Shaft	92	101UN	6933	Washer
19	105BK		Ball Bearing	56	10T3X	6927	Level Wind Guard	93	101Q2	6934	B Side Plate Cam Lever
20	142V6		Cast Control Cap	58	100U9	5942	Yoke Spring	94	10SSN	5680	Washer
21	10896	1696	Cast Control Spacer (B)	60	10LV0	5944	Screw	95	103LE	4814	Screw
22	1085F	2224	Cast Control Spacer	61	100US	5945	Clutch Cam Retainer	96	10G6D	5715	Washer
23	1054D	5319	Bearing Retainer	62	10190	5308	Washer	97	108WS	2427	O Ring
24	105C3	4343	Ball Bearing	63	100UK	5946	Clutch Cam	98	10SAZ	5970	Brake Dial
25	101GT	5503	O Ring	64	10MME	4886	Clutch Pawl Assembly	99	10KNH	5681	Spring
26	100BL	6918	Bearing Spacer	65	10R1H	5337	Clutch Pawl Spring	100	103L7	4817	Screw
27	105BP	4194	Ball Bearing	66	10QZV	5338	Clutch Plate	101	10CLF	4819	Idle Gear
28	10R22	5320	O Ring	67	10LF4	5948	Screw	102	10GQZ	4932	Click Spring
29	10LCY	5932	Screw	68	10EX8	3927	Ball Bearing	103	14AYQ		B Side Plate Assembly
31	1005E	5780	Roller Clutch Bearing	69	100S4	6928	Screw	104	10GR3	7198	Washer
32	13UCY		Roller Clutch Inner Tube	70	10R56	6908	Clutch Guard Assembly	201	1496T		Handle Assembly
33	100BK	6921	Key Washer	71	10T3V	6929	Clutch Bar Guide B	205	10S8M	6938	Yoke
34	106XT	4625	Drag Washer	72	101EC	6930	Clutch Button	301	14AYS		A Side Plate Assembly
36	10CHY	4590	Drag Washer	73	10SXB	5668	Screw	302	101Q3	6940	Drive Gear
37	100BJ	6922	Anti-Reverse Ratchet	74	105NB	2717	E Lock	303	101Q4	6941	Pinion Gear
38	14977		Drive Shaft	75	10LCQ	5328	Screw				

Please note that the number of adjusting washers may not be the same as shown in the exploded views.
(Adjustment will vary with each individual product.)

(250210)_002