AVETREELS

EX80/2 - EXW80/2

01
02
03
04
05
06
07
09
10
12
13
14
15
16
17
18
19
20
21
22
23
24
25
25-a
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
45-a
46
47
48
49
50
51
52
53
54
55
56
57
58
63
64
65
66
67
68
69
70
71
73
73
74
76
77
78
79
80
81
82
83
84
85
86
86-a
86-b
86-c
86-d
87
87-a
87-b
87-c

( )

FOR EXW80

FOR EX80

AVETREELS

EX80/2 - EXW80/2

01. ENDCAP HOUSING SCREW (PACK OF 12)
02. ENDCAP HOUSING
03. DOG SPRING SET
04. DOG SET
05. HARNESS LUG SCREW (PACK OF 2)
06. HARNESS LUG
07. FRAME
09. OUTTER BRAKE BEARING
10. OUTTER BRAKE
12. E-CLIP WASHER (PACK OF 3)
13. BRAKE DISC
14. BRAKE RETAINER SPRING
15. INNER BRAKE
16. BRAKE PIN (PACK OF 2)
17. BRAKE DISC SPRING (PACK OF 3)
18. INNER BRAKE SPOOL BEARING
19. SPOOL
20. CLICKER DISC
21. CLICKER DISC SCREW (PACK OF 4)
22. SPOOL TUBE
23. SPOOL BEARING
24. SPACER
25. SPOOL SHAFT
    25-a. LARGE PINION BEARING
26. BELLEVILLE WASHER (PACK OF 2)
27. PRESET KNOB SCREW (PACK OF 3)
28. PRESET KNOB
29. LEVER SPACER
30. LEVER
31. PRESET KNOB SPACER (PACK OF 2)
32. CAM HOUSING OUTTER WASHER
33. GLIDE PLATE SCREW (PACK OF 3)
34. GLIDE PLATE
35. GLIDE PLATE SPACER (PACK OF 3)
36. ENDHOUSING SCREW (PACK OF 11)
37. PUSH KNOB COVER SCREW (PACK OF 2)
38. PUSH KNOB COVER
39. RELEASE ARM
40. RELEASE ARM SPRING
41. PUSH KNOB LOCK PLATE
42. PUSH KNOB
43. PUSH KNOB WASHER
44. RELEASE ARM PIN
45. HANDLE KNOB
    45-a. HANDLE KNOB
46. HANDLE ARM
47. HANDLE ARM THRUST WASHER
48. DRIVE SHAFT BEARING
49. ENDHOUSING TUBE
50. CLICKER KNOB
51. CLICKER SHAFT PIN
52. CLICKER SHAFT SPRING
53. CLICKER SHAFT
54. CLICKER SPACER TUBE
55. CLICKER KNOB WASHER
56. CLICKER SHAFT PIN
57. FREE LIMIT PIN SET
58. FULL LIMIT PIN
60. ENDHOUSING
63. CAM HOUSING
64. CAM HOUSING INNER WASHER
65. FEMALE CAM
66. MALE CAM
67. PRESET NUT
68. PINION BEARING / PRESET NUT BEARING
69. CAM HOUSING SCREW (PACK OF 2)
70. CLICKER POSITION BALL SPRING
71. CLICKER POSITION BALL
72. CLICKER WASHER
73. CLICKER RETAINERING RING
74. CLICKER HOUSING
75. SPRING WASHER (PACK OF 2)
76. CLICKER HOUSING SCREW (PACK OF 2)
77. DRIVE SHAFT BEARING
78. DRIVE SHAFT
79. DRIVE SHAFT LARGE GEAR
80. DRIVE SHAFT LARGE GEAR SPACER
81. DRIVE SHAFT SMALL GEAR
82. DRIVE SHAFT SMALL GEAR SPACER
83. DRIVE SHAFT STOP NUT
84. REEL FOOT
85. REEL FOOT SCREW (PACK OF 4)
86. CLAMP SET
    86-a. REEL FOORT STUDS (PACK OF 4)
    86-b. CLAMP
    86-c. CLAMP NUT WASHER (PACK OF 4)
    86-d. NUT (PACK OF 4)
87. CLAMP SET
    87-a. CLAMP
    87-b. CIAMP SCREW (PACK OF 2)
    87-c. CLAMP NUT (PACK OF 2)