
www.reelschematic.com

EAGLE CLAW®

BZ1000-2000



PARTS NO	DESCRIPTION
1	DRAG KNOB
2	RETAINER RING
3	EARED WASHER
4	WASHER
5	KEY WASHER
6	SPOOL ASSY
7	CLICK SPRING
8	SCREW
9	BUSHING
10	CLICK GEAR
11	CLICK GEAR WASHER
12	CLICK GEAR
13	MAIN SHAFT
14	SCREW
15	BAIL ASSY
16	LINE ROLLER
17	BAIL ARM
18	SCREW
19	SCREW
20	ROTOR NUT
21	BAIL LEVER
22	SPRING
23	CLICK LEVER
24	SCREW
25	NUT
26	WASHER

PARTS NO	DESCRIPTION
27	ROTOR
28	SCREW
29	BUSHING
30	SPRING
31	BALL BEARING
32	PINION GEAR
33	SCREW
34	STOPPER
35	C RETAINER
36	HANDLE NUT
37	WASHER
38	BALL BEARING
39	DRIVE GEAR
40	WASHER
41	BALL BEARING
42	BODY COVER
43	SCREW
45	SCREW
46	SLIDER
47	SLIDER SCREW
48	OSCILLATION GEAR
50	BODY SIDE COVER
51	STOPPER SPRING
54	HANDLE ASSY