One-Year Limited Warranty

Bass Pro Shops® will repair or replace (at our discretion) any Johnny Morris reel which proves to be defective in workmanship or materials within one year from the original date of purchase. You must save your dated sales receipt for warranty validation. This warranty gives you special legal rights, and you may have other rights which vary from state to state.

For reels purchased through our catalogs or Bass Pro Shops® online:

For reel replacement only: Return your reel **postage prepaid with your dated sales receipt** to the Return Center address listed on your receipt.

For reel repair only: Return you reel **postage prepaid with a copy of your dated sales receipt** as proof of purchase and warranty validation to the Outdoor World Rod & Reel Repair address listed under Care and Lubrication.

For reels purchased through Bass Pro Shops® retail locations:

For reel replacement only: Return your reel (**postage prepaid if sending by mail**) to the store from which it was purchased along with your dated sales receipt.

For reel repair only: Return your reel **postage prepaid with a copy of your dated sales receipt** as proof of purchase and warranty validation to the Outdoor World Rod & Reel Repair address listed under Care and Lubrication.

This warranty does not cover lost parts, malfunctions or damage due to abuse, accidents, normal wear, or cleaning and relubrication required due to the owner's failure to provide reasonable and necessary maintenance.

Repairs needed to your reel due to abnormal use, modification, or reels past the one-year warranty period are available, for a reasonable charge, providing the reel is returned **postage prepaid**, from Outdoor World Rod & Reel Repair.

Except to the extent prohibited by applicable law, there are no warranties or conditions, express or implied, other than those expressly set out herein. Bass Pro Shops® shall not, under any circumstances, be liable for an amount greater than the actual purchase price of the product nor for any special, incidental or consequential damages suffered or incurred in connection with the product and Bass Pro Shops® does not assume, and does not authorize any person to assume for it, any obligation or liability other than those expressly set out herein.

Garantie Limitée d'Une Année

Bass Pro Shops® réparera ou remplacera (à notre discrétion) n'importe quel moulinet à lance-appât à Johnny Morris qui s'avère être défectueux de fabrication ou de matériaux avant qu'une année passe après la date du premier achat. Il faut que vous gardiez votre reçu daté pour vérifier votre garantie. Cette garantie vous donne des droits légaux spéciaux, et vous pouvez avoir d'autres droits qui varient selon votre province.

Pour les moulinets achetés à nos catalogues ou à Bass Pro Shops® en ligne:

Pour le remplacement du moulinet seulement: Envoyez votre moulinet **avec le tarif payé d'avance et avec votre reçu daté** à l'adresse qui se trouve à votre reçu.

Pour la réparation du moulinet seulement: Envoyez votre moulinet **avec le tarif payé d'avance et avec votre reçu daté** comme justification d'achat et vérification de garantie à l'adresse de Outdoor World Rod & Reel Repair ci-dessus.

Pour les moulinets achetés à des détaillants de Bass Pro Shops®:

Pour le remplacement du moulinet seulement: Envoyez votre moulinet (**avec le tarif payé d'avance si vous l'envoyez par la poste**) au magasin où vous l'avez acheté avec votre reçu daté.

Pour la réparation du moulinet seulement: Envoyez votre moulinet **avec le tarif payé d'avance et avec votre reçu daté** comme justification d'achat et vérification de garantie à l'adresse de Outdoor World Rod & Reel Repair ci-dessus.


Cette garantie ne s'applique pas: aux pièces perdues, aux défaillances ou aux dégâts en raison de mauvais traitement, d'accident, ou d'usure normale, ou aux nettoyages et aux graissages qu'il faut à cause de l'incapacité du propriétaire de entretenir le moulinet raisonnablement.

Vous pouvez faire réparer un moulinet auquel la garantie ne s'applique pas à un prix raisonnable. Envoyez votre moulinet **avec le tarif payé d'avance** à Outdoor World Rod & Reel Repair.

Sauf dans la mesure interdite par la loi qui s'y applique, il n'y a pas de garanties ou conditions, expresses ou implicites, en plus de ceux expressément établies ici. Bass Pro Shops® ne sera pas, en aucun cas, responsable d'un prix en plus du prix de l'achat du produit, ni de n'importe quels dommages-intérêts, indirects ou directs, que l'on souffre ou encourt à propos du produit. Bass Pro Shops® ni assume, ni autorise personne à assumer au nom de Bass Pro Shops®, aucune obligation ou engagements en plus de ceux expressément établies ici.

Johnny Morris CARBON BLACK

JCB10HFA



Bass Pro Shops®

basspro.com

NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME
1	FRAME ASSEMBLY	17	PILLAR	34	BALL BEARING	51	DRAG WASHER (A)	68	STAR DRAG ASSEMBLY	84	SPOOL COVER ASSEMBLY	102	CLICK SPRING
2	CLUTCH BAR PLATE (A)	18	O-RING	35	CRANK SHAFT	52	DRAG WASHER (D2)	69	HANDLE WASHER	85	SPOOL COVER SCREW(*3)	103	CLICK PLATE
3	CLUTCH BAR PLATE (B)	19	LINE GUIDE PAWL	36	IDLER(L)	53	SLEEVE WASHER	70	HANDLE ASSEMBLY(INCL. 2B/B)	86	MAGNET HOLDER		
4	CLUTCH BAR ASSEMBLY	20	SPACER(OPTIONAL)	37	IDLER(L) WASHER (A)	54	SLEEVE	71	HANDLE NUT	87	MAGNET(*5)		
5	CLUTCH LINK	21	PAWL CAP	38	BEARING PLATE	55	CAST CONTROL CAP	72	SPOOL ASSEMBLY(INCL.1 B/B)	88	MAGNET HOLDER PLATE		
6	CLUTCH BAR SCREW	22	FRONT COVER	39	IDLER(L) WASHER (B)	56	TENSION WASHER	73	BRAKE SHOE HOLDER	89	MAGNET HOLDER SPRING(*2)		
7	LINE GUIDE ASSEMBLY	23	FRONT COVER SCREW (A)	40	RIGHT SIDE COVER SCREW(B)	57	WASHER(F.R.P)	74	BRAKE SHOE(WHITE)(*6)	90	WASHER(F.R.P)		
8	WORM SHAFT	24	FRONT COVER SCREW (B)	42	BEARING PLATE SCREW	58	BALL BEARING	75	BRAKE SHOE SPRING(*6)	91	BALL BEARING		
9	BALL BEARING	25	YOKE HOLDER	43	PINION YOKE	59	RIGHT SIDE COVER ASSEMBLY	76	BRAKE HOLDER PLATE	92	BEARING RETAINER		
10	WORM SHAFT BUSHING (A)	26	CLUTCH CAM	44	PINION GEAR	60	O-RING	77	BRAKE HOLDER PLATE SCREW(*3)	94	HANDLE NUT RETAINER		
11	IDLER(S)	27	CLUTCH SPRING BUSHING	45	PINION YOKE SPRING(*2)	61	ONE WAY CLUTCH	78	LEFT SIDE COVER	95	HANDLE NUT RETAINER SCREW		
12	WORM SHAFT PIN	28	CLUTCH SPRING	46	RATCHET	62	RIGHT SIDE COVER SCREW(A)	79	LOCKING PIN	97	BEARING RETAINER		
13	LINE GUIDE PIPE	29	RETURN PAWL	47	RATCHET WASHER	64	RIGHT SIDE COVER SCREW (C)	80	LOCKING PIN SPRING	98	FLIPPING SWITCH PIN		
14	WORM SHAFT BUSHING (B)	30	RETURN PAWL SPRING	48	DRIVE GEAR	65	CLICK PLATE	81	PUSH BUTTON ASSEMBLY	99	FLIPPING SWITCH		
15	WORM SHAFT WASHER	31	CAM PLATE	49	DRAG WASHER (L)	66	CLICK LEAF SPRING	82	CONTROL DIAL ASSEMBLY	100	RETAINER		
16	E-RING	32	CAM PLATE SCREW (A)-(*3)	50	DRAG WASHER (D1)	67	SPRING WASHER	83	SLIDE CAM	101	CLICK SPRING HOLDER		