One-Year Limited Warranty

Bass Pro Shops® will repair or replace (at our discretion) any Johnny Morris Signature Series baitcast reel which proves to be defective in workmanship or materials within one year from the original date of purchase. You must save your dated sales receipt for warranty validation. This warranty gives you special legal rights, and you may have other rights which vary from state to state.

For reels purchased through our catalogs or Bass Pro Shops® online:

For reel replacement only: Return your reel **postage prepaid with your dated sales receipt** to the Return Center address listed on your receipt.

For reel repair only: Return you reel **postage prepaid with a copy of your dated sales receipt** as proof of purchase and warranty validation to the Outdoor World Rod & Reel Repair address listed under care and lubrication.

For reels purchased through Bass Pro Shops® retail locations:

For reel replacement only: Return your reel (**postage prepaid if sending by mail**) to the store from which it was purchased alongwith your dated sales receipt.

For reel repair only: Return your reel **postage prepaid with a copy of a sales receipt** as proof of purchase and warranty validation to the Outdoor World Rod and Reel Repair address listed under care and lubrication.

This warranty does not cover lost parts, malfunctions or damage due to abuse, accidents, normal wear, or cleaning and relubrication required due to the owner's failure to provide reasonable and necessary maintenance.

Repairs needed to your reel due to abnormal use, modification, or reels past the one-year warranty period are available for a reasonable charge, providing the reel is returned **postage prepaid**, from Outdoor World Rod & Reel Repair.

Except to the extent prohibited by applicable law, there are no warranties or conditions, express or implied, other than those expressly set out herein. Bass Pro Shops® shall not, under any circumstances, be liable for an amount greater than the actual purchase price of the product nor for any special, incidental or consequential damages suffered or incurred in connection with the product and Bass Pro Shops® does not assume, and does not authorize any person to assume for it, any obligation or liability other than those expressly set out herein.

Garantie limitée d'une année

Bass Pro Shops® réparera ou remplacera (à notre discrétion) n'importe quel moulinet à lance-appât à Johnny Morris qui s'avère être défectueux de fabrication ou de matériaux avant qu'une année passe après la date du premier achat. Il faut que vous gardiez votre reçu daté pour vérifier votre garantie. Cette garantie vous donne des droits légaux spéciaux, et vous pouvez avoir d'autres droits qui varient selon votre province.

Pour les moulinets achetés à nos catalogues ou à Bass Pro Shops® en ligne:

Pour le remplacement du moulinet seulement: Envoyez votre moulinet **avec le tarif payé d'avance et avec votre reçu daté** à l'adresse qui se trouve à votre reçu.

Pour la réparation du moulinet seulement: Envoyez votre moulinet **avec le tarif payé d'avance et avec votre reçu daté** comme justification d'achat et vérification de garantie à l'adresse de Outdoor World® Rod & Reel Repair ci-dessus.

Pour les moulinets achetés à des détaillants de Bass Pro Shops®:

Pour le remplacement du moulinet seulement: Envoyez votre moulinet **(avec le tarif payé d'avance si vous l'envoyez par la poste)** au magasin où vous l'avez acheté avec votre reçu daté.

Pour la réparation du moulinet seulement: Envoyez votre moulinet **avec le tarif payé d'avance et avec votre reçu daté** comme justification d'achat et vérification de garantie à l'adresse de Outdoor World® Rod & Reel Repair ci-dessus.


Cette garantie ne s'applique pas: aux pièces perdues, aux défaillances ou aux dégâts en raison de mauvais traitement, d'accident, ou d'usure normale, ou aux nettoyages et aux graissages qu'il faut à cause de l'incapacité du propriétaire de entretenir le moulinet raisonnablement.

Vous pouvez faire réparer un moulinet auquel la garantie ne s'applique pas à un prix raisonnable. Envoyez votre moulinet **avec le tarif payé d'avance** à Outdoor World® Rod & Reel Repair.

Sauf dans la limite des lois applicables, il n'existe nulles autres garanties ou conditions, expresses ou tacites, que celles prévues aux présentes. Bass Pro Shops® ne sont, en aucune circonstance, responsables d'un montant supérieur au prix d'achat du produit ni d'aucun dommage spécial, indirect ou consécutif subi ou survenu relativement au proudit; Bass Pro Shops n'assument ni n'autorisent personne à assumer en leur nom, toute obligation ou responsabilité autres que celles mentionnées aux présentes.

Johnny Morris SIGNATURE SERIES II

JMX10HD/JMX10SHD/JMX20HD




Bass Pro Shops®
basspro.com

NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME
1	FRAME ASSEMBLY	17	PILLAR	33	CAM PLATE SCREW (B)	49	DRAG WASHER (L)	65	CLICK PLATE	81	PUSH BUTTON ASSEMBLY	97	BEARING RETAINER
2	CLUTCH BAR PLATE (A)	18	O-RING	34	BALL BEARING	50	DRAG WASHER (D1)	66	CLICK LEAF SPRING	82	CONTROL DIAL ASSEMBLY	100	RETAINER
3	CLUTCH BAR PLATE (B)	19	LINE GUIDE PAWL	35	CRANK SHAFT	51	DRAG WASHER (A)	67	SPRING WASHER	83	SLIDE CAM	101	CLICK SPRING HOLDER
4	CLUTCH BAR ASSEMBLY	20	SPACER(OPTIONAL)	36	IDLER(L)	52	DRAG WASHER (D2)	68	STAR DRAG ASSEMBLY	84	SPOOL COVER ASSEMBLY	102	CLICK SPRING
5	CLUTCH LINK	21	PAWL CAP	37	IDLER(L) WASHER (A)	53	SLEEVE WASHER	69	HANDLE WASHER	85	SPOOL COVER SCREW(*3)	103	CLICK PLATE
6	CLUTCH BAR SCREW	22	FRONT COVER	38	BEARING PLATE	54	SLEEVE	70	HANDLE ASSEMBLY(INCL. 2B/B)	86	MAGNET HOLDER		
7	LINE GUIDE ASSEMBLY	23	FRONT COVER SCREW (A)	39	IDLER(L) WASHER (B)	55	CAST CONTROL CAP	71	HANDLE NUT	87	MAGNET(*5)		
8	WORM SHAFT	24	FRONT COVER SCREW (B)	40	RIGHT SIDE COVER SCREW(B)	56	TENSION WASHER	72	SPOOL ASSEMBLY(INCL.1 B/B)	88	MAGNET HOLDER PLATE		
9	BALL BEARING	25	YOKE HOLDER	41	BALL BEARING	57	WASHER(F,R,P)	73	BRAKE SHOE HOLDER	89	MAGNET HOLDER SPRING(*2)		
10	WORM SHAFT BUSHING (A)	26	CLUTCH CAM	42	BEARING PLATE SCREW	58	BALL BEARING	74	BRAKE SHOE(WHITE)(*6)	90	WASHER(F,R,P)		
11	IDLER(S)	27	CLUTCH SPRING BUSHING	43	PINION YOKE	59	RIGHT SIDE COVER ASSEMBLY	75	BRAKE SHOE SPRING(*6)	91	BALL BEARING		
12	WORM SHAFT PIN	28	CLUTCH SPRING	44	PINION GEAR	60	O-RING	76	BRAKE HOLDER PLATE	92	BEARING RETAINER		
13	LINE GUIDE PIPE	29	RETURN PAWL	45	PINION YOKE SPRING(*2)	61	ONE WAY CLUTCH	77	BRAKE HOLDER PLATE SCREW(*3)	93	CLUTCH SPRING HOLDER		
14	WORM SHAFT BUSHING (B)	30	RETURN PAWL SPRING	46	RATCHET	62	RIGHT SIDE COVER SCREW(A)	78	LEFT SIDE COVER	94	HANDLE NUT RETAINER		
15	WORM SHAFT WASHER	31	CAM PLATE	47	RATCHET WASHER	63	SLEEVE WASHER	79	LOCKING PIN	95	HANDLE NUT RETAINER SCREW		
16	E-RING	32	CAM PLATE SCREW (A)-(*2)	48	DRIVE GEAR	64	RIGHT SIDE COVER SCREW (C)	80	LOCKING PIN SPRING	96	SPRING WASHER		

Johnny Morris SIGNATURE SERIES II

JMX10HLD/JMX10SHLD



Bass Pro Shops®
basspro.com

NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME	NO	PART NAME
1	FRAME ASSEMBLY	17	PILLAR	33	CAM PLATE SCREW (B)	49	DRAG WASHER (L)	65	CLICK PLATE	81	PUSH BUTTON ASSEMBLY	97	BEARING RETAINER
2	CLUTCH BAR PLATE (A)	18	O-RING	34	BALL BEARING	50	DRAG WASHER (D1)	66	CLICK LEAF SPRING	82	CONTROL DIAL ASSEMBLY	100	RETAINER
3	CLUTCH BAR PLATE (B)	19	LINE GUIDE PAWL	35	CRANK SHAFT	51	DRAG WASHER (A)	67	SPRING WASHER	83	SLIDE CAM	101	CLICK SPRING HOLDER
4	CLUTCH BAR ASSEMBLY	20	SPACER(OPTIONAL)	36	IDLER(L)	52	DRAG WASHER (D2)	68	STAR DRAG ASSEMBLY	84	SPOOL COVER ASSEMBLY	102	CLICK SPRING
5	CLUTCH LINK	21	PAWL CAP	37	IDLER(L) WASHER (A)	53	SLEEVE WASHER	69	HANDLE WASHER	85	SPOOL COVER SCREW(*3)	103	CLICK PLATE
6	CLUTCH BAR SCREW	22	FRONT COVER	38	BEARING PLATE	54	SLEEVE	70	HANDLE ASSEMBLY(INCL. 2B/B)	86	MAGNET HOLDER		
7	LINE GUIDE ASSEMBLY	23	FRONT COVER SCREW (A)	39	IDLER(L) WASHER (B)	55	CAST CONTROL CAP	71	HANDLE NUT	87	MAGNET(*5)		
8	WORM SHAFT	24	FRONT COVER SCREW (B)	40	RIGHT SIDE COVER SCREW(B)	56	TENSION WASHER	72	SPOOL ASSEMBLY(INCL.1 B/B)	88	MAGNET HOLDER PLATE		
9	BALL BEARING	25	YOKE HOLDER	41	BALL BEARING	57	WASHER(F,R,P)	73	BRAKE SHOE HOLDER	89	MAGNET HOLDER SPRING(*2)		
10	WORM SHAFT BUSHING (A)	26	CLUTCH CAM	42	BEARING PLATE SCREW	58	BALL BEARING	74	BRAKE SHOE(WHITE)(*6)	90	WASHER(F,R,P)		
11	IDLER(S)	27	CLUTCH SPRING BUSHING	43	PINION YOKE	59	RIGHT SIDE COVER ASSEMBLY	75	BRAKE SHOE SPRING(*6)	91	BALL BEARING		
12	WORM SHAFT PIN	28	CLUTCH SPRING	44	PINION GEAR	60	O-RING	76	BRAKE HOLDER PLATE	92	BEARING RETAINER		
13	LINE GUIDE PIPE	29	RETURN PAWL	45	PINION YOKE SPRING(*2)	61	ONE WAY CLUTCH	77	BRAKE HOLDER PLATE SCREW(*3)	93	CLUTCH SPRING HOLDER		
14	WORM SHAFT BUSHING (B)	30	RETURN PAWL SPRING	46	RATCHET	62	RIGHT SIDE COVER SCREW(A)	78	LEFT SIDE COVER	94	HANDLE NUT RETAINER		
15	WORM SHAFT WASHER	31	CAM PLATE	47	RATCHET WASHER	63	SLEEVE WASHER	79	LOCKING PIN	95	HANDLE NUT RETAINER SCREW		
16	E-RING	32	CAM PLATE SCREW (A)-(*2)	48	DRIVE GEAR	64	RIGHT SIDE COVER SCREW (C)	80	LOCKING PIN SPRING	96	SPRING WASHER		