


| No. | PARTS NAME | No. | PARTS NAME | No. | PARTS NAME | No. | PARTS NAME |
|---|---|---|---|---|---|---|---|
| 185 | "E" washer | 449 | Spring washer | 740 | Drive shaft | 1021 | Yoke spring |
| 211 | Set plate screws | 451 | Handle nut washer | 741 | Drive gear | 1099 | Fixing lever |
| 215 | Cover screw | 460 | Drive shaft shield | 742 | Shaft spacer | 1100 | Side part for Release bar |
| 302 | Star grag washer | 463 | Cast control spring | 743 | Drive shaft bushing | 1101 | Clutch release yoke |
| 384 | Ball bearing (S6700) | 464 | Click spring A | 745 | Drive shaft washer | 1102 | Anti-reverseratchet |
| 389 | Ball bearing (S695) | 465 | Bearing spring | 754 | Fixed screw | 1104 | Clutch dog |
| 391 | One-way bearing | 468 | Yoke | 755 | Cast control screw | 1105 | Clutch spring |
| 392 | Ball bearing (S105) | 473 | Drag washer A | 757 | Close cover | 1106 | Yoke plate |
| 393 | Ball bearing (S128) | 474 | Drag washer B | 758 | Handle arm | 1107 | Clutch skid |
| 394 | Ball bearing (S126) | 564 | Alarm pin | 759 | Thimble | 1108 | Clutch lever bracket |
| 411 | Cast control bracket | 601 | Washer 1 | 761 | Thimble spring | 1109 | Right plate |
| 412 | Yoke ratchet | 631 | Wrench | 767 | Lock set | 1111 | Transitional board |
| 432 | Pinion gear | 668 | Side plate screws | 768 | Handle shaft coat | 1120 | Release bar |
| 435 | Clutch lever screw | 670 | Close cover screws | 779 | Loose sleeve screw | 1121 | Spool shaft |
| 437 | One-way bearing tube | 679 | Washer 2 | 873 | Strike alert lever | 1122 | Clutch release bar |
| 438 | Anti-reversenail | 692 | Knob cover | 920 | Sound gear | 1123 | Lever wind washer |
| 440 | Spool shaft nail | 693 | Handle knob（EVA） | 921 | T handle nail | 1124 | Frame |
| 443 | Eared washer | 724 | Bearing washers | 927 | Alarm sound gear | 1125 | Spool |
| 444 | Key washer A | 725 | Tension knob | 932 | Bushing screw | | |
| 445 | Key washer B | 729 | Star drag knob | 936 | Bearing ring | | |
| 446 | Anti-reverse dog | 731 | Handle bolt | 937 | Alarm spring | | |
| 447 | Anti-reverse plate | 735 | Reel foot | 943 | Handle knob screw | | |
| 448 | Click bracket | 736 | Sound spring plate | 944 | Handle lock ring | | |