


No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
185	"E" washer	460	Drive shaft shield	759	Thimble	1042	Drive gear
211	Set plate screws	463	Cast control spring	761	Thimble spring	1099	Fixing lever
215	Cover screw	464	Click spring A	767	Lock set	1100	Side part for Release bar
302	Star grag washer	465	Bearing spring	768	Handle shaft coat	1101	Clutch release yoke
384	Ball bearing (S6700)	473	Drag washer A	779	Loose sleeve screw	1102	Anti-reverseratchet
389	Ball bearing (S695)	474	Drag washer B	873	Strike alert lever	1108	Clutch lever bracket
391	One-way bearing	564	Alarm pin	920	Sound gear	1112	Clutch dog
392	Ball bearing (S105)	601	Washer 1	921	T handle nail	1113	Yoke spring
393	Ball bearing (S128)	631	Wrench	927	Alarm sound gear	1114	Yoke plate
394	Ball bearing (S126)	668	Side plate screws	932	Bushing screw	1115	Clutch skid
411	Cast control bracket	670	Close cover screws	936	Bearing ring	1116	Right plate
435	Clutch lever screw	679	Washer 2	937	Alarm spring	1118	Transitional board
437	One-way bearing tube	692	Knob cover	943	Handle knob screw	1119	Frame
438	Anti-reversenail	693	Handle knob（EVA）	944	Handle lock ring	1120	Release bar
440	Spool shaft nail	724	Bearing washers	1019	Drive shaft	1121	Spool shaft
443	Eared washer	731	Handle bolt	1020	Clutch spring	1122	Clutch release bar
444	Key washer A	735	Reel foot	1028	Yoke ratchet	1123	Lever wind washer
445	Key washer B	736	Sound spring plate	1035	Yoke	1125	Spool
446	Anti-reverse dog	742	Shaft spacer	1037	Cast control screw		
447	Anti-reverse plate	743	Drive shaft bushing	1038	Tension knob		
448	Click bracket	745	Drive shaft washer	1039	Star drag knob		
449	Spring washer	754	Fixed screw	1040	Close cover		
451	Handle nut washer	758	Handle arm	1041	Pinion gear		