


No.	PARTS NAME	No.	PARTS NAME	No.	PARTS NAME
11	Friction spring	666	Small ring	1555	Sound coat
43	Drive shaft washer	669	Side plate screws	1590	Handle lock ring
46	Reel foot screws	670	Close cover screws	1591	Drag tension knob
185	"E" washer	671	Spool shaft screw	1593	Pre-program plate
207	Push slice screw	673	Screw for bearing cover	1594	Pre-program key
211	Set plate screws	679	Washer 2	1600	Drive shield
215	Cover screw	680	Drive shaft coat washer	1602	Handle shaft coat
380	Ball bearing (S605)	684	Drag plate	1603	Main Knob
384	Ball bearing (S6700)	698	Spool ring	1615	Bearing cover
388	Ball bearing (S85)	699	Set plate	1623	Drag adjustable washer
389	Ball bearing (S695)	772	Handle bolt	1624	Spool shaft spring
395	One-way bearing	792	Ball bearing (S624)	1706	Sound nail
400	Drive shaft coat	804	Lever spring	1707	The sound nail springs
401	"O" ring	873	Strike alert lever	1793	Cover
420	Sound nail	910	Anti-reverse dog	1795	Spool shaft
428	Sound nail spring	921	T handle nail	1796	Spool cannulation
539	Alarm sound gear	937	Alarm spring	1799	Drive gear-high speed
564	Alarm pin	943	Handle knob screw1	1800	Spool spring washer
598	Handle bolt washer	946	Sound gear	1801	Ratcheting washer
601	Washer 1	1147	Handle cover	1802	Right plate
627	Drag knob cover	1148	Hander cover	1803	Frame
630	"O" ring	1151	Lock set	1804	Spool
631	Wrench	1155	Handle arm	1805	Drag control lever
639	Rear drag plate	1159	Reel foot	1806	Close cover
642	Front drag plate	1328	Reel foot spacer	1807	Anti-reverse ratchet
646	Pre-program key pin	1374	Handle knob screw 2	1808	High speed pinion gear
647	Set plate nail	1441	Drive shaft		
660	Bearing ring	1447	Pin with small teeth		
661	Handle washer	1448	Drag plate undersleeve		
665	Big ring	1449	Fixed plate pin		