
OCEAN CITY REEL NO. 1581

(Model A)



HOW TO ORDER PARTS FOR YOUR REEL—Locate the part desired in the illustration above and note part number. **When ordering,** state quantity, part number, part name and model letter which you will find on underside of reel stand. Enclose money order, stamps or check. Our minimum charge for one order is $.25; please add $.15 on each order for return postage and insurance.

PART NO.	PART NAME	PRICE
5—H	Click Button	.12
6—G	Click Pawl	.06
7—F	Click Spring and Rivets	.10
19—L	Frame Post, Plain	.08
94	Frame Post, Slotted	.14
22—J	Handle, Complete with Knobs	.36
95	Handle Nut	.12

PART NO.	PART NAME	PRICE
24—F	Handle Knob	.12
25—B	Handle Knob Rivet	.06
63—D	Line Guide	.30
31—M	Left Side Plate Complete with Part Nos. 5-H, 7-F, 6-G	.40
57—H	Left Side Stand Screw	.02
37—K	Main Gear	.20

PART NO.	PART NAME	PRICE
96—A	Main Gear Stud	.22
42—L	Right Side Plate	.40
54—H	Right and Left Plate and Rt. Stand Screw	.02
97	Right Plate Guard	.10
44—ZG	Spool (with cork arbor)	.60
43—T	Stand	.36

PART NO.	PART NAME	PRICE
71—A	Worm	.40
72—A	Worm Gear	.12
74—A	Worm Pawl	.10
75—A	Worm Pawl Cover	.02
76—A	Worm Pawl Cover Screw	.02
100	Worm Guard	.12
CA—1	Cork Arbor only	.10

FORM 132

www.reelschematic.com