
www.reelschematic.com

qualia

Huracán series

HC 20,30 Parts



1. Spool washer
2. Spool click ratchet
3. Rotor nut-bearing
4. Rotor nut retainer screw
6. Main shaft
7. Rotor cover top screw
8. Rotor body
9. Line roller screw
10. Roller screw shield
11. Roller shield
12. Roller shim (2)
13. Roller bearing
14. Line roller
15. Bail wire assembly
16. Bail hinge
17. Rotor cover bushing (2)
18. Rotor cover (A)
19. Rotor cover bottom screw (2)
21. Bail spring pin
22. Bail spring
23. Mainshaft screw
24. Clutch bearing cover screw (3)
25. Clutch bearing cover
26. Front bearing shim
27. Front bearing
28. Bearing seat
29. Clutch bearing spring
30. Clutch bearing
31. Rotor bearing
32. Pinion gear
33. Handle boss cover
34. Main body
35. Body plate screw
36. Body plate
37. Oscillation gear bushing
38. Oscillation gear
39. Oscillation block
40. Rear shaft support
41. Bail trip wire
42. Bail pivot
43. Rotor cover (B)
44. Drag knob assembly
45. Protective shield
46. Drag retainer spring
47. Top keyed washer
48. Friction washer (3)
49. Eared washer (2)
50. Keyed washer
51. Spool assembly
52. Spool shell
53. A/R switch cam
54. Switch cam spring
55. A/R switch
56. AR switch screw
57. Main gear
58. Main gear shim
59. Main gear bearing (2)
60. Sideplate
61. Sideplate screw (3)
61L. Long sideplate screw
62. Handle assembly