
(1) Main Body Assembly			
ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	UB1000-75-02	Gear Housing
2	1	UB1001	Foot
3	1	UB1002-75-03	Slider Cover
4	1	UB1019	Side Cover Cap
6	1	UB1030	Clutch Housing Nut
7	3	UB1052	Foot Mount Screw
8	3	UB1053	Cover Screw
9	3	UB1054	Cover Screw O-Ring
10	1	UB1055	Drive Gear Bearing
11	1	UB1056	Drive Gear Support Bearing
12	1	UB1057-01	Pinion Support Bearing
13	1	UB1059-01	Slider Bearing Screw

(1) Main Body Assembly			
ITEM	QTY	PART NUMBER	DESCRIPTION
14	1	UB1060-01	Slider Gear Trust Washer
15	1	UB1062	Cover O-Ring Seal
16	1	UB1063-01	Clutch Bearing
17	1	UB1064	Clutch Sleeve
18	1	UB1065	Slider Post O-Ring
19	1	UB1066	Clutch Housing O-ring
21	3	UB1070	Spool Shaft / Flange Screw
22	1	UB1091	Huada Clutch

(1) Main Body Assembly			
ITEM	QTY	PART NUMBER	DESCRIPTION
24	2	UB1095	Gear Shaft Seal
25	1	UB1069-1	Roller Post-Main Gear
26	1	UB1069-2	Slider Cam Roller
27	1	UB6102	Main Seal
28	1	UB1011-5-01	Pinion
29	1	UB6103	Foot Logo
30	2	UB1015	Slider Gear Bearing
31	1	UB6104	Sight Plug
32	1	UB1012-33-01	Face Gear
33	1	UB1100	O-Ring Sight Cap
34	1	UB1105	Slider Cap Post O-ring
35	1	UB1022-01	Bearing Slider Assy R1
36	1	UB1003-01	Neck Flange
37	1	UB1003-02	Neck Flange incert
129	1	UB1069-01	Slider Gear

MAIN BODY ASSEMBLY (1)



NO. 3 & 4 VISSER SPINNING REEL
EXPLODED VIEW, BODY ASSY (1)