
Please quote by part number, not key number when ordering
spares@daiwaaustralia.com.au PH: 02 8644 8644

2019 CERTATE LT 3000D-C



DAIWAFISHING.COM.AU

Please quote by part number, not key number when ordering

spares@daiwaaustralia.com.au PH: 02 8644 8644

2019 CERTATE LT 3000D-C

Key No.	Part Number	Description
1	6J775201	DRAG KNOB ASSY
2	6J556701	DRAG RING
3	6J556601	DRAG RATCHET
4	6J679101	ATD DRAG WASHER(LT3-3pcs)
5	6J561201	DRAG DISC WASHER
6	6J556501	DRAG RIP WASHER
7	6B358702	SPOOL COLLAR RING
8	6J546701	SPOOL COLLAR
9	6J867401	SPOOL ASSY.(ATD)
10	6J558001	LINE STOPPER
11	6J558101	LINE STOPPER PLATE
12	6J314801	LINE STOPPER SPRING
13	6J546300	SPOOL WASHER (A)
14	6J549501	SPOOL METAL
15	6J558201	SPOOL METAL SCREW
16	6H624801	SPOOL METAL COLLAR
17	6J602201	SPOOL WASHER (B)
18	6J546201	CLICK HOLDER
19	6J525101	CLICK REEF SPRING
20	6G471501	ROTOR NUT PLATE
21	6J729101	ROTOR NUT PACKING
22	63755202	ROTOR NUT WASHER
23	6H959602	ROTOR NUT BALL BEARING
24	6J690201	ROTOR NUT BEARING COLLAR
25	6J253001	ROTOR NUT
26	6J808500	ROTOR NUT COLLAR
27	63712836	ROTOR NUT WASHER
28	6H022701	ROTOR NUT SCREW
29	6J257101	ROTOR COVER
30	6H022701	ROTOR COVER SCREW
31	6J254301	ROTOR
32	6J435201	KICK LEVER SPRING
33	6J339500	KICK LEVER WASHER
34	6J254401	KICK LEVER ASSY
35	6H417701	KICK LEVER SCREW
36	6J254601	ARM LEVER SHAFT
37	6J254701	ARM LEVER SHAFT COLLAR
38	6J255103	ARM LEVER HOLDER COVER
39	6J255201	ARM LEVER HOLDER COVER SCREW
40	6J254801	ARM LEVER
41	6J254901	ARM LEVER SCREW COLLAR
42	6J255001	ARM LEVER SCREW
43	6J257001	ROLLER CREW
44	6J538001	ROLLER MAG COLLAR (B)
45	6J538401	ROLLER MAGNET ASSEMBLY(A)
46	6J256702	ROLLER BALL BEARING (B)
47	6J256601	ROLLER COLLAR(A)
48	6J256301	ROLLER COLLAR(B)
49	6J256501	LINE ROLLER
50	6J256401	ROLLER COLLAR(A)
51	6J537801	ROLLER MAGNET ASSEMBLY(B)
52	6J891101	BAIL ASSY
53	6J254901	BAIL HOLDER SCREW COLLAR
54	6J255001	BAIL HOLDER SCREW
55	6G471803	BAIL SHAFT
56	6G685401	BAIL SHAFT WASHER
57	6J255301	BAIL SHAFT SPRING
58	6G471602	BAIL SHAFT SPRING COLLAR
59	6J255903	BAIL HOLDER COVER
60	6J255201	BAIL HOLDER COVER SCREW
61	6J554901	STOPPER LEVER PACKING(A)
62	6J774701	STOPPER LEVER
63	6J782101	STOPPER LEVER SCREW
64	6J553802	MAGSEALED PLATE
65	6H842807	MAGSEALED PLATE SCREW
66	6H502200	ONEWAY CLUCH WASHER
67	6H412602	ONEWAY CLUCH
68	6J553701	STOPPER LEVER PACKING(B)
69	6J774801	CLUCH RING
70	6J552102	PINION BEARING PLATE
71	6J552202	PINION BEARING PLATE SCREW
72	6G279602	PINION BALL BEARING(A)
73	63758500	PINION BEARING(A) WASHER
74	6Z024882	PINION+DRIVE GEAR SET
75	6H814900	PINION BEARING(B) SPRING WASHER
76	6E096500	PINION BEARING(B) WASHER
77	6G538007	PINION BALL BEARING(B)
78	6J552001	PINION BEARING(B) COLLAR
79	6J773302	BODY ASSY
80	6J773601	MAIN SHAFT
81	6J774301	OSCILLATING POST
82	6J774401	REAR CAP PACKING
83	6J774501	REAR CAP
84	6J774601	REAR CAP SCREW (B)
85	6H158201	BAIL KICK COLLAR SCREW
86	6J571801	BAIL KICK COLLAR
87	6J553603	REAR CAP SCREW (A)
88	6G818902	DRIVE BALL BEARING (A)
89	6J555501	DRIVE BEARING (A) WASHER
90	6J774102	ENJINE PLATE(R)
91	6G399702	HANDLE CAP O-RING
92	6J555901	HANDLE CAP
93	6G610104	OSCILLATING GEAR WASHER
94	6J601701	OSCILLATING GEAR
95	6G683301	OSCILLATING GEAR O-RING
96	6H129200	OSCILLATING GEAR WASHER
97	6G686904	OSCILLATING GEAR BALL BEARING
98	6G940403	OSCILLATING GEAR SCREW
99	6J552701	DRIVE GEAR RING
100	6H739701	DRIVE BALL BEARING (B)
101	6G613400	DRIVE BEARING (B) WASHER
102	6J553001	ENJINE PLATE PACKING)
103	6J774204	ENJINE PLATE(L)
104	6H866201	HANDLE PACKING
105	6J868001	HANDLE ASSY
106	6G315302	REAR CAP SCREW WASHER(A)
107	6G315301	REAR CAP SCREW WASHER(B)