
Feel Alive.

21 CERTATE SW G 18000H

Please quote by part number, not key number when ordering.
spares@daiwaaustralia.com.au PH: (02) 8644 8644



21 CERTATE SW G
18000-H

S34711U

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 CERTATE SW G 18000H		1	6M122401	DRAG KNOB
21 CERTATE SW G 18000H		2	6M042301	CLICK GEAR PLATE SCREW
21 CERTATE SW G 18000H		3	6J900301	CLICK GEAR PLATE
21 CERTATE SW G 18000H		4	6J916501	CLICK GEAR PIN
21 CERTATE SW G 18000H		5	6J900201	CLICK GEAR
21 CERTATE SW G 18000H		6	6J899901	SPOOL COLLAR RETAINER
21 CERTATE SW G 18000H		7	6M145701	SPOOL COLLAR (A)
21 CERTATE SW G 18000H		8	6J923401	SPOOL COLLAR (B)
21 CERTATE SW G 18000H		9	6M146301	DRAG WASHER
21 CERTATE SW G 18000H		10	6J899601	EARED WASHER
21 CERTATE SW G 18000H		11	6J923301	KEY WASHER
21 CERTATE SW G 18000H		12	6M154301	SPOOL ASSY
21 CERTATE SW G 18000H		13	6J937401	SPOOL WASHER
21 CERTATE SW G 18000H		14	6J898501	SPOOL PLATE PACKING (A)
21 CERTATE SW G 18000H		15	6J922401	SPOOL PLATE
21 CERTATE SW G 18000H		16	6J922501	SPOOL PLATE PACKING (B)
21 CERTATE SW G 18000H		17	6H503901	ROTOR COVER SCREW
21 CERTATE SW G 18000H		18	6H685701	ROTOR COVER
21 CERTATE SW G 18000H		19	6H685601	ROTOR NUT PACKING
21 CERTATE SW G 18000H		20	6B861702	ROTOR NUT BALL BEARING
21 CERTATE SW G 18000H		21	6J930201	ROTOR NUT COLLAR
21 CERTATE SW G 18000H		22	6H685402	ROTOR NUT
21 CERTATE SW G 18000H		23	6H685301	ROTOR NUT PLATE
21 CERTATE SW G 18000H		24	6F274501	ROTOR NUT O RING
21 CERTATE SW G 18000H		25	6H684503	ROTOR
21 CERTATE SW G 18000H		26	6H782801	ROTOR BRAKE SPRING
21 CERTATE SW G 18000H		27	6E272501	ROTOR BRAKE WASHER
21 CERTATE SW G 18000H		28	6H684601	ROTOR BRAKE SHAFT
21 CERTATE SW G 18000H		29	6H684701	ARM LEVER SPRING COLLAR
21 CERTATE SW G 18000H		30	6G418101	ARM LEVER SPRING
21 CERTATE SW G 18000H		31	6G337301	ARM LEVER SHAFT
21 CERTATE SW G 18000H		32	6J889901	BAIL
21 CERTATE SW G 18000H		33	6E096501	ROLLER WASHER
21 CERTATE SW G 18000H		34	6J042801	ROLLER COLLAR
21 CERTATE SW G 18000H		35	6J042902	LINE ROLLER
21 CERTATE SW G 18000H		36	6J019304	ROLLER BALL BEARING
21 CERTATE SW G 18000H		37	6H503605	ARM LEVER
21 CERTATE SW G 18000H		38	6H504701	ROLLER SCREW
21 CERTATE SW G 18000H		39	6H842801	RETAINING SCREW
21 CERTATE SW G 18000H		40	6H503701	ARM LEVER SCREW
21 CERTATE SW G 18000H		41	6H684801	ARM LEVER COVER
21 CERTATE SW G 18000H		42	6H503901	ARM LEVER COVER SCREW
21 CERTATE SW G 18000H		43	6H687201	ROTOR WASHER
21 CERTATE SW G 18000H		44	6G338401	CLUCH RING O RING
21 CERTATE SW G 18000H		45	6H688601	CLUCH RING
21 CERTATE SW G 18000H		46	6H684108	MAGSEALED COVER
21 CERTATE SW G 18000H		47	6H535301	MAGSEALED PLATE
21 CERTATE SW G 18000H		48	6H502601	MAGSEALED PLATE O RING
21 CERTATE SW G 18000H		49	6F765401	ONEWAY CLUCTH
21 CERTATE SW G 18000H		50	6G158101	ONEWAY CLUTCH WASHER
21 CERTATE SW G 18000H		51	6J895801	PINION BEARING PLATE
21 CERTATE SW G 18000H		52	6F206902	PINION BEARING PLATE SCREW
21 CERTATE SW G 18000H		53	6G426301	PINION BALL BEARING (A)
21 CERTATE SW G 18000H		54	6J922101	PINION BALL BEARING COLLAR (A)
21 CERTATE SW G 18000H		55	6E262701	RATCHET
21 CERTATE SW G 18000H		56	63727601	RATCHET WASHER
21 CERTATE SW G 18000H		57	6Z026140	PINION DRIVE GEAR SET
21 CERTATE SW G 18000H		58	6J921401	PINION BEARING SPRING WASHER
21 CERTATE SW G 18000H		59	63737808	PINION BEARING WASHER
21 CERTATE SW G 18000H		60	6G523401	PINION BALL BEARING (B)

REEL NAME	MGFT CODE	KEY NO	PARTS CODE	DESCRIPTION
21 CERTATE SW G 18000H		61	6J921301	PINION BALL BEARING COLLAR (B)
21 CERTATE SW G 18000H		62	6M153502	BODY
21 CERTATE SW G 18000H		63	6J894602	OSCILLATING POST
21 CERTATE SW G 18000H		64 65 66	6J920701	MAIN SHAFT
21 CERTATE SW G 18000H		65	6M067801	OSCILLATING POST COLLAR SCREW
21 CERTATE SW G 18000H		66	6J894401	OSCILLATING POST COLLAR
21 CERTATE SW G 18000H		67	6J921101	REAR CAP PACKING
21 CERTATE SW G 18000H		68	6J921201	REAR CAP
21 CERTATE SW G 18000H		69	6J894901	REAR CAP SCREW(A)
21 CERTATE SW G 18000H		70	6E272501	REAR CAP SCREW WASHER
21 CERTATE SW G 18000H		71	6J895002	REAR CAP SCREW(B)
21 CERTATE SW G 18000H		72	6J920101	OSCILLATING GEAR WASHER
21 CERTATE SW G 18000H		73	6J920201	OSCILLATING GEAR
21 CERTATE SW G 18000H		74	6J037601	OSCILLATING GEAR O RING
21 CERTATE SW G 18000H		75	63737808	OSCILLATING GEAR BEARING WASHER
21 CERTATE SW G 18000H		76	6B861702	OSCILLATING GEAR BALL BEARING
21 CERTATE SW G 18000H		77	6H347101	OSCILLATING GEAR SCREW
21 CERTATE SW G 18000H		78	6H243301	STOPPER COLLAR
21 CERTATE SW G 18000H		79	6M030401	STOPPER
21 CERTATE SW G 18000H		80	63516401	STOPPER SCREW
21 CERTATE SW G 18000H		81	6J922001	STOPPER SPRING
21 CERTATE SW G 18000H		82	6J308501	DRIVE GEAR O RING
21 CERTATE SW G 18000H		83	6J920302	IDLE GEAR
21 CERTATE SW G 18000H		84	6G336701	IDLE GEAR O RING
21 CERTATE SW G 18000H		85	6B853101	OSCILLATING GEAR NUT O RING
21 CERTATE SW G 18000H		86	6J902801	OSCILLATING GEAR NUT
21 CERTATE SW G 18000H		87	6G426301	DRIVE BALL BEARING (A)
21 CERTATE SW G 18000H		88	6J920401	DRIVE BALL BEARING WASHER (A)
21 CERTATE SW G 18000H		89	6J920601	ENGINE PLATE (R) O RING
21 CERTATE SW G 18000H		90	6M153802	ENGINE PLATE (R)
21 CERTATE SW G 18000H		91	6J042501	HANDLE CAP O RING
21 CERTATE SW G 18000H		92	6J394903	HANDLE CAP
21 CERTATE SW G 18000H		93	6G426301	DRIVE BALL BEARING (B)
21 CERTATE SW G 18000H		94	6H502203	DRIVE BALL BEARING WASHER (B)
21 CERTATE SW G 18000H		95	6J920601	ENGINE PLATE (L) O RING
21 CERTATE SW G 18000H		96	6M154102	ENGINE PLATE (L)
21 CERTATE SW G 18000H		97	6J432001	ENGINE PLATE PACKING
21 CERTATE SW G 18000H		98	6M154601	HANDLE