
PENN PARTS SCHEMATIC 210



Penn Reel Parts list for: Model: 210

KEY NO	PART NO.	DESCRIPTION
1	1-210	R.S. PLATE
2	2-210	R.S. RING
3	3-210	BRIDGE W/ SLEEVE
4	4-60	FIBER WASHER
5	5-500	MAIN GEAR
6	6-309	DRAG WASHER
7	7C-500	METAL DRAG WASHER (SET)
8	8-60	TENSION SPRING
9	9-60	SPACING SLEEVE
10	10-505	STAR DRAG
11	11-155	ECCENTRIC JACK
12	12-155	PINION YOKE
13	13-140	PINOIN GEAR
14	14-500	DOG SPRING
15	15-210	DOG
16	16-60CH	LOWER BRIDGE SCREW (2 REQ.)
17	17-60CH	UPPER BRIDGE SCREW (2 REQ.)
18	18-60	CLUTCH SPRING (2 REQ.)
19	19-209	ECCENTRIC
20	20-155	ECCENTRIC SPRING
21	21-285	ECCENTRIC LEVER
22	22-60CH	ECCENTRIC SCREW
23	23-60	HANDLE SCREW
23A	110-60	HANDLE LOCK SCREW
24	24-66	HANDLE
26	26-113H	R.S. BEARING
27	27-210	L.S. PLATE ASSEMBLY
28	28-209	L.S. RING
29L	29L-210	SPOOL (ALUMINUM)
29M	29M-210	SPOOL METAL
30	30-66	STAND
31	31-210	R.S. STAND SCREW (2 REQ.)
32	32-22	L.S. STAND SCREW (2 REQ.)

KEY NO	PART NO.	DESCRIPTION
33	33-113	ROD CLAMP
*	33R-200	RINGED ROD CLAMP (OPTIONAL)
34	34-45	ROD CLAMP SCREW
34C	34C-45	ROD CLAMP SCREW W/ NUTS
35	35-155	CLICK TONGUE
36	36N-209	CLICK BUTTON
37	37-160	FRAME POST (2 REQ)
38	39-6	R.S. POST SCREW
39	38-8	L.S. POST SCREW
40	40-210	L.S. BEARING CAP ONLY
40A	40A-210	L.S. BEARING CAP W/ BEARING
42	42-209	WORM
43	44N-109	R.S. WORM BEARING
44A	57-109	R.S. WORM BEARING SPRING
45	45N-209	WORM GEAR
46	46-209	LINE GUIDE
47	47-109	PAWL
48	48-109	PAWL COVER
50	50-209	WORM SHEILD
55	55-113H	SPOOL BEARING
58	58-209	SLOTTED POST
62	62-209	CLICK SPRING
63	63-209	CLICK SPRING SCREW
64	64-209	IDLER GEAR
65	65-209	IDLER GEAR SCREW
66	66-209	LEVEL WIND DRIVE GEAR
67	67-209	DRIVE GEAR LOCK SPRING
69B	69B-600	CLICK BUTTON RETAINING RING
98	98-505	GEAR SLEEVE
149	149-45	CLAMP NUT
149A	149-200	HEX NUT

***Not Shown**