




Key No.	Part No.	Part Name
1	6K264405	PALM SIDE COVER UNIT
2	5K349002	COMPLETE SPOOL ASSEMBLY(INCLUDES SS BEARING)
3	5K348503	FRONT SUPPORT OLTE-RH
4	6K963102	TAP SCREW
5	6K704403	LINE GUIDE CAP
6	6K148801	WASHER
7	6K256501	LEVEL WIND PIN
8	5K250602	LEVEL WIND ASSEMBLY
9	6B339801	RETAINER
10	6K456801	BUSH
11	5K095601	WORM SHAFT
12	6K456403	PIPE
13	6E096503	WASHER
14	6K469301	WORM PINION
15	6B339801	RETAINER
16	6K930403	PILLAR
17	6K062706	TAP SCREW
18	6K053406	TAP SCREW
19	5K348201	HOOK KEEPER
20	5K348102	OLTE-RH FRAME
21	5K047003	TAP SCREW
22	5K348402	THUMB BAR
23	5K320501	CLUTCH LINK
24	5K047001	TAP SCREW
25	5K086701	SPRING
26	5K348301	KICK LEVER
27	5K093401	SPRING
28	5K251301	CLUTCH CAM
29	5K251502	CAM PLATE
30	6K053403	SCREW
31	5K093701	CLUTCH
32	6K942501	COIL SPRING
33	5K243801	PINION
34	6K859301	DEAD STOP A/R CLUTCH
35	6K170701	RING
36	6K304002	SS BALL BEARING

Key No.	Part No.	Part Name
37	5K348614	GEAR SIDE COVER
38	6K961802	SCREW
39	6K904901	O-RING
40	5K348702	CAST CONTROL CAP ASSEMBLY
41	6K256901	SS BEARING
42	63201402	RETAINER
43	5K134901	BEARING PLATE
44	6E096503	WASHER
45	5K320801	GEAR METAL OLTE-RH
46	63535902	SCREW
47	6K258101	GEAR
48	6K893601	RATCHET
49	5K027101	CARBON BASE WASHER
50	5K243901	DRIVE GEAR
51	5K039901	WASHER
52	5K040001	WASHER
53	6K859205	BUSH
54	6K582202	SS BALL BEARING
55	6K177301	WASHER
56	6K177302	WASHER
57	6K259201	LEAF SPRING ASSEMBLY
58	5K027201	SPRING WASHER
59	6K193601	WASHER
60	5K348902	STAR DRAG
61	5K232001	WASHER
62	5K349309	COMPLETE HANDLE ASSEMBLY
63	TS9-DTKL	SET OF 2 KNOB INCLUDES CAPS
64	5K129202	WASHER
65	6K626402	SS BALL BEARING
66	63511816	SCREW
67	TS6-17	NUT
68	TS7-17	RETAINER
69	63520407	SCREW
70	5K126102	SS SPOOL BEARING
71	6K474502	SS PALM SIDE COVER BEARING