



PART LISTING ABU 176/276/576

| EM | PART DESCRIPTION | 176 | 276 | 576 | ITEM | PART DESCRIPTION | 176 | 276 | 576 |
|----|--------------------------------|---------|---------|---------|------|-----------------------------------|---------|---------|---------|
| 1 | Cone Assy | 1101926 | 1101926 | 1101927 | 30 | Handle Screw Washer | 1101759 | 1101759 | 1101759 |
| 2 | Cam Connexion Retainer Screw*2 | 1101731 | 1101731 | | 31 | Handle Cover*2 | 1101760 | 1101760 | 1101760 |
| 3 | Snubber Support Assy | 1101928 | 1101928 | | 32 | Clutch BB Washer | 1101761 | 1101761 | 1101761 |
| 4 | Rotor Swing Arm Spring*2 | 1101929 | 1101929 | | 33 | Main Gear Stand (B) | 1101762 | 1101762 | 1101762 |
| 5 | Rotor SEMIS | 1101930 | 1101930 | | 34 | One Way Clutch | 1101763 | 1101763 | 1101763 |
| 6 | Cam Screw*2 | 1101735 | 1101735 | | 35 | Main Gear Ball Bearing(Bushing)*2 | 1101764 | 1101764 | 1101765 |
| 7 | Connexion Spacer | 1101736 | 1101736 | | 36 | Pinion Washer | 1101766 | 1101766 | 1101766 |
| 8 | Cam Connexion Retainer | 1101737 | 1101737 | | 37 | Pinion Down Ball Bearing | 1101767 | 1101767 | 1101767 |
| 9 | Pick Up Pin Cam | 1101738 | 1101738 | | 38 | Main Gear | 1101947 | 1101947 | 1101947 |
| 10 | Main Shaft Spring (B) | 1101931 | 1101931 | | 39 | Main Gear Stand (A) | 1101769 | 1101769 | 1101769 |
| 11 | "E" Ring*2 | 1101740 | 1101740 | | 40 | Handle Connexion Retainer | 1101770 | 1101770 | 1101770 |
| 13 | Spool Ring | 1101932 | 1101932 | | 41 | Handle Space Washer | 1101771 | 1101771 | 1101771 |
| 14 | Drag Squared Washer*2 | 1101933 | 1101933 | | 42 | Double Handle Assy | N/A | N/A | 1101946 |
| 15 | Drag Teflon | 1101934 | 1101934 | | 42 | Single Handle Assy | 1101773 | 1101773 | N/A |
| 16 | Spool | 1101935 | 1101935 | | 43 | Handle Nut Cover | 1101774 | 1101774 | 1101774 |
| 17 | Drag Washer (red) | 1101936 | 1101936 | | 44 | Pinion | 1101948 | 1101948 | 1101948 |
| 18 | Drag Spring Washer | 1101937 | 1101937 | | 45 | Main Shaft Sleeve | 1101949 | 1101949 | 1101949 |
| 19 | Drag Support | 1101938 | 1101938 | | 46 | Main Shaft Spring (A) | 1101950 | 1101950 | 1101950 |
| 20 | Spool Osl. | 1101939 | 1101939 | | 47 | Gear Box Cover | MIP | 1101951 | 1101952 |
| 21 | Pinion Up Ball Bearing | 1101750 | 1101750 | | 48 | Thumb Button Support | 1101953 | 1101953 | 1101953 |
| 22 | Main Shaft Bush | 1101940 | 1101940 | | 49 | Thumb Button Assy | 1101954 | 1101954 | 1101954 |
| 23 | Frame | 1101941 | 1101941 | | 50 | Rotor Assy | 1101955 | 1101955 | 1101955 |
| 24 | Osl. Screw*2 | 1101753 | 1101753 | | 51 | Drag Clicker Screw | 1101956 | 1101956 | 1101956 |
| 25 | Drag Knob | 1101942 | 1101942 | | 52 | Drag Clicker | 1101784 | 1101784 | 1101784 |
| 26 | Drag Knob Ring | 1101943 | 1101943 | | 53 | Stand Screw *4 | 1101957 | 1101957 | 1101957 |
| 27 | Drag Knob Ring | 1101944 | 1101944 | | 54 | Gear Box Cover Screw*2 (A) | 1101786 | 1101786 | 1101786 |
| 28 | Handle Nut | 1101757 | 1101757 | | 55 | Gear Box Cover Screw (B) | 1101958 | 1101958 | |
| 29 | Handle Screw | 1101945 | 1101945 | | | | | | |