




KEY NO.	DESCRIPTION	PART NO.	KEY NO.	DESCRIPTION	PART NO.
		SX 40			SX 40
1	SPACE WASHER	1195751	42	HANDLE SCREW COVER	1279189
2	O-RING	1195755	43	SCREW (6 REQ)	1279194
3	BEARING SLEEVE	1195758	44	BEARING RETAINER (2 REQ)	1279338
4	BALL BEARING	1195757	45	SCREW	1195720
5	SEAL	1195761	46	OSCILLATION MOUNT	1279340
6	SPOOL SHAFT WASHER	1195763	47	IDLER GEAR	1195767
7	SPOOL SHAFT	1260209	48	SCREW	1221496
8	SCREW	1195642	49	GEAR BOX	1279343
9	SCREW (2 REQ)	1221453	50	SCREW (2 REQ)	1279218
10	WASHER (2 REQ)	1252583	51	SWITCH SPRING	1221500
11	BAIL ARM	1279320	52	SWITCH LEVER	1221501
12	BALL BEARING	1195641	53	IAR SWITCH	1279221
13	LINE ROLLER	1279323	54	CLIP	1221504
14	POMBUSHING	1279234	55	STEM	1279347
15	BRASS BUSHING	1279238	56	GUIDE BAR	1260233
16	O-RING	1195591	57	MAIN GEAR	1221510
17	CLIP	1195592	58	SHIM	1195560
18	BAIL HOLDER	1279324	59	HANDLE ASSEMBLY	1279350
19	BAIL WIRE	1260211	60	BALL BEARING	1195757
20	SCREW	1221460	61	OSCILLATION GEAR	1195805
21	NUT LOCKING PLATE	1195770			