

MODEL: ABU SP REV02X40

ITEM	DESCRIPTION	SAP#	ITEM	DESCRIPTION	SAP#
1	DRAG KNOB ASSY	1446976	39	ROTOR NUT	1378801
2	STOP RING	1262749	40	ROTOR NUT WASHER	1378802
3	KEY WASHER (2REQ)	1446956	41	SCREW	1378803
4	EARED WASHER	1446957	42	WASHER	1378805
5	DRAG WASHER	1225637	43	SCREW (3REQ)	1210692
6	SPOOL	1446986	44	BEARING COVER ASSY	1378883
6A	SPOOL ASSY	1446987	45	BEARING (4REQ)	1378807
7	LINE CLIP SPRING	1216569	46	BEARING SLEEVE	1378808
8	LINE CLIP	1378771	47	ONE WAY CLUTCH	1380128
9	SPOOL CLICK	1446960	48	CLUTCH SPRING	1378810
10	SPOOL SPRING	1214415	49	PINION GEAR ASSY	1446964
11	SCREW	1216396	50	SCREW (2REQ)	1378884
12	SHEET WASHER	1201745	51	SWITCH SPRING	1378885
13	CLICK GEAR	1446961	52	IAR SWITCH	1446981
14	SPOOL SHAFT WASHER	1378777	53	DUST CAP	1380131
15	MAIN SHAFT	1378928	54	SCREW (6REQ)	1378818
16	SCREW (2REQ)	1378779	55	BEARING RETAINER (2REQ)	1378935
17	BAIL HOLDER	1378929	56	SIDE COVER	1378863
18	BUSHING (2REQ)	1378781	57	DRIVE GEAR	1380133
19	BAIL WIRE ASSY	1378930	58	SHIM	1378822
20	LOWER BUSHING	1380122	59	HANDLE ASSY	1446990
21	UPPER BUSHING	1380123	60	O/S SLIDER	1409802
22	LINE ROLLER	1378785	61	SCREW	1395731
23	BEARING	1395730	62	O/S GEAR PIN	1378827
24	LINE ROLLER COLLAR	1378846	63	O/S GEAR BEARING	1393642
25	BAIL ARM	1378847	64	O/S GEAR	1403870
26	SCREW	1378789	65	O/S GEAR BUSHING	1378829
27	SCREW	1378790	66	SCREW	1395732
28	BAIL ARM COVER	1446988	67	UPPER O/S SLIDER GUIDE	1378892
29	BAIL ARM SPRING	1378849	68	LOWER O/S SLIDER GUIDE	1378893
30	SPRING SEAT	1378793	69	TRANSFER GEAR	1403857
31	PIVOT LEVER	1378794	70	REAR COVER	1446991
32	TRIP PLUNGER	1378879	71	BODY ASSY	1446992
33	ROTOR BRAKE	1378851	72	HANDLE SUB-ASSY	1446985
34	ROTOR BRAKE SPRING	1378852	73	BUSHING (2REQ)	1438531
35	RUBBER SLEEVE	1378853	74	T KNOB	1438532
36	ROTOR SCREW (3REQ)	1207341	75	SCREW	1241728
37	ROTOR	1446989	76	HANDLE KNOB COVER	1438533
38	ROTOR SLEEVE	1378933			

EXPLODED VIEW

