



Please specify reel model number and number in reel foot when ordering parts.

Vid beställning av reservdelar bör alltid rulltyp och nummerbeteckning under rullfoten anges

Ambassadeur **MAX4 61 31 00**

1543126

34-13775-0

| # | PART# | DESCRIPTION | # | PART# | DESCRIPTION | # | PART# | DESCRIPTION |
|----|---------|---------------------------|----|---------|-----------------------|-----|---------|--------------------|
| 1 | 1573327 | FRAME | 40 | 1281216 | BALL BEARING | 79 | 1573312 | MAGNET HOLDER |
| 2 | 1573165 | SLIDE WASHER RIGHT | 41 | 1415532 | MAIN GEAR SHAFT PLATE | 80 | 1116222 | MAGNET |
| 3 | 1573166 | SLIDE WASHER LEFT | 42 | 1573330 | MAIN GEAR SHAFT | 81 | 1313476 | SPRING |
| 4 | 1573167 | LINE GUIDE | 43 | 1380622 | STOPPER | 82 | 1572922 | SLIDE CAM |
| 5 | 1380597 | LEVEL WIND TUBE | 44 | 1380623 | RATCHET | 83 | 1380655 | SCREW |
| 6 | 1380696 | WORM SHAFT | 45 | 1415535 | DRAG WASHER | 84 | 1572927 | CLICK CLAW SPRING |
| 7 | 1313502 | WORM SHAFT BUSHING | 46 | 1380603 | WORM SHAFT DRIVE GEAR | 85 | 1490809 | SCREW |
| 8 | 1125732 | WORM SHAFT GEAR | 47 | 1380767 | MAIN GEAR | 86 | 1573315 | CLICK BUTTON |
| 9 | 1125733 | WORM SHAFT PIN | 48 | 1380627 | WASHER DRUM | 87 | 1572918 | WASHER |
| 10 | 1380599 | WORM SHAFT PIN HOLDER | 49 | 1380629 | DRAG WASHER | 88 | 1572928 | CLICK CLAW |
| 11 | 1185695 | WASHER | 50 | 1415536 | DRAG WASHER | 89 | 1572929 | WASHER |
| 12 | 1124201 | RETAINER | 51 | 1380702 | PRESSURE WASHER | 90 | 1144219 | RETAINER |
| 13 | 1573168 | LINE GUIDE SHAFT | 52 | 1416412 | WASHER | 91 | 1125797 | FRICTION WASHER |
| 14 | 1125806 | PAWL | 53 | 1573304 | LOCKONG PIN | 92 | 1132859 | BALL BEARING |
| 15 | 1125736 | WASHER | 54 | 1313476 | SPRING | 93 | 1104790 | RING |
| 16 | 1129323 | LINE GUIDE NUT | 55 | 1573331 | GEAR SIDE PLATE | 94 | 1573319 | SPOOL |
| 17 | 1185695 | WASHER | 56 | 1380633 | ONE WAY CLUTCH | 95 | 1380657 | BALL BEARING |
| 18 | 1380625 | LEVEL WIND GEAR | 57 | 1185714 | O-RING | 96 | 1380658 | SPOOL SHAFT PIN |
| 19 | 1144184 | WASHER | 58 | 1185879 | BUSHING | 97 | 1572931 | SPOOL GEAR |
| 20 | 1380604 | LEVEL WIND GEAR BUSHING | 59 | 1104790 | RING | 98 | 1144219 | RETAINER |
| 21 | 1573299 | SCREW | 60 | 1125828 | FRICTION WASHER | 99 | 1380728 | HANDLE |
| 22 | 1415533 | SCREW | 61 | 1125829 | RUBBER WASHER | 100 | 1208088 | BUSHING |
| 23 | 1573328 | LIFT CURVE | 62 | 1573306 | BRAKE KNOB | 101 | 1556220 | HANDLE KNOB |
| 24 | 1415528 | LIFT CURVE PLATE | 63 | 1415539 | IAR SLEEVE | 102 | 1208088 | BUSHING |
| 25 | 1116183 | SCREW | 64 | 1415540 | BALL BEARING | 103 | 1208090 | SCREW |
| 26 | 1380735 | CLUTCH SPRING | 65 | 1252080 | SCREW | 104 | 1551194 | HANDLE KNOB CAP |
| 27 | 1380736 | KICK LEVER | 66 | 1252079 | SCREW | 105 | 1380665 | WASHER |
| 28 | 1116230 | KICK LEVER SPRING BUSHING | 67 | 1380642 | SPRING WASHER | 106 | 1380666 | HANDLE NUT |
| 29 | 1127699 | KICK LEVER SPRING | 68 | 1380643 | CLICK SPRING HOLDER | 107 | 1380667 | SCREW |
| 30 | 1252059 | SCREW | 69 | 1380644 | CLICK SPRING | 108 | 1573334 | GEAR SIDE COMPLETE |
| 31 | 1380611 | THUMB BAR | 70 | 1380645 | SPRING WASHER | 109 | 1573323 | HANDLE COMPLETE |
| 32 | 1573301 | THUMB BAR SCREW | 71 | 1573332 | STAR WHEEL | 110 | 1573335 | PALM SIDE COMPLETE |
| 33 | 1573329 | FRONT COVER | 72 | 1380647 | WASHER | 111 | 1573325 | SPOOL COMPLETE |
| 34 | 1185912 | SCREW | 73 | 1573333 | PALM SIDE PLATE | 112 | 1116206 | SCREW |
| 35 | 1380740 | YOKE | 74 | 1563599 | MAG DIAL | 113 | 1573326 | WASHER |
| 36 | 1380618 | SPRING | 75 | 1125780 | CLICK SPRING | | | |
| 37 | 1380749 | PINION | 76 | 1572921 | SLIDE CAM | | | |
| 38 | 1124201 | RETAINER | 77 | 1573310 | BEARING HOUSING | | | |
| 39 | 1116187 | WASHER | 78 | 1573311 | MAGNET PLATE | | | |