



PARTS LIST OF MAXPROSP5

ITEM#	DESCRIPTION	PART#(05)	ITEM#	DESCRIPTION	PART#(05)
1	Drag Knob Assembly	1530090	30	Bearing Retainer	1280406
2	Retainer Ring	1092606	31	Washer	1114764
3	Spool Washer	1280353	32	Bearing 7*14*4	1085280
4	Key Washer	1280355	33	Bearing Holder	1115558
5	Washer	1536759	34	Clutch Assembly	1102144
6	Spool	1530091	35	Pinion	1536771
7	Spool Assembly	1530092	36	Clutch Spring	1252716
8	Washer (T=0.5)	1178949	37	Handle Screw	1530097
9	Click Gear	1085271	38	Body	1530098
10	Main Shaft	1280357	39	Slider Retainer	1121651
11	Nut Set Screw	1529596	40	Screw	1385624
12	Rotor Nut	1085606	41	Slider	1188579
13	Bail Arm Screw	1448222	42	Screw	1126275
14	Bail Holder	1530093	43	Rear Cover	1530099
15	Bushing	1538277	44	Bearing 5*8*2.5	1112125
16	Screw	1536760	45	Oscillation Gear	1280412
17	Bail Arm	1530094	46	Reduction Gear	1256967
18	Bearing 4*7*2.5	1275826	47	Bearing 7*11*3	1085280
19	Line Roller	1529959	48	Drive Gear	1538809
20	Washer	1529960	49	Washer	1085287
21	Bail Assembly	1530095	50	Body Cover	1530100
22	Screw	1411137	51	Screw	1529968
23	Bail Arm Cover	1530490	52	Handle Rivet Assembly	1530101
24	Trip Spring	1126273	53	Handle Knob	1530102
25	Trip Linkage	1252713	54	Bushing	1529970
26	Bail Slider	1128143	55	Screw	1119121
27	Trip Bar	1280403	56	Handle Knob Cover	1529972
28	Rotor	1530096	57	Handle Assembly	1530103
29	Screw	1197283			