



PARTS LIST OF MAXPROSP10

ITEM#	DESCRIPTION	PART#(10)	ITEM#	DESCRIPTION	PART#(10)
1	Drag Knob Assembly	1530104	31	Washer	1085287
2	Retainer Ring	1092606	32	Bearing 7*14*4	1085280
3	Eared Washer	1280353	33	Bearing Holder	1115558
4	Key Washer	1280355	34	Clutch Assembly	1102144
5	Washer	1536759	35	Pinion	1536772
6	Spool	1530105	36	Clutch Spring	1252716
7	Spool Assembly	1530106	37	Handle Screw	1530097
8	Washer (T=0.5)	1178949	38	Body	1530111
9	Click Gear	1126316	39	Slider Retainer	1126332
10	Main Shaft	1529977	40	Screw	1188428
11	Nut Set Screw	1529596	41	Slider	1280427
12	Rotor Nut	1085606	42	Screw	1126275
13	Bail Arm Screw	1448222	43	Rear Cover	1530112
14	Bail Holder	1530107	44	Oscillation Gear	1256966
15	Bushing	1188261	45	Bearing 5*8*2.5	1112125
16	Screw	1536760	46	Screw	1497921
17	Bail Arm	1530108	47	Reduction Gear	1256967
18	Bearing 4*7*2.5	1275826	48	Bearing 7*11*3	1092725
19	Line Roller	1529959	49	Drive Gear	1538809
20	Washer	1529960	50	Washer	1085287
21	Bail Assembly	1530109	51	Bearing 7*13*4	1252717
22	Screw	1411137	52	Body Cover	1530113
23	Bail Arm Cover	1530491	53	Screw	1447884
24	Trip Spring	1119106	54	Screw	1126084
25	Trip Linkage	1252713	55	Handle Rivet Assembly	1530101
26	Bail Slider	1126272	56	Handle Knob	1530102
27	Trip Bar	1529982	57	Bushing	1529970
28	Rotor	1530110	58	Screw	1119121
29	Screw	1117984	59	Handle Knob Cover	1529972
30	Bearing Retainer	1280406	60	Handle Assembly	1530103