



PARTS LIST OF MAXZSP30/40

ITEM#	DESCRIPTION	PART#(30)	PART#(40)	ITEM#	DESCRIPTION	PART#(30)	PART#(40)
1	Drag Knob Assembly	1529993	1529993	30	Bearing Retainer	1252715	1252715
2	Retainer Ring	1085295	1085295	31	Washer	1114764	1114764
3	Key Washer	1085296	1085296	32	Bearing 7*13*4	1252717	1252717
4	Eared Washer	1085297	1085297	33	Bearing Holder	1280475	1280475
5	Washer	1085298	1085298	34	Clutch Assembly	1102144	1102144
6	Spool	1537749	1537757	35	Pinion	1536773	1536774
7	Spool Assembly	1537750	1537758	36	Clutch Spring	1252716	1252716
8	Washer (T=0.5)	1178949	1178949	37	Handle Screw	1537733	1537733
9	Click Gear	1126316	1126316	38	Body	1537754	1537761
10	Main Shaft	1279725	1529194	39	Slider Retainer	1126332	1126332
11	Nut Set Screw	1126258	1126258	40	Screw	1188428	1188428
12	Rotor Nut	1085606	1085606	41	Slider	1279738	1529195
13	Bail Arm Screw	1448222	1448222	42	Slider Screw	1126275	1126275
14	Bail Holder	1537751	1537759	43	Rear Cover	1530067	1530077
15	Bushing	1188261	1538277	44	Oscillation Gear	1252730	1347984
16	Screw	1536760	1536760	45	Bearing 5*8*2.5	1112125	1112125
17	Bail Arm	1537752	1537752	46	Screw	1497921	1085900
18	Bearing 4*7*2.5	1275826	1275826	47	Reduction Gear	1252732	1252732
19	Line Roller	1529959	1529959	48	Drive Gear	1252725	1252725
20	Washer	1529960	1529960	49	Washer	1114764	1114764
21	Bail Assembly	1529998	1530010	50	Body Cover	1537755	1537762
22	Screw	1411137	1411137	51	Screw	1447884	1447884
23	Bail Arm Cover	1529999	1530011	52	Screw	1529196	1529196
24	Trip Spring	1119106	1119106	53	Handle Rivet Assembly	1530069	1530069
25	Trip Linkage	1252713	1252713	54	Handle Knob	1537736	1537736
26	Bail Slider	1126272	1126272	55	Screw	1119121	1119121
27	Trip Bar	1530000	1530012	56	Handle Knob Cover	1529972	1529972
28	Rotor	1537753	1537760	57	Handle Assembly	1537756	1537756
29	Screw	1126451	1092844				